

# SD700-PROFINet Application Training

## 1. Preface


SD700-NA Servo、Siemens PLC、GSDML Document、Botu Software。

The panel displays supported messages:

Example of application of message 111

Example of application of message 3

## 2. Panel Display




Status	Meaning	Status	Meaning
88.	Light on when the control power is ON, off when it is OFF	88.	Light on when the main circuit power is ON, off when it is OFF
88.	<b>Speed control:</b> Light on when the speed consistent (/V-CMP) signal output	88.	Light on when the rotation checkout (/TGON) signal output
	<b>Position control:</b> Light on when the positioning completion signal (/COIN) output	88.	<b>Speed control:</b> Light on when the speed command is input
	<b>Torque control:</b> always on		<b>Position control:</b> Light on when the position command is input
88.	Light on when servo is OFF, off when servo is ON	88.	<b>Torque control:</b> Light on when the torque command is input
		88.	<b>Position control:</b> Light on when the pulse clear signal is input

### 3. Messages Supported

Messages	Maximum number of PZDs (one PZD per word)	
Standard message 1	2	2
Standard message 3	5	9
Siemens Message 102	6	10
Siemens Message 105	10	10
Siemens Message 111	12	12
Siemens Message 750 ( Auxiliary message )	3	1


### 4. 111 Example of message application operation

Install the Botu software, open the Botu software



#### 4.1 Create a new project

Open the software, click "Create New Project", enter the project name and select the project path. Then click "Create".



Click on "Configure Device"




Click on "Add Device" and select the PLC model you are using。





## 4.2 Device Configuration


Click on "Devices and Networks"




Installing GSDML files




Find the SD700NA on the right side of the "Hardware content", double click or drag it into the "Network View"




Click on "Unallocated" as follows



Add Message




Double click on "PROFIdrive Module" in the right menu directory and add the 111 message to it.



Click "Update Accessible Devices" in "Online Access" and click "Online Diagnostics" on the scanned servo.



Assigning IP addresses and device names




### 4.3 Adding EPOS blocks

Double click on "Main[OB1]"




Select "Library" "Drive\_Lib\_S7\_1200\_1500" in the right menu, and select "SINA\_POS".




If the library is not complete, then you can download and install StartDrive software, the download link is

<https://support.industry.siemens.com/cs/us/en/view/68034568>


Drag "SINA\_POS" into "Main[OB1]", and drag it in as shown below.



Dock the variables for each interface as follows



The hardware representation is added as follows, adding "Standard\_Telegram\_111"




#### 4.4 Compile and download

After adding, compile and download.



The following compilation and download is recommended here:












#### 4.5 Trial run

After the program is downloaded, click on "Enable/Disable Monitoring".



ModePos input 2 for absolute position operation. Click Enable, enter target position and target speed, Trigger rising edge "ExecuteMode" to run the motor.






Detailed introduction can be viewed S7-1500 or S7-1200 with SD700 profinet to achieve AC3 (111 message) use case


## 5、 Example of application operation of message No. 3

### 5.1 Configuration devices


First configure the device correctly




Add message 3



Assigning IP addresses and device names





Switch to the "Topology View" interface and connect the PLC and the device according to the physical wiring. The interface on the left side of the device corresponds to the upper port of the physical device.




## 5.2 Isochronous synchronization function setting

Find the isochronous sync as shown below and check the box。




### 5.3 Adding process objects


Click "Process Object" - "New Object", add "TO\_PositioningAxis"




Add message 3 to the "Hardware Interface" as shown in the following figure:



Select the encoder type according to the encoder type set by Pn040.




If an absolute encoder is used, set the following in the "Data exchange with encoder" section.




If an incremental encoder is used, set it according to the following diagram.




At "Extended Parameters", you can set the screw distance to 60mm/rot.



At dynamic limits, set maximum speed and maximum acceleration.





Do not check the "Enable follow error monitoring" box.






## 5.4 Pointing trial run

Add the program block as shown below



Enable servo online and enter the jogging speed. Point-action operation





## 5.5 Encoder setting method

### Absolute value equation

Regardless of the encoder, G1\_XIST1 transmits only incremental values.

Absolute encoders are recommended to choose cyclic absolute encoders, the PLC calculates the multi-turn value itself.




## Incremental



## Data setup rules

23-bit single-turn, 16-bit multi-turn

Can be written as:



## 实例分析 – 多圈绝对值 (16位多圈 +23位单圈)

SIEMENS  
Ingenuity for life

	数值	位对应的含义
979[1]	0x80000002	[0] - 旋转编码器 [1] - G1_XIST1 相对位置 [31] - 979 参数值 Gx 有效
979[2]	65536	单圈脉冲 (16位)
979[3]	7	G1_XIST1 7位细分
979[4]	5	G1_XIST2 5位细分
979[5]	2048	11位多圈



G1\_XIST1


31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	R	R	R	R	R	R	R	R	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	F	F	F	F	F	F	F

G1\_XIST2

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
R	R	R	R	R	R	R	R	R	R	R	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	P	F	F	F	F	F

F 细分 P 脉冲数  
R 圆圈 E 错误码

17-bit single-turn, 16-bit multi-turn. It can be written as:



### General setting principles:


Single-turn pulse = Increment per turn \* 2<sup>Gx\_XIST1</sup>; 2<sup>Number of multi-turn positions</sup> = Number of turns \* 2<sup>Gx\_XIST2</sup>

## 6. 102+750 Perform torque limiting

First configure the device correctly, add messages 102 and 750




Set the "Base Torque" to 300% of the rated torque in the process object. And check the Torque Data



### Adopt "MC\_TORQUELIMITING" function block


This is inseparable from the configuration, first look at the process object inside the relevant configuration situation。



When load side is selected, the unit is N



Electronic gear ratio 1:1, screw pitch 60mm/rot. can also be set to other values.



The base torque is 300% of the actual motor rated torque

The conversion relationship for this limit is as follows

$F = M \cdot 2 \cdot \pi \cdot (\eta / S) \cdot (\text{molecule} / \text{Denominator})$  The numerator and denominator are the numerator and denominator of the electronic gear ratio, such as the value set in the configuration of the above figure.

F= Power

M= Torque

S= Screw pitch

$\eta$  = Screw axis efficiency


Can launch  $M = F \cdot S \cdot \text{Denominator} / (2 \cdot \pi \cdot 1000 \cdot \text{molecule})$ , Unit Nm。Where 1000mm is converted to 1m。

### Example:


Torque reduction by MOMRED, default 0x4000 corresponds to 300% reduction of rated torque ,

Torque reduction is achieved with the block "MC\_TORQUELIMITING" (PnA37 needs to be set to 0). The value of "Limit" in "MC\_TORQUELIMITING" corresponds to the torque limit value.


First enable the motor for point operation :



Then the torque is limited to 2N\*100%. Enable the "MC\_TORQUELIMITING" block :



The torque command is observed through the oscilloscope and the torque is limited to 2.98%




Why is the purpose of limiting achieved? By substituting the data of the configuration into the formula, the torque limiting value can be calculated

$$M = 2 \times 60 / (2 \times \pi \times 1000) = 0.019 \text{ Nm}$$

Percentage =  $0.019 / 0.64 = 2.98\%$  (The rated torque of the motor carried is 0.64Nm)


### Torque limiting using MC\_TORQUERANGE (function of 750 messages)

The servo is still enabled, and the forward operation is activated, and the forward torque is limited to 0.0254Nm (2% of the rated torque), as follows




Observe the torque command and torque feedback waveforms as follows :






It can be seen that the torque is limited to about 2.0%.

Negative torque limit of -0.0254Nm when running in negative jogging




The waveform of the oscilloscope is shown below, and you can see that the torque is limited to about -2%.




## 7. 102+750 for closed-loop torque control

Based on the above, add the data block "MC-PostServo", as shown in the following figure :



Write the program in the data block as follows :




Compile and download the program, go to online, and lead Tag\_1.




Call only MC\_POWER、MC\_TORQUEADDITIVE and MC\_TORQUERANGE。After enable  
MC\_TORQUEADDITIVE Given torque 0.0254 (  $0.0254/1.27=2\%$  ) . ( Motor rated torque

1.27Nm )


The waveform observes the torque command and torque feedback, as shown below. You can see that the torque command reaches 1.89%, which is close to 2%.



The additional torque becomes 0.05Nm, as follows. Torque command (  $0.05/1.27 = 3.9\%$  )




As you can see from the waveform, the torque command reaches 3.66%, which is close to 3.9%




## 8. 105+DSC function

In DSC mode, the servo receives the position deviation, position gain and velocity feedforward from the PLC. Under the DSC function, the servo's original position gain, position deviation and feedforward are invalid, and three variables need to be set on the Bottu software.

After selecting the DSC function for 105 messages, you need to set PnA38 to 1; If the DSC function is not selected, the PnA38 needs to be set to 0. The following is the block diagram of the loop for DSC control.



First select 105 messages for configuration :



Then select Enable DSC in the process object




Set servo PnA38 to 1


✓	PnA38	DSC选择	[1]启用DSC	-	0~1	0
---	-------	-------	----------	---	-----	---


Adjust the expected pre-control percentage, speed loop substitution time, gain factor, etc.

(choose according to the actual working conditions) :




Call MC\_POWER;MC\_HOME;MC\_MOVEABSOLUTE Module







Enable :




Perform zero return: Remember to cancel the zero return function after it is completed



Given target position and speed, trigger operation :



Observing the waveform, you can see that the operation condition is good.



If you need to improve the response, you can increase the percentage of "Pre-control", set the "Substitution time of speed control loop" and "Gain factor" parameters of the response. As shown below :

