


# Operation Guide of Modbus TCP

## 1.Summary

The MT01 card is a Modbus TCP fieldbus option card. This card is installed on our company's frequency converter to improve communication efficiency and facilitate the implementation of networked functions for the frequency converter. The frequency converter is controlled by the master station as a slave station. The MT01 card is suitable for our full power range products in this series.

Please read this guide carefully before using this product.



### Features:

- The bus communication rate reaches 100Mbit/s, the communication cycle is short.
- Flexible networking topology, MT01 supports all types of topologies: chain, bus, tree or star, etc, where MT01 functions as the Modbus TCP server and the master station as the client.
- The option card is directly installed on the option card slot, no external power supply is required, and the installation is convenient.


## 2.MT01 Installation

Installation steps:

- 1) Check the option card accessory package contains: Modbus TCP card,pluggable terminal \*1, screw \*1, manual;
- 2) Install the option card as shown below:

Step 1. Push the option card along the bottom rail into the bottom of the CU. Then terminals of the option card are inserted into the bottom of the CU terminal, and the two screw holes are aligned;


Step 2. as the picture shows, align the screws with the screw holes to fix the CU and the Modbus TCP card.




## 3.Electrical Connections

The MT01 module uses a standard Ethernet RJ45 socket to connect to the MODBUS TCP master station, and its pin signal definition is the same as the standard Ethernet pin, cross-wire and straight-wire are both available.

- 1) Chain network electrical connection




2) Star network electrical connection



## 4 .Status Indicator Description

MT01 expansion card can track bus communication failures through 2 status indicators. The diagnosis failure description is shown in the following table:



Indicator light	Color	Status description
ERROR	Red light is always on	ModbusTCP communication error
	Red light is flashing	Internal fault
	Red light is off	Communication is normal
STATUS	Green light is always on	Communication messages in progress
	Green light is flashing	Communication messages in progress
	Green light is off	No communication message transmission
POWER	Green light is always on	The expansion card is powered on normally
	Green light is off	The power supply of the expansion card is abnormal or the inverter is not powered on
Interface	Terminals or signals	Explanation
ModbusTCP Communication interface	RJ1	Communication interface1
	RJ2	Communication interface2
Independent power supply interface	VDD	Translation: External 24V power supply, 24V±5%; When the frequency converter is powered off, it can be powered by this port to ensure that MT01 does not lose connectivity
	GND	Power ground
	PE	Ground

## 5.Related Parameters

Parameter Number	Parameter Name	Comments
1001	IP Address[0]	IP address. E.g,192.168.0.1 set the following parameters :
1002	IP Address[1]	
1003	IP Address[2]	
1004	IP Address[3]	1001: 192 , 1002: 168 , 1003: 0 , 1004:1
1005	IP Address Mask[0]	IP address mask. E.g,255.255.255.0 set the following parameters :
1006	IP Address Mask[1]	
1007	IP Address Mask[2]	
1008	IP Address Mask[3]	1005 : 255 , 1006 : 255 , 1007 : 255 , 1008 : 0
1009	Gateway address[0]	Gateway address. E.g,192.168.0.241 set the following parameters :
1010	Gateway address[1]	
1011	Gateway address[2]	
1012	Gateway address[3]	1009 : 192 , 1010 : 168 , 1011 : 0 , 1012 : 241


## 6.Technical Specifications

Type	Specifications
Communication connector	RJ45 × 2
Network standard	IEEE 802.3/802.3u
Physical layer	10Base-T/100Base-TX
Cable Type	Category 5e shielding 100M
Protocol	Modbus TCP
Maximum number of clients	6
Port	502

## 7.Protocol Description

### 7.1.Protocol Format

ModbusTCP frame format of MT01 is shown as the figure below:



### Specification:

Field		Length	Description
MBAP Header	Transaction Identifier	2	Identification of a MODBUS Request / Response transaction.
	Protocol Identifier	2	0 = MODBUS protocol
	Length	2	Number of following bytes
	Unit Identifier	1	Identification of a remote slave connected on a serial line or on other buses.
Function code		1	Modbus function code
Data		2*N	Frequency Converter Parameter Address, Number of Parameters, and Parameter Values, etc.

### 7.2.Function Code

Function code	Description	Meaning
0x03	Read Holding Registers	Read drive functional parameters and running status parameters
0x06	Preset Single Register	Over-write individual drive functional parameters
0x10	Preset Multiple Registers	Over-write multiple Registers

### 7.3.Register Address Definition

All the following register addresses are started from 0.

#### 7.3.1.The Rules of Register Address of the Parameter Number

The parameters can be mapping to Modbus TCP register address. The read and write characteristics and ranges of frequency converter parameters still follow the instructions provided in the frequency converter manual.The rules of register address of the parameter number are shown below:

**Register address = Parameter number – 1**

**For example:**

The register address of P0-30 is  $30 - 1 = 29$  (0x001D)

The register address of P9-11 is  $911 - 1 = 910$ (0x038E)

**Attention:**

Parameters Group 8 and 9 are Read-only.

The Drive don't support write or read multiple parameters at a time.

## 7.3.2.Other Register Addresses Specification

In addition to parameter is mapped to Modbus registers, there are some additional registers within the drive which can be used to control the drive, monitor the drive's status.

Register address	Specification	R/W
9999	Control command	W
10000	Frequency command ( 0~Fmax, unit 0.01Hz )	W

## 7.3.3.Register 9999 specification

Bit	Specification
Bit 7~0(run/stop control etc.)	0x00: No function (Keep the original state unchanged) 0x01: Run forward 0x02: Reverse 0x03: Jog 0x04: Jog reverse 0x05: Stop 0x06: Coast 0x07: Reset 0x08: Clear command (Clean all running and stopping instructions)
Bit 11~8(Preset value select)	0000B:P0-30(Preset Value 0) 0001B: P0-31(Preset Value1) ... 1111B: P0-45(Preset Value 15)
Bit 13~12(Ramp time select)	00B: Ramp 1 01B: Ramp 2 10B: Ramp 3 11B: Ramp 4
Bit 14	Reserved
Bit 15	1B: Enable Bit8~13 function  0B: Disable Bit8~13 function

### 7.3.4.Communication ratio values

The Communication data is expressed by hexadecimal in actual application and there is no radix point in hexadecimal. For example, if you want to set P5-08 = 61.5, 61.5 can be magnified by 10 times into 615. So hex 0x0267 (615) can be used to express 61.5.

A non-integer can be timed by a multiple to get an integer and the integer can be called communication ratio values.

The communication ratio values are referred to the radix point of the setting range of default value in the functional parameter list. If there are radix point n, then the communication ratio value m is  $10^n$ .

### 7.3.5.Error message

There may be errors in the communication process, for example, some parameters are read-only, but the PC/PLC sends a written directive, the drive will return an error message.

Error message data frame format is shown as the figure below:



Error message function code = requirements function code + 0x80

Error code	Specification
0x01	Function code error, the drive does not support this kind of function code.
0x02	The register address is invalid.
0x03	The value exceeds the upper limit of the parameter.
0x04	Operation error.

## 8.Fault Description And Disposal

Type	ERROR	STATUS	POWER	Corresponding measures
1	Red light flashing slowly	X	X	Internal fault
2	Red light is always on	X	X	ModbusTCP communication abnormality
3	X	Green light flashing	X	ModbusTCP communication is normal
4	X	X	Green light on	MT01 power supply is normal.
5	X	X	Green light off	MT01 power supply is abnormal or not powered on