

## Preface

First of all, we'd like to extend out sincere thanks for purchasing SD500 series spindle servo drive from Veichi Electric!

SD500 series spindle servo drive is designed with high performance closed-loop vector control, featuring wide speed range, fast response, accurate positioning, etc. Its various functions and external extension interfaces, with the upper CNC system, are enough for spindle orientation, C-axis, rigid tapping, indexing and positioning. The SD500 series spindle servo drive can be widely used in machining center, CNC machine tool, CNC milling machine, tilting lathe and flying shear, chasing cut, etc., becoming the preferred drive product for various machine tool power axis.

This user manual of SD500 spindle servo drive provides product safety information, mechanical and electrical installation instructions, basic commissioning, troubleshooting and daily maintenance-related matters. To ensure correct installation and operation of the SD500 spindle servo drive and full use of its superior performance, please read this in detail before installing it. If there are any doubts about functions and performance, please consult our technical support staff for assistance.

Due to the continuous improvement of servo products, the information provided here is subject to change without notice.

## Catalog

|  |           |
|--|-----------|
| <b>Chapter 1 General.....</b>                                    | <b>1</b>  |
| 1.1 Safety Precautions .....                                     | 1         |
| 1.2 Pre-Use.....   | 2         |
| 1.3 Technical Specification .....                                | 4         |
| <b>Chapter 2 Mechanical and Electrical Installation.....</b>     | <b>6</b>  |
| 2.1 Mechanical Installation .....                                | 6         |
| 2.2 Electrical Installation.....                                 | 8         |
| <b>Chapter 3 Keyboard Layout and Operating Instructions.....</b> | <b>20</b> |
| <b>Chapter 4 Parameter Table.....</b>                            | <b>22</b> |
| 4.1 Parameter Mark Description.....                              | 22        |
| 4.2 Parameter List.....  | 22        |
| 4.3 Group F00: Environmental Applications .....                  | 23        |
| 4.4 Group F01: Basic Settings .....                              | 24        |
| 4.5 Group F02: Motor 1 Parameter.....                            | 29        |
| 4.6 Group F03: Vector Control .....                              | 35        |
| 4.7 Group F05: Input Terminal .....                              | 40        |
| 4.8 Group F06: Output Terminal .....                             | 46        |
| 4.9 Group F07: Running Control.....                              | 52        |
| 4.10 Group F10: Protection Parameters .....                      | 56        |
| 4.11 Group F11: Operator Parameters.....                         | 63        |
| 4.12 Group F12: Communication Parameters.....                    | 66        |
| 4.13 Group F15: Position Control.....                            | 69        |
| 4.14 Group F24: Spindle Control .....                            | 72        |
| 4.15 C0x Group: Monitoring Parameters.....                       | 75        |
| 4.16 Terminal Input / Output Function Selection.....             | 77        |
| 4.17 Fault And Warning Code List .....                           | 79        |
| <b>Chapter 5 Spindle Function Application Guidance .....</b>     | <b>82</b> |
| 5.1 Motor Self-Learning.....                                     | 82        |

---

|   |            |
|---|------------|
| 5.2 Speed Control .....                                     | 84         |
| 5.3 Position Control.....                                   | 88         |
| 5.4 Spindle Orientation.....                                | 90         |
| 5.5 Common Faults And Problems Explanation.....             | 93         |
| <b>Chapter 6 Inspection, Maintenance and Warranty .....</b> | <b>98</b>  |
| 6.1 Inspection.....   | 98         |
| 6.2 Maintenance.....  | 99         |
| 6.3 Product Warranty .....                                  | 99         |
| <b>Appendix .....</b>                                       | <b>100</b> |
| Appendix I: Modbus Communication Protocol.....              | 100        |
| Appendix II: Matching Cable Description .....               | 101        |

# Chapter 1 General

## 1.1 Safety Precautions

To ensure safety and proper use of this product, please fully understand the safety precautions described in this manual before using the product.

### Warning signs and meanings

The following marks are used in this manual to indicate that the place is important regarding safety. Failure to observe these precautions may result in personal injury or even death and damage to this product and associated systems.



|   |  |
|---|--|
|  Dangerous | <b>Danger:</b> major safety accidents or death may be caused due to wrong operation. |
|  Caution   | <b>Note:</b> minor injuries may be caused due to wrong operation.                    |

Table 1-1

### Operation qualifications

This product must be operated by trained professionals. Moreover, the operator must be trained with professional skills, installation methods, wiring, operation and maintenance of the equipment, and proper solutions to various emergencies that may arise during running.

### Security guidance

The warning signs are presented to prevent injury to the operator and damage to this product and associated systems; please read this manual carefully before use and follow the safety rules and warning signs strictly.

- Proper transportation, storage, installation, and careful operation and maintenance are essential to the safe operation of the spindle drive. During transportation and storage, the spindle drive must be protected from shock and vibration, and must be stored in a dry place free of corrosive gases, conductive dust, and ambient temperature lower than 60°C.
- This product carries a hazardous voltage and it controls a potentially hazardous motion mechanism. Failure to comply with the regulations of this manual may result in personal injury or death and damage to this product and associated systems.
- Do not perform wiring work while the power is on, as there is a risk of death by electric shock. Before wiring, inspection, maintenance, etc., cut off the power to all associated equipment and make sure the DC voltage of the main circuit has dropped to a safe level and wait for 5 minutes.
- The power cable, motor cable and control cable must be connected tightly, the grounding terminals must be grounded effectively, and the grounding resistance is lower than 10Ω.
- Human static electricity can seriously damage internal sensitive devices. Before performing related operations, please observe the measures and methods specified in the electrostatic preventive measures (ESD), otherwise the spindle drive may be damaged.
- Since the spindle drive output voltage is in a pulse waveform, be sure to remove or move it to the output side if there is a capacitor or varistor against lightning installed on the spindle drive's input side.
- Do not install switching devices such as circuit breakers and contactors on the output side of the spindle drive (if a switching device must be connected on the output side, the output current of the spindle drive must be 0 when the switch is operated).
- Failure at any point in the control equipment may result in production stoppage and major accidents. Therefore, please take the

necessary external protection measures or backup devices.

- This product should be used only for the purposes specified by the manufacturer, and must not be used in special areas such as emergency, rescue, marine, medical, aviation, nuclear facilities, etc. without permission.
- Maintenance of this product should only be performed by Veichi or professionals authorized by Veichi. Unauthorized modifications and use of parts that are not approved by Veichi may result in product failure. During maintenance, any defective device must be replaced timely.
- Veichi are not responsible for any injury or damage to equipment on customers' side or secondary customers if these operating instructions are not complied with.

## 1.2 Pre-use

When receive the ordered products, please check the outer packaging to see if it is damaged, then open the outer packaging and confirm that the spindle drive has no seeable damage, scratches or dirt (damage caused on the product during transportation does not belong to the scope of our "three packages"). If you receive a product with shipping damage, please contact us or the shipping company immediately. And at last, please confirm that the spindle drive model you received is the same as what you ordered.

### 1.2.1 Spindle Servo Drive Model and Nameplate Description




Figure 2-1




Figure 1-3

Rated output current of spindle servo drive

| Input voltage | 380V                    |                          |                 |
|---------------|-------------------------|--------------------------|-----------------|
| Model         | Rated input current (A) | Rated output current (A) | Motor power(kw) |
| SD500-004D-*  | 12.0                    | 10.0                     | 4.0             |
| SD500-5R5D-*  | 14.6                    | 13.0                     | 5.5             |
| SD500-7R5D-*  | 21.5                    | 17.0                     | 7.5             |
| SD500-011D-*  | 27.0                    | 25.0                     | 11.0            |
| SD500-015D-*  | 35.2                    | 32.0                     | 15.0            |
| SD500-018D-*  | 45.3                    | 38.0                     | 18.0            |
| SD500-022D-*  | 50.0                    | 45.0                     | 22.0            |
| SD500-030D-*  | 67.7                    | 60.0                     | 30.0            |
| SD500-037D-*  | 83.4                    | 75.0                     | 37.0            |

Table 1-2

## 1.2.2 Motor Naming Rules




Figure 1-3

## 1.3 Technical Specification

| Item                     | Description                 |   |
|--------------------------|-----------------------------|---|
| Power input              | Voltage & frequency         | Three-phase:380V~440V, 50/60Hz  |
|                          | Allowable fluctuation       | Voltage imbalance rate:<3%; frequency: ±5%; distortion rate in accordance with IEC61800-2 |
|                          | Closing surge current       | Lower than rated current  |
|                          | Power factor                | ≥0.94 (with DC reactor)   |
|                          | Spindle drive efficiency    | ≥96%  |
| Output                   | Output voltage              | Output under rated conditions: three-phase 380 to 440V, error less than 5%                |
|                          | Output speed range          | 4-pole motor 0~18000rpm; 0~600Hz  |
| Main control performance | Motor control mode          | Sine wave PWM modulation, fully closed-loop vector control                                |
|                          | Speed control range         | 1:1000  |
|                          | Steady-state speed accuracy | ≤0.05% rated synchronous speed  |
|                          | Starting torque             | 200% rated torque at 0Hz  |
|                          | Torque response             | <10ms   |
|                          | Speed control accuracy      | ±0.2%   |
|                          | Position control accuracy   | ±1pulse   |
|                          | Overload capacity           | 200% rated current for 20S  |
| Input/output interface   | Digital input               | 7-way optocoupler isolated input, input method NPN or PNP optional                        |
|                          | Digital output              | 2-way optocoupler isolated output   |
|                          | Analog input                | 2-way: -10V to +10V, 0 to 10V, 0 to 20mA selectable                                       |
|                          | Analog output               | 1-way:0~10V、0~20mA Optional   |
|                          | Relay output                | 2-way: two sets of normally open and normally closed contacts                             |
|                          | Encoder input interface     | 2-way: motor encoder 1 way; spindle encoder 1 way   |
|                          | Encoder output interface    | 1-way: crossover output   |
|                          | Pulse input interface       | 1-way: orthogonal pulse/direction + pulse/CW+CCW  |
| Bus interface            | None                        |   |

|                  |                            |  |
|------------------|----------------------------|--|
| Spindle function | Speed control              | Range: 0~12000RPM;   |
|                  | Directional control        | $\pm 1$ pulse accuracy; set 8 positions with terminals   |
|                  | Rigid tapping              | Connectable to a variety of imported and domestic systems with 2% tapping error  |
|                  | Encoder self-learning      | Dual encoders automatically learn directions without wiring adjustments  |
|                  | One-touch zero setting     | One touch to set any position as zero point  |
|                  | Arbitrary crossover output | 1 to 32767 arbitrary crossover output selection  |
|                  | Others                     | C-axis control, thread cutting, electronic gear, borehole, zero- speed lock  |
| Protection       |                            | Protection against overvoltage, undervoltage, current limit, overcurrent, overload, overheat, overvoltage stall, input and output phase loss, and stall, data protection, electronic thermal relay   |
| Environment      | Installation site          | Altitude below 1,000 metres, if use above 1,000 metres requires a derating of 1% for every 100 metres of elevation;<br>No condensation, icing, rain, snow, hail, etc., solar radiation below 700W/m <sup>2</sup> , air pressure 70 to 106kPa |
|                  | Temperature & humidity     | -10~+50 °C, if derate above 40 °C, max. of 60 °C (no-load running)<br>5%~95%RH (no condensation)   |
|                  | Vibration                  | When 9~200Hz, 5.9m/s <sup>2</sup> (0.6g)   |
|                  | Storage temperature        | -30~+60°C  |
|                  | Installation method        | Wall-mounted, vertical -mounted  |
|                  | Protection level           | IP20   |
|                  | Cooling method             | Forced air cooling   |

Table 1-3




## Chapter 2 Mechanical and Electrical Installation

To ensure safety during use of the product and to give play to the maximum performance of the spindle drive, please use the product in strict accordance with the environmental, wiring, and ventilation requirements described in this chapter.

### 2.1 Mechanical Installation

#### 2.1.1 Spindle Drive External Dimensions



| Drive model  | External dimensions(mm) |     |       |     |     | Mounting Dimension(mm) |      |       |   |     | Mounting aperture |
|--------------|-------------------------|-----|-------|-----|-----|------------------------|------|-------|---|-----|-------------------|
|              | W                       | H   | H1    | D   | D1  | W1                     | W2   | H2    | A | B   |                   |
| SD500-004D-* | 100                     | 242 | 231   | 156 | 149 | 84                     | 86.5 | 231.5 | 8 | 5.5 | 3-M4              |
| SD500-5R5D-* |                         |     |       |     |     |                        |      |       |   |     |                   |
| SD500-7R5D-* | 116                     | 320 | 307.5 | 176 | 169 | 98                     | 100  | 307.5 | 9 | 6   | 3-M5              |
| SD500-011D-* |                         |     |       |     |     |                        |      |       |   |     |                   |




Figure 2-1

### 2.1.2 Installation Environment and Precautions

- Environment temperature: the surrounding environment temperature has a great impact on the lifespan of the spindle servo drive, so it must not exceed the allowable temperature range (-10°C~50°C), and when the environment temperature exceeds 40°C, the external forced heat dissipation and the drive must be derated to use.
- Humidity should be below 95% and no condensation of water droplets at the site. Avoid applications with direct sunlight, oil, dust or metal dust.
- Thin air above 1000m will lead to poor heat dissipation, so please derate to use it. Derate by 1% for every 100m of elevation.

- d) The spindle drive needs to be mounted on a flame-retardant surface to ensure enough space for heat dissipation. The mounting surface needs reliably bear the weight of the spindle servo drive, otherwise there is a possibility of personnel injury or equipment damage if it falls.
- e) When the spindle drive is installed near a vibration source, please install vibration isolators on the mounting surface of the servo unit to prevent vibration from being transmitted to the servo unit.
- f) Install the spindle servo drive away from sources of electromagnetic interference.

### 2.1.3 Spindle Drive Installation Space Requirements

Heat generated from SD500 spindle servo drive is distributed in a bottom-up way, the spindle servo drive must be installed in the following vertical way (see Figure 2-1), and other components in the cabinet should be taken consideration to ensure that the SD500 spindle drive has enough space for heat dissipation. Multiple spindle servo drives are usually installed side by side, and the installation space requirements are shown in the figure below as well. In cases where the drives are mounted above or below, it is highly recommended to install thermal deflectors between the drives.




Figure 2-2

## 2.2 Electrical Installation

2.2.1 Peripheral Electrical Components and Connections




Figure 2-3

**Note:** When only one encoder is configured in the system, the spindle encoder signal terminal is invalid. The encoder signal must be connected to the motor encoder signal terminal.

2.2.2 Description of Use of External Electrical Components

| Accessory           | Mounting position          | Function description  |
|---------------------|----------------------------|---|
| Air circuit breaker | Front end of input circuit | It contacts and breaks the circuit and acts promptly to protect the downstream equipment in case of short circuit or serious overload. Rated current of air switch can be selected according to 150% of the rated current of the drive. |

|                           |  |  |
|---------------------------|--|--|
| Electromagnetic contactor | Between the air switch and the spindle servo drive | Drive power-up control. Selected according to 150% of the drive's rated current.   |
| AC reactor                | Spindle servo drive input side                     | Improve the power factor of the input side and the efficiency and thermal stability of the whole spindle drive;<br>Effectively eliminate the influence of input-side high harmonics on the spindle drive and reduce external conduction and radiation interference.<br>Selected according to 100% of the rated current of the drive. |
| Braking resistor          | Models with 37kW and below                         | For models with 37kW or lower, please use the optional braking resistor, and refer to the braking resistor matching table;<br>The motor consumes regenerative energy through the braking resistor during decelerating.   |

Table 2-1

- select braking resistor

When the spindle drive with large inertia decelerates with load or for emergency, the motor is running under the discharge state, the load energy through the inverter bridge to the spindle drive DC link, causing the spindle drive bus voltage to rise until it exceeds a certain limit, and then the drive will report an overvoltage fault, to prevent which, those external braking components need to be installed. The following table shows the typical reference values of external braking resistor specifications:

| Spindle drive model | Min. allowable braking resistance | Braking resistor power |
|---------------------|-----------------------------------|------------------------|
| SD500-004D-*        | 50Ω                               | 1.0kW                  |
| SD500-5R5D-*        | 50Ω                               | 1.0kW                  |
| SD500-7R5D-*        | 45Ω                               | 1.5kW                  |
| SD500-011D-*        | 35Ω                               | 2.0kW                  |
| SD500-015D-*        | 30Ω                               | 3.0kW                  |
| SD500-018D-*        | 30Ω                               | 3.0kW                  |
| SD500-022D-*        | 25Ω                               | 4.0kW                  |
| SD500-030D-*        | 18Ω                               | 6.0kW                  |
| SD500-037D-*        | 18Ω                               | 7.0kW                  |

Table 2-2

The table is a typical reference data, the braking resistor needs to be determined according to the power generated by the motor in the actual application system (but the braking resistance value cannot be lower than the limit in the table above), and the system inertia, deceleration time, the energy of the bit energy load, etc. are related. The greater the inertia of the system, the shorter the deceleration time required, and the more frequent the braking, the greater the power and the smaller the resistance value of the braking resistor needs to be. Users can choose different resistor resistance and power according to the actual situations, please consult our technical support for detailed calculation.

## 2.2.3 Main Circuit Terminal Description




Figure 2-4

| Terminal mark | Terminal name  | Function description                             |
|---------------|--|--|
| R、S、T         | Three-phase AC power input terminal, 380 ~ 440V, 50/60Hz | AC input three-phase power connection point      |
| (+), (-)      | DC bus positive/negative terminals                       | Common DC bus input point or external brake unit |
| (+), PB       | Brake resistor connection terminal                       | Reserved terminal for external braking resistor  |
| U、V、W         | Spindle servo driver output terminal                     | Three-phase AC output connected to the motor     |
| PE            | Ground terminal  | Power and motor ground terminal                  |

Table 2-3

● Recommended cable size for main circuit connection:

| Servo spindle drive model | Recommended cable size(mm2) |       |      | Terminal screw specification | Recommended tightening torque (N.m) |
|---------------------------|-----------------------------|-------|------|------------------------------|-------------------------------------|
|                           | R/S/T                       | U/V/W | PE   |                              |                                     |
| SD500-004D.*              | 4.0                         | 4.0   | 4.0  | M4                           | 1.2~1.5                             |
| SD500-5R5D.*              | 6.0                         | 6.0   | 6.0  | M4                           | 1.2~1.5                             |
| SD500-7R5D.*              | 6.0                         | 6.0   | 6.0  | M5                           | 2~2.5                               |
| SD500-011D.*              | 10.0                        | 10.0  | 10.0 | M5                           | 2~2.5                               |
| SD500-015D.*              | 10.0                        | 10.0  | 10.0 | M6                           | 4~6                                 |
| SD500-018D.*              | 16.0                        | 16.0  | 16.0 | M6                           | 4~6                                 |
| SD500-022D.*              | 16.0                        | 16.0  | 16.0 | M6                           | 4~6                                 |
| SD500-030D.*              | 25.0                        | 25.0  | 25.0 | M8                           | 8~10                                |


|              |      |      |    |      |
|--------------|------|------|----|------|
| SD500-037D-* | 25.0 | 25.0 | M8 | 8~10 |
|--------------|------|------|----|------|

Table 2-4

**Main circuit notes:**

- The input side wiring of the spindle servo drive has no phase sequence requirement, and attention should be paid to the electrical specifications of the power input.
- External power wiring specifications and installation methods need to comply with local regulations and relevant IEC standards
- The braking resistor is selected with reference to the recommended value and the wiring distance is shorter than 5m.
- The output side of the spindle servo drive must not be connected to capacitors or surge absorbers, otherwise it will cause frequent protection or even damage to the spindle servo drive.
- Separate the motor cable, input power cable and control cable alignment.
- Please use ground wires of the diameter specifications in the technical standards for electrical equipment, and it should be as closer as possible to the ground point, ground resistance at  $4\Omega$  or below. Do not share the ground wires with the welding machines or power equipment.

2.2.4 Pulse-type Control Circuit Wiring




Note:  means shielded twisted pair cables

Figure 2-5



● Control signal function description

| Category       | Terminal mark                    | Terminal name                         | Definition of terminal functions   |
|----------------|----------------------------------|---------------------------------------|--|
| Power supply   | +5V-DGND                         | External +5V power supply             | Encoder power supply with terminals, encoder power supply maximum output current: 300mA  |
|                | +10V-GND                         | External +10V power supply            | Provide +10V power supply, maximum output current: 50 mA. Generally used as the power supply for external potentiometer, potentiometer resistance range: 1K $\Omega$ ~ 5K $\Omega$   |
|                | +24V-COM                         | External +24V power supply            | External +24V power supply, generally used as power supply for digital input/output terminals and external sensor Maximum output current: 100 mA   |
| Analog         | A11-GND                          | Voltage-type analog input             | 1. Input range: A11: -10V~+10V; A12:0~10V/0~20mA, default by voltage-type input, setting by function code P05.42.<br>2. Input impedance: voltage-type input impedance 20k $\Omega$ , current type input impedance 500 $\Omega$ .   |
|                | A12-GND                          | Voltage or current-type analog input  |  |
|                | AO-GND                           | Voltage or current-type analog output | Output range: voltage 0~+10V or current 0~20mA, default by voltage-type output, setting by function code P06.00.   |
| Digital Input  | X1、X2<br>X3、X4<br>X5、X6<br>X7、X8 | Switching input, high-speed input     | 1.Input impedance: 4.4 K $\Omega$<br>2. Voltage range at level input: 10 ~ 30V<br>3. Bidirectional input terminal for both NPN and PNP connection.<br>4. X7 can be used as a high-speed pulse input channel with a maximum input frequency of 100 kHz in addition to the features of X1 to X6. 5.<br>5. All of them are programmable digital input terminals. terminal function setting via the function code. |
|                | A+/A-<br>B+/B-<br>Z+/Z-          | Spindle incremental encoder input     | Only for RS-485 standard differential signal transmitter signal  |
|                | PULS+/PULS-<br>SIGN+/SIGN-       | Position command signal               | Only for RS-485 standard differential signal transmitter signal  |
| Digital output | Y1+/COM<br>Y2+/COM               | Switching output 1, 2                 | Optocoupler isolation, open collector output<br>1.Output voltage range: DC 0V~30V<br>2.Output current range: DC 0mA~50mA   |
|                | TA1/TB1/TC1<br>TA2/TB2/TC2       | Relay output 1, 2                     | TA1-TC1/ TA2-TC2: normally open;<br>TB1-TC1/ TB2-TC2: normally closed;<br>Contact capacity: 30VDC/1A   |
|                | OA+/OA-<br>OB+/OB-<br>OZ+/OZ-    | Encoder crossover output              | Differential output, the receiver needs to use RS-485 standard differential signal receiver  |

Table 2-5

### 2.2.5 Wiring Terminal Pin Definition




Figure 2-6

- CN1 multi-function control terminal pin definition:

| CN1 multi-functional terminal interface |             |                                |         |             |                                |
|---|-------------|--------------------------------|---------|-------------|--------------------------------|
| Pin No.                                 | Signal name | Function                       | Pin No. | Signal name | Function                       |
| 1                                       | AGND        | Analog GND                     | 23      | -           | -                              |
| 2                                       | 10V+        | Internal 10V,100mA             | 24      | -           | -                              |
| 3                                       | AGND        | Analog GND                     | 25      | X5          | Multi-function contact input 5 |
| 4                                       | SIGN-       | Command direction-             | 26      | X2          | Multi-function contact input 2 |
| 5                                       | PULS-       | Pulse command-                 | 27      | SC          | I/O public terminal+           |
| 6                                       | OB-         | Crossover output OB-           | 28      | Y2+         | Open collector output 2+       |
| 7                                       | OA-         | Crossover output OA-           | 29      | TB2         | Relay B2                       |
| 8                                       | -           | -                              | 30      | TB1         | Relay B1                       |
| 9                                       | -           | -                              | 31      | AO1         | 0~10V, 0~20mA optional         |
| 10                                      | X4          | Multi-function contact input 4 | 32      | AGND        | Analog GND                     |
| 11                                      | X1          | Multi-function contact input 1 | 33      | DGND        | Digital GND                    |
| 12                                      | 24V+        | Internal 24V,100mA             | 34      | DGND        | Digital GND                    |
| 13                                      | Y1+         | Open collector output 1+       | 35      | OZ-         | Crossover output OZ-           |
| 14                                      | TA2         | Relay A2                       | 36      | OZ+         | Crossover output OZ+           |
| 15                                      | TA1         | Relay A1                       | 37      | -           | -                              |
| 16                                      | AI2         | 0~10V, 0~20mA optional         | 38      | -           | -                              |
| 17                                      | AI1         | -10V~+10V                      | 39      | X7          | Multi-function contact input 7 |
| 18                                      | AGND        | Analog GND                     | 40      | X6          | Multi-function contact input 6 |
| 19                                      | SIGN+       | Command direction +            | 41      | X3          | Multi-function contact input 3 |
| 20                                      | PULS+       | Pulse command +                | 42      | COM         | Internal +24V power to ground  |
| 21                                      | OB+         | Crossover output OB+           | 43      | TC2         | Relay C2                       |
| 22                                      | OA+         | Crossover output OA+           | 44      | TC1         | Relay C1                       |

Table 2-6

- CN2 multi-function control terminal pin definition:




Figure 2-7

| CN2 encoder interface |             |                           |         |             |                         |
|-----------------------|-------------|---------------------------|---------|-------------|-------------------------|
| Pin No.               | Signal name | Function                  | Pin No. | Signal name | Function                |
| 1                     | U-          | Spindle encoder signal A- | 8       | A+          | Motor encoder signal A+ |

|         |          |                           |    |    |                            |
|---------|----------|---------------------------|----|----|----------------------------|
| 2       | W-       | Spindle encoder signal Z- | 9  | B+ | Motor encoder signal B+    |
| 3       | A-       | Motor encoder signal A-   | 10 | V+ | Spindle encoder signal B+  |
| 4       | B-       | Motor encoder signal B-   | 11 | T1 | Motor overheating          |
| 5       | V-       | Spindle encoder signal B- | 12 | 5V | Motor encoder power supply |
| 6       | U+       | Spindle encoder signal A+ | 13 | 0V | Motor encoder power supply |
| 7       | W+       | Spindle encoder signal Z+ | 14 | Z- | Motor encoder signal Z-    |
| Housing | Shielded | -                         | 15 | Z+ | Motor encoder signal Z+    |

Table 2-7

**Note:** If the system is equipped with only one encoder, the spindle encoder signal terminal is invalid, and the encoder signal must be connected to the motor encoder signal terminal.




Figure 2-8

- CN6 network terminal pin definition:

| CN6A/CN6B interface definition |             |                                |         |             |            |
|--------------------------------|-------------|--------------------------------|---------|-------------|------------|
| Pin No.                        | Signal name | Function                       | Pin No. | Signal name | Function   |
| 1                              | GND         | Signal ground                  | 6       | -           | -          |
| 2                              | -           | -                              | 7       | 485-        | 485 data-  |
| 3                              | GND         | Signal ground                  | 8       | 485+        | 485 data + |
| 4                              | +5V         | External keyboard power supply | Housing | Shielded    | Shielded   |
| 5                              | +5V         |                                |         |             |            |

Table 2-8

### 2.2.6 Control Circuit Wiring Instructions

#### ◆ AI analog input circuit:

SD500 spindle servo provides two analog input interfaces AI1 (-10~+10V) and AI2 (0~+10V or 0~20mA). Since the weak analog signals are susceptible to external interference, the wiring control cables should be sufficiently far away from the main circuit and strong power cables (including power cables, motor cables, relays, contactor connection cables, etc.) for more than 30cm and avoid parallel placement. The connection cable is strongly recommended to use twisted shielded pair cables, and the cable shielding layer should be reliably connected to the drive terminal housing, and the wiring distance should be as short as possible. In some cases where the analog signal is subject to serious interference, a ferrite magnet ring can be added near the driver end. The following diagram shows the analog input terminal wiring diagram:




Figure 2-9

◆ Digital input terminal wiring:

The digital input terminals X1 to X7 support either drain or source wiring. The following is an example of X1, and interface circuit for X1 to X7 are all the same. The following is an example of wiring through a relay or transistor circuit (drain or source wiring). When using a relay connection, select a relay for microcurrent. If there is no such relay for microcurrent, it may cause poor contact.

a) Drain-type wiring




Figure 2-9

b) Source-type wiring




Figure 2-10

c) Relay-type wiring




Figure 2-11

Notes:

- The above examples are all powered by external power supply. If you use the internal power supply of the drive, please connect according to the dotted cable shown in the figure.
- The external power supply (DC24V) must have a capacity of 50mA or more.
- Mixing of NPN and PNP input methods is not supported.

◆ Digital output terminal wiring

Take Y1 as an example, Y1/Y2 circuit interface circuits are the same.

The following diagram shows wiring of the upper receiver device of an optocoupler and a relay respectively:




Figure 2-12

Notes:

- When the digital output terminal needs to drive the relay, absorber diodes should be added on both ends of the relay coils, and the diode

polarity should be installed correctly, otherwise it will cause damage to the equipment.

- The maximum allowable voltage is DC 30V and maximum allowable current is DC20mA for open collector output circuit.

### 2.2.7 Noise and High Harmonic Countermeasures

Here explains the countermeasures against noise and high harmonics.

This servo unit has a built-in microprocessor. Therefore, it may be subject to noise interference from its peripheral devices. To prevent mutual noise interference between the servo unit and its peripheral devices, take the following countermeasures to prevent noise interference as necessary.

- Be sure to locate the input command device and noise filter as close as possible to the servo unit.
- Be sure to connect surge suppressors to the coils of relays, solenoids, and solenoid contactors.
- Do not use the same bushing for the main circuit cable and the input/output signals/encoder cable, and do not tie them together. When wiring, keep the main circuit cable and the input/output signal cable/encoder cable away apart above 30 cm.
- Do not use the same power source with a welding machine or EDM machine, etc. Even if the power supply is not the same, connect a noise filter to the input side of the main circuit power cable and control power cable when there is a high frequency generator nearby.

## Chapter 3 Keyboard Layout and Operating Instructions




Figure 3-1

| Integrated keyboard       | Function   |
|---------------------------|--|
| Menu<br>MODE              | During standby or running, enter the menu to see functions; During parameter modification, press the key to exit; During standby or running, press and hold the key (1 second) to enter the status interface directly. |
| Confirm /Move<br>SET<br>◀ | Confirm function: press the key after modifying the value to confirm it.<br>Move function: long press the key to move the function digit, long press without releasing activate cyclic move.                           |
| Up/Down<br>▲ ▼            | Value modification: up key increases the value; down key decreases the value;<br>Fault reset: press the up and down keys simultaneously to enable fault reset  |

Table 3-1

### • Basic parameter group setting

The following is an example of setting F1.22 [acceleration time] = 10.00s to illustrate the basic operation of the LED operator.




Figure 3-2

**Note:** Use the keyboard move key to quickly select the tens, hundreds and thousands bits of the modified parameter values.

• Check monitoring status




Figure 3-3

**Note:** When using the external keyboard, use the left move button to cycle through the first row of monitoring parameters, and use the right move button to cycle through the second row of monitoring parameters.

• Check monitoring parameters

The following is an example of checking C02.05 [PLC running phase] to illustrate the basic LED operator.




Figure 3-4

• Motor Self-learning

To deliver the best control performance, self-learning of motor running system parameters under vector control need self-learning. Please refer to the following figure for the self-learning process. Please select rotary self-learning for the first time, and make sure the motor is in no-load or light-load state during the self-learning process.




Figure 3-5



## Chapter 4 Parameter Table

### 4.1 Parameter Mark Description

#### ◆Marks and terms indicating control modes

| Mark  | Content  |
|-------|--|
| V/F   | Valid parameters in V/F control mode for asynchronous motors               |
| SVC   | Valid parameters under open-loop vector control of asynchronous motors     |
| FVC   | Valid parameters under closed-loop vector control of asynchronous motors   |
| PMVF  | Valid parameters in V/F control mode for synchronous motors                |
| PMSVC | Valid parameters in open-loop vector control mode for synchronous motors   |
| PMFVC | Valid parameters in closed-loop vector control mode for synchronous motors |

Table 4-1

Note: The control mode marks not shaded indicate that the parameters are not valid in that control mode.

#### ◆Marks and terms indicating control modes

| Mark | Content   |
|------|---|
| RUN  | Parameters that can be modified during running                                |
| STOP | Parameters that cannot be modified during running                             |
| READ | The parameter can only be read, not modified (LED shows 5 "--" when modified) |

Table 4-2

### 4.2 Parameter List

#### ◆Parameters types of this product

| Parameter     | Designation  | Parameter     | Designation                              |
|---------------|--|---------------|--|
| F00.0x        | Environment settings                               | F06.2x-F06.3x | Digital, relay output                    |
| F01.0x        | Basic command                                      | F06.4x        | Frequency detection                      |
| F01.1x        | Frequency command                                  | F06.5x        | Monitor parameter comparator output      |
| F01.2x-F01.3x | Acceleration/deceleration time                     | F06.6x        | Virtual input/output terminal            |
| F01.4x        | PWM control  | F07.0x        | Start control                            |
| F02.0x        | Motor basic parameters and self-learning selection | F07.1x        | Stop control                             |
| F02.1x        | Advanced parameters of asynchronous motors         | F07.2x        | DC braking and speed tracking            |
| F02.2x        | Advanced parameters of synchronous motors          | F07.3x        | Jogging                                  |
| F02.3x-F02.4x | Encoder parameter                                  | F07.4x        | Start/stop frequency holding and hopping |
| F02.5x-F02.60 | Motor application parameter                        | F10.0x        | Current protection                       |
| F02.6x-F02.7x | Sine-cosine encoder parameter                      | F10.1x        | Voltage protection                       |
| F03.0x        | Speed loop   | F10.2x        | Auxiliary protection                     |
| F03.1x        | Current loop and torque limit                      | F10.3x        | Load protection                          |

|               |   |        |                                     |
|---------------|---|--------|-------------------------------------|
| F03.2x        | Torque optimization control             | F10.4x | Stall protection                    |
| F03.3x        | Magnetic flux optimization              | F10.5x | Failure recovery protection         |
| F03.4x-F03.5x | Torque control                          | F11.0x | Key operation                       |
| F03.7x        | Position compensation                   | F11.1x | Cyclic monitoring of status screens |
| F03.8x        | Extension control                       | F11.2x | Monitoring parameter control        |
| F05.0x        | Digital input terminal                  | F12.0x | MODBUS slave parameter              |
| F05.1x        | Curve X1-X5 detection delay             | F12.1x | MODBUS master parameter             |
| F05.2x        | Digital input terminal action selection | F12.6x | M3 bus communication                |
| F05.3x        | PUL terminal                            | F15.xx | Position control parameter          |
| F05.4x        | Analog AI type processing               | F24.xx | Spindle-specific parameter          |
| F05.5x        | Analog AI liner processing              | C00.0x | Basic monitoring                    |
| F05.6x        | AI curve 1 processing                   | C01.0x | Fault monitoring                    |
| F05.7x        | AI curve 2 processing                   | C02.0x | Application parameter monitoring    |
| F05.8x        | AI as digital input terminal            | C04.xx | Spindle feedback monitoring         |
| F06.0x        | AO analog output                        | C05.xx | Position control monitoring         |

Table 4-3

### 4.3 Group F00: Environmental Applications

#### ◆ Group F00.0x: Environment setting

| Parameter code<br>(Address) | Designation               | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---------------------------|---|----------------------------|--------------------------|
| F00.00<br>(0x0000)          | Parameter access<br>level | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the parameter access level according to the restriction level.</p> <p>0: Standard parameters (Fxx.yy)</p> <p>1: Common parameters (F00.00,Pxx.yy)</p> <p>2: Monitored parameters (F00.00,Cxx.yy)</p> <p>3: Changed parameters (F00.00,Hxx.yy)</p> | 0<br>(0-3)                 | RUN                      |
| F00.03<br>(0x0003)          | Initialization            | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the spindle drive initialization method.</p> <p>0: No initialization</p> <p>11: Select the parameters according to the usage (motor parameters are not included)</p> <p>22: All parameters initialized</p> <p>33: Clear fault records</p>         | 0<br>(0-33)                | STOP                     |

|                    |                                    |  |                |      |
|--------------------|------------------------------------|--|----------------|------|
| F00.04<br>(0x0004) | Keyboard parameter<br>copy         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: No function<br>11: Upload parameters to keyboard<br>22: Download parameters to spindle drive | 0<br>(0~9999)  | STOP |
| F00.05<br>(0x0005) | User password                      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Used to set the user password.  | 0<br>(0~65355) | STOP |
| F00.06<br>(0x0006) | LCD keyboard<br>language selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Select the language to be displayed on the LCD operator.<br>0: Chinese;<br>1: English;          | 0<br>(0~1)     | RUN  |

Table 4-4

#### 4.4 Group F01: Basic Settings

##### ◆ Group F01.0x: Basic instructions

| Parameter code<br>(Address) | Designation                | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|----------------------------|--|----------------------------|--------------------------|
| F01.00<br>(0x0100)          | Motor 1 control method     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Control mode of the motor<br>0: AM-VF; asynchronous motor V/F control<br>1: AM-SVC; asynchronous motor open-loop vector control<br>2: AM-FVC; asynchronous motor closed-loop vector control<br>10: PM-VF; synchronous motor V/F control<br>11: PM-SVC; synchronous motor open-loop vector control<br>12: PM-FVC; synchronous motor closed-loop vector control | 2<br>(0~12)                | STOP                     |
| F01.01<br>(0x0101)          | Command running<br>channel | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Channels used to select the spindle drive to receive start/stop commands and the running direction<br>0: Keypad control<br>1: Terminal control<br>2: RS485 communication control<br>3: M3 Bus communication   | 1<br>(0~3)                 | RUN                      |

|                            |  |   |                       |      |
|----------------------------|--|---|-----------------------|------|
| F01.02<br>(0x0102)         | Frequency giving<br>source channel A       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>source channel A selection to give frequency for spindle drive<br>0: Keyboard number entering<br>1: Keyboard analog potentiometer<br>2: Voltage analog AI1<br>3: Current/voltage analog AI2<br>4: Reserved<br>5: Terminal pulse PUL<br>6:RS485 communication<br>7: Terminal UP/DW control<br>8: PID control<br>9: Program control (PLC)<br>10: Positioning pulse terminal<br>11: Multi-speed | 10<br>(0~11)          | RUN  |
| F01.03<br>(0x0103)         | Frequency giving<br>source channel A gain  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Gain of the frequency giving source channel A  | 100.0<br>(0.0~500.0%) | STOP |
| F01.04<br>(0x0104)         | Frequency giving<br>source channel B       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Source channel B selection to give frequency for spindle drive, the same as [F01.02]   | 2<br>(0~11)           | RUN  |
| F01.05<br>(0x0105)         | Frequency giving<br>source channel B gain  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Gain of the frequency giving source channel B  | 100.0<br>(0.0~500.0%) | STOP |
| F01.06<br>(0x0106)         | Reference frequency of<br>source channel B | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The reference source for the frequency giving channel B is selected by this parameter.<br>0: Maximum output frequency as the reference source<br>1: Channel A frequency set as the reference source  | 0<br>(0~1)            | RUN  |
| F01.07<br>(0x0107)<br>STOP | Selection of frequency<br>giving source    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Used to select the combination of channel A and channel B to set frequency for spindle drive.<br>0: Channel A<br>1: Channel B<br>2: Channel A+ Channel B   | 0<br>(0~5)            | RUN  |

|                    |  |   |                             |     |
|--------------------|--|---|-----------------------------|-----|
|                    |  | <p>3: Channel A - Channel B</p> <p>4: Channel A, channel B both maximum value</p> <p>5: Channel A, channel B both minimum value</p>   |                             |     |
| F01.08<br>(0x0108) | Frequency giving via bundled commands          | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>When this parameter is valid, it is used to set the frequency source channel for each bundled command.</p> <p>Ones-bit: Keyboard to bundle commands;</p> <p>Tens-bit: Terminal to bundle commands;</p> <p>Hundreds-bit: Communication to bundle commands;</p> <p>Thousands-bit: Card to bundle commands;</p> <p>0: No bundle</p> <p>1: Keyboard number entering to give frequency;</p> <p>2: Keyboard analog potentiometer to give frequency;</p> <p>3: Voltage analog AI1 to give frequency;</p> <p>4: Current/voltage analog AI2 to give frequency;</p> <p>5: Reserved;</p> <p>6: Terminal pulse PUL to give frequency;</p> <p>7: Communication to give frequency;</p> <p>8: Terminal UP/DW control;</p> <p>9: PID control to give frequency;</p> <p>A: Program control to give frequency;</p> <p>B: Reserved;</p> <p>C: Multi-Speed feeding;</p> | 0000<br>(0000~DDDD)         | RUN |
| F01.09<br>(0x0109) | Frequency giving from keyboard number entering | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set and modify frequency via keyboard number entering.</p>  | 50Hz<br>(0.00~ upper limit) | RUN |

Table 4-5

## ◆ Group F01.1x: Frequency command

| Parameter code<br>(Address) | Designation   | Content  | Default<br>(Setting range)             | Adjustable<br>properties |
|-----------------------------|---------------|--|--|--------------------------|
| F01.10<br>(0x010A)          | Max frequency | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>The maximum frequency that can be set for the spindle drive.</p> | 150.00Hz<br>(upper limit<br>frequency) | STOP                     |

|                    |   |   |  |      |
|--------------------|---|---|--|------|
|                    |   |   | ~600.00Hz)   |      |
| F01.11<br>(0x010B) | Upper limit<br>frequency source<br>selection            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Select the source of the upper limit frequency for the spindle drive.<br>0: Via keyboard number entering;<br>1: Via keypad analog potentiometer;<br>2: Via current/voltage analog AI1;<br>3: Via current/voltage analog AI2;<br>4: Reserved;<br>5: Via terminal pulse PUL;<br>6: Via RS485 communication<br>7: Selection card; | 0<br>(0~7)   | RUN  |
| F01.12<br>(0x010C) | Upper limit<br>frequency setting via<br>keyboard number | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The upper limit frequency giving channel when F01.11 is set to 0.  | 150.00Hz<br>(0.00~ Max.<br>frequency set<br>via numbers) | RUN  |
| F01.13<br>(0x010D) | Lower limit<br>frequency                                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the lower limit for the given frequency.   | 0.00Hz<br>(0.00~ Max.<br>frequency set<br>via numbers)   | RUN  |
| F01.14<br>(0x010E) | Frequency<br>command resolution                         | <b>V/F SVC FVC PMV/F PMSVC PMFVC</b><br>Set the resolution of the frequency command.<br>0:0.01Hz                      1:0.1Hz   | 0<br>(0~3)   | STOP |

Table 4-6

◆ Group F01.2x-F01.3x: Acceleration/deceleration time

| Parameter<br>code  | Designation                                 | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|--------------------|---|---|----------------------------|--------------------------|
| F01.20<br>(0x0114) | Acceleration/deceleration<br>time reference | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the reference frequency to calculate the acceleration/deceleration time.<br>0: Maximum frequency as reference<br>1: Fixed frequency 50Hz as reference<br>2: Frequency set as reference | 0<br>(0~2)                 | STOP                     |

|                    |  |  |  |      |
|--------------------|--|--|--|------|
| F01.21<br>(0x0115) | Acceleration time unit                                     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set unit of acceleration time.<br>0:1S 1:0.1S 2:0.01S   | 2<br>(0~2)                                       | STOP |
| F01.22<br>(0x0116) | Acceleration time 1  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The time it takes to accelerate the output frequency from 0.00Hz to the time reference frequency.<br>1~65000s (F01.21 = 0)<br>0.1~6500.0s (F01.21 = 1)<br>0.01~650.00s (F01.21 = 2) | Set by models(0.01~650.00s)                      | RUN  |
| F01.23<br>(0x0117) | Deceleration time1   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The time it takes for the output frequency to decelerate from the time reference frequency to 0.00Hz.   | Set by models(0.01~650.00s)                      | RUN  |
| F01.30<br>(0x011E) | S-curve acceleration/deceleration selection                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Whether S curve acceleration / deceleration setting is valid<br>0: Invalid; 1: Valid  | 0<br>(0~1)                                       | STOP |
| F01.31<br>(0x011F) | Accelerate time to start S-curve                           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the acceleration time to start S-curve.   | 0.20s<br>(0.00~10.00)                            | STOP |
| F01.32<br>(0x0120) | Accelerate time to end S-curve                             | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the acceleration time to end S-curve.   | 0.20s<br>(0.00~10.00)                            | STOP |
| F01.33<br>(0x0121) | Decelerate time to start S-curve                           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the deceleration time to start S-curve.   | 0.20s<br>(0.00~10.00)                            | STOP |
| F01.34<br>(0x0122) | Decelerate time to end S-curve                             | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the deceleration time to end S-curve.   | 0.20s<br>(0.00~10.00)                            | STOP |
| F01.35<br>(0x0123) | Switching frequency between acceleration time 1 and time 2 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the switching frequency of acceleration time 1 and acceleration time 2.   | 0.00Hz<br>(0.00~ Max. frequency set via numbers) | RUN  |

Table 4-7

## ◆ Group F01.4x: PWM control

| Parameter code<br>(Address) | Designation       | Content   | Default<br>(Setting range)     | Adjustable<br>properties |
|-----------------------------|-------------------|---|--------------------------------|--------------------------|
| F01.40<br>(0x0128)          | Carrier frequency | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Used to set the switching frequency of the spindle drive IGBT. | Set by models<br>(1.0~16.0kHz) | RUN                      |

|                    |                                |   |                         |     |
|--------------------|--------------------------------|---|-------------------------|-----|
| F01.41<br>(0x0129) | PWM control mode               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: Carrier is related to temperature or not;<br>0: Irrelated<br>1: Related<br>Tens-bit: Carrier is related to output frequency or not;<br>0: Irrelated<br>1: Related<br>Hundreds-bit: Random PWM enabling<br>0: Off<br>1: On<br>Thousands-bit: PWM method<br>0: Only three-phase modulation;<br>1: Automatically switching between two- and three-phase | 1101<br>(0000~1111)     | RUN |
| F01.43<br>(0x012B) | Dead-time<br>compensation gain | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Gain of dead-time compensation   | Set by<br>models(0~512) | RUN |

Table 4-8

#### 4.5 Group F02: Motor 1 Parameter

##### ◆ Group F02.0x: Basic motor parameters and self-learning selection

| Parameter code<br>(Address) | Designation              | Content  | Default<br>(Setting range)      | Adjustable<br>properties |
|-----------------------------|--------------------------|--|---------------------------------|--------------------------|
| F02.00<br>(0x0200)          | Motor type               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the type of motor<br>0: Asynchronous motor (AM) 1: Permanent magnet<br>synchronous motor (PM) | 0<br>(0~1)                      | READ                     |
| F02.01<br>(0x0201)          | Motor pole No.           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the number of motor poles.  | 4<br>(2~98)                     | STOP                     |
| F02.02<br>(0x0202)          | Motor rated power        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated power of the motor.   | Set by models<br>(0.1~1000.0kW) | STOP                     |
| F02.03<br>(0x0203)          | Motor rated<br>frequency | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated frequency of the motor.   | Set by models<br>(0.01~最大频率)    | STOP                     |
| F02.04<br>(0x0204)          | Motor rated speed        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated speed of the motor.   | Set by models<br>(0~65000rpm)   | STOP                     |
| F02.05                      | Motor rated voltage      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>  | Set by models                   | STOP                     |



|                    |                                       |  |                                |      |
|--------------------|---------------------------------------|--|--------------------------------|------|
| (0x0205)           |                                       | Set the rated voltage of the motor.  | (0~1500V)                      |      |
| F02.06<br>(0x0206) | Motor rated current                   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated current of the motor.   | Set by models<br>(0.1~3000.0A) | STOP |
| F02.07<br>(0x0207) | Motor parameter self-tuning selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The value of [F02.07] will be set to "0" automatically after the parameter self-tuning is completed.<br><br>0: No operation<br>1: Static + rotary self-learning<br>2: Static self-learning<br>3: Stator resistance self-learning<br><br>6: Rotary self-learning<br>7: Inertia self-learning | 0<br>(0~7)                     | STOP |

Table 4-9

◆ Group F02.1x: Advanced parameters of asynchronous motors

| Parameter code<br>(Address) | Designation                        | Content   | Default<br>(Setting range)        | Adjustable<br>properties |
|-----------------------------|------------------------------------|---|-----------------------------------|--------------------------|
| F02.10<br>(0x020A)          | No-load current                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the no-load current of the asynchronous motor.           | Set by models<br>(0.1~3000.0A)    | STOP                     |
| F02.11<br>(0x020B)          | Stator resistance                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Sets the stator resistance value of the asynchronous motor.  | Set by models<br>(0.01mΩ~60000mΩ) | STOP                     |
| F02.12<br>(0x020C)          | Rotor resistance                   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Sets the rotor resistance value of the asynchronous motor.   | Set by models<br>(0.01mΩ~60000mΩ) | STOP                     |
| F02.13<br>(0x020D)          | Stator leakage inductance          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the stator leakage inductance of the asynchronous motor. | Set by models<br>(0.01mH~65535mH) | STOP                     |
| F02.14<br>(0x020E)          | Stator inductance                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the stator inductance of the asynchronous motor.         | Set by models<br>(0.01mH~65535mH) | STOP                     |
| F02.15<br>(0x020F)          | Per-unit stator resistance         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the stator resistance per unit value.                    | Set by models<br>(0.01~50.00%)    | READ                     |
| F02.16<br>(0x0210)          | Per-unit rotor resistance          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rotor resistance per unit value.                     | Set by models<br>(0.01~50.00%)    | READ                     |
| F02.17<br>(0x0211)          | Per-unit stator leakage inductance | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the stator leakage inductance per unit value.            | Set by models<br>(0.01~50.00%)    | READ                     |
| F02.18                      | Per-unit stator                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>   | Set by models                     | READ                     |

|          |            |   |              |  |
|----------|------------|---|--------------|--|
| (0x0212) | inductance | Set the stator inductance per unit value. | (0.1~999.0%) |  |
|----------|------------|---|--------------|--|

Table 4-10

## ◆ Group F02.2x: Advanced parameters of synchronous motors

| Parameter code<br>(Address) | Designation   | Content   | Default<br>(Setting range)          | Adjustable<br>properties |
|-----------------------------|---|---|-------------------------------------|--------------------------|
| F02.20<br>(0x0214)          | Synchronous motor<br>stator resistance              | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the stator resistance of the synchronous motor.  | Set by models<br>(0.01mΩ~60000mΩ)   | STOP                     |
| F02.21<br>(0x0215)          | Synchronous motor<br>D-axis inductance              | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the d-axis inductance of the synchronous motor.  | Set by models<br>(0.001mH~6553.5mH) | STOP                     |
| F02.22<br>(0x0216)          | Synchronous motor<br>Q-axis inductance              | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the q-axis inductance of the synchronous motor.  | Set by models<br>(0.001mH~6553.5mH) | STOP                     |
| F02.23<br>(0x0217)          | Synchronous motor<br>counter-electromotive<br>force | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the counter-electromotive force of the synchronous motor. It is only recognized during rotary self-tuning. | Set by models<br>(0~1500V)          | STOP                     |
| F02.24<br>(0x0218)          | Synchronous motor<br>encoder angle                  | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the encoder mounting angle of synchronous motor..  | Set by models<br>(0.0°~360.0°)      | RUN                      |
| F02.25<br>(0x0219)          | Synchronous motor<br>per-unit stator<br>resistance  | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the stator resistance per unit value of synchronous motor.   | Set by models<br>(Monitor value)    | READ                     |
| F02.26<br>(0x021A)          | Synchronous motor<br>per-unit d-axis<br>inductance  | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the per-unit d-axis inductance of synchronous motor.   | Set by models<br>(Monitor value)    | READ                     |
| F02.27<br>(0x021B)          | Synchronous motor<br>per-unit q-axis<br>inductance  | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Set the per-unit q-axis inductance of synchronous motor.   | Set by models<br>(Monitor value)    | READ                     |
| F02.28<br>(0x021C)          | Pulse width factor                                  | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>Sets the pulse width factor of the synchronous motor.  | Set by models<br>(00.00~99.99)      | STOP                     |

Table 4-11

## ◆ Group F02.3x-F02.4x: Encoder parameters

| Parameter code<br>(Address) | Designation                    | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--------------------------------|--|----------------------------|--------------------------|
| F02.30<br>(0x021E)          | Speed feedback<br>encoder type | V/F SVC FVC <b>PMVF</b> <b>PMSVC</b> <b>PMFVC</b><br>0: Standard ABZ encoder | 0<br>(0~4)                 | STOP                     |

|                    |   |   |                           |      |
|--------------------|---|---|---------------------------|------|
|                    |   | 4: Sine-cosine encoder  |                           |      |
| F02.31<br>(0x021F) | Encoder direction                             | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: Same direction 1: Opposite direction                                       | 0<br>(0~1)                | STOP |
| F02.32<br>(0x0220) | ABZ encoder<br>Z-pulse detection<br>selection | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: Off 1: On (positive pulse) 2: On (negative pulse)                          | 1<br>(0~1)                | STOP |
| F02.33<br>(0x0221) | ABZ encoder cable<br>No.                      | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the number of ABZ encoder cables.   | 2500<br>(1~10000)         | STOP |
| F02.35<br>(0x0223) | Encoder ratio<br>numerator                    | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder ratio numerator.  | 1<br>(1~32767)            | RUN  |
| F02.36<br>(0x0224) | Encoder ratio<br>denominator                  | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder ratio denominator.  | 1<br>(1~32767)            | RUN  |
| F02.37<br>(0x0225) | Encoder speed filter<br>time                  | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder speed filter time.  | 0.0ms<br>(0.0~ 100.0ms)   | RUN  |
| F02.38<br>(0x0226) | Encoder<br>disconnection<br>detection time    | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder disconnection detection time.                                 | 0.500s<br>(0.100~60.000s) | RUN  |
| F02.39<br>(0x0227) | Encoder crossover<br>output ratio             | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder crossover output ratio.                                       | 1<br>(1~32767)            | RUN  |
| F02.40<br>(0x0228) | Encoder installation<br>position              | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: Single encoder for motor;1: Single encoder for spindle;2:<br>Dual encoders | 0<br>(0~1)                | STOP |
| F02.41<br>(0x0229) | Positioning encoder<br>direction selection    | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: Same direction 1: Opposite direction                                       | 0<br>(0~1)                | STOP |
| F02.42<br>(0x022A) | Encoder Z-pulse<br>detection selection        | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: Off 1: On (positive pulse) 2: On (negative pulse)                          | 1<br>(0~2)                | STOP |
| F02.43<br>(0x022B) | Positioning encoder<br>cable No.              | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the number of ABZ encoder cables.   | 1024<br>(1~10000)         | STOP |
| F02.44<br>(0x022C) | Positioning encoder<br>speed filter time      | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the positioning encoder speed filter time.                                | 1.0ms<br>(0.0~ 100.0ms)   | RUN  |
| F02.45<br>(0x022D) | Crossover output<br>selection                 | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Ones-bit: Crossover output encoder selection                                  | 0x0010<br>(0x0000~0x1111) | STOP |

|                    |   |   |                           |     |
|--------------------|---|---|---------------------------|-----|
|                    |   | <p>0: Motor encoder 1: Spindle encoder</p> <p>Tens-bit: Crossover output direction</p> <p>0: Forward 1: Reverse</p>   |                           |     |
| F02.46<br>(0x022E) | Z-pulse<br>disconnection<br>detection turns | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the number of Z-pulse disconnection detection turns</p> <p>When dual encoder (F2.40=2), if the motor frequency &gt; 60Hz, E.PG11,Z pulse loss fault will not be reported. If this value is set to 5, the full frequency band will not block E.PG11.</p>   | 4<br>(1-32767)            | RUN |
| F02.47<br>(0x022F) | Z-pulse error<br>threshold                  | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the difference threshold value between the actual AB pulses and the set ones between the two Z pulses, if the threshold value is exceeded for certain times, report PG02 warning;</p> <p>0: Threshold value = F2.33 encoder cable number/32, report PG02 warning after the number of times reaches 7; (default)</p> <p>F2.33 encoder cable number/32: threshold value = set value, report PG02 warning after the number of times reaches 4 times;</p> <p>101: Block the PG02 and PG07 (second encoder) warning.</p> <p>Other non-zero numbers: threshold = set value, report PG02 after the number of times reaches 13;</p> | 0<br>(0-65535)            | RUN |
| F02.49<br>(0x0231) | PG speed detection<br>selection             | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones-bit: S speed detection stage in non-FVC mode</p> <p>0: Off</p> <p>1: On</p> <p>Thousands-bit: Filter of C00.29 PG feedback frequency</p> <p>0: On</p> <p>1: Off</p>  | 0x0000<br>(0x0000-0xFFFF) | RUN |

Table 4-12

## ◆ Group F02.5x-F02.60: Motor application parameters

| Parameter code<br>(Address) | Designation | Content | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|-------------|---------|----------------------------|--------------------------|
|-----------------------------|-------------|---------|----------------------------|--------------------------|

|                    |   |  |                               |      |
|--------------------|---|--|-------------------------------|------|
| F02.50<br>(0x0232) | Stator resistance<br>learning selection             | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Invalid<br>1: Learn only but no update<br>>1: Learn and update   | 0<br>(0-3)                    | STOP |
| F02.51<br>(0x0233) | Stator resistance<br>learning factor 1              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set stator resistance starting learning factor 1.   | 0<br>(0-1000)                 | RUN  |
| F02.52<br>(0x0234) | Stator resistance<br>learning factor 2              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set stator resistance starting learning factor 2.   | 0<br>(0-1000)                 | RUN  |
| F02.53<br>(0x0235) | Stator resistance<br>learning factor 3              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set stator resistance starting learning factor 3.   | 0<br>(0-1000)                 | RUN  |
| F02.60<br>(0x023C) | Magnetic polarity<br>search of<br>synchronous motor | <b>V/F SVC FVC PMVF PMSVC PMFV</b><br>Ones-bit: Closed-loop vector<br>0: Off<br>1: On<br>2: On, start at each power-on<br>Tens-bit: Open-loop vector<br>0: Off<br>1: On<br>2: On, start at each power-on | 0x0010<br>(0x0000-0x00<br>22) | STOP |

Table 4-13

## ◆ Group F02.6x-F02.7x: Sine and cosine encoder parameters

|                    |                                    |   |                   |      |
|--------------------|------------------------------------|---|-------------------|------|
| F02.68<br>(0x0245) | Sin-cos encoder<br>subdivision No. | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The number of subdivisions of a sine wave period for a sin-cos signal  | 10<br>(0-12)      | STOP |
| F02.69<br>(0x0246) | SIN signal bias<br>correction      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>SIN signal bias calibration acquired via self-learning, manual fine-tuning available.                          | 4096<br>(0-10000) | RUN  |
| F02.70<br>(0x0247) | COS signal bias<br>correction      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>COS signal bias calibration acquired via self-learning, manual fine-tuning available.                          | 4096<br>(0-10000) | RUN  |
| F02.71<br>(0x0248) | SIN COS amplitude<br>rectification | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Amplitude proportionality between SIN and COS signals obtained by self-learning, manual fine-tuning available. | 1024<br>(1-10000) | RUN  |

|                    |   |   |                   |      |
|--------------------|---|---|-------------------|------|
| F02.72<br>(0x0249) | SIN COS min.<br>threshold                 | V/F SVC FVC PMVF PMSVC PMFVC<br>The minimum threshold for the sum of squares of SIN COS signal, report the E.PG13 fault below the threshold | 2000<br>(1~10000) | RUN  |
| F02.73<br>(0x024A) | Sine/cosine crossover<br>output cable No. | V/F SVC FVC PMVF PMSVC PMFVC<br>The number of encoder cables for crossover output.  | 1024<br>(0~10000) | STOP |

Table 4-14

#### 4.6 Group F03: Vector Control

##### ◆ Group F03.0x: Speed loop

| Parameter code<br>(Address) | Designation                            | Content  | Default<br>(Setting range)        | Adjustable<br>properties |
|-----------------------------|--|--|-----------------------------------|--------------------------|
| F03.00<br>(0x0300)          | ASR speed rigidity<br>grade            | V/F SVC FVC PMVF PMSVC PMFVC<br>Rigidity level setting, the higher the level, the better the speed rigidity. | 32<br>(0~64)                      | RUN                      |
| F03.01<br>(0x0301)          | ASR speed rigidity<br>mode             | V/F SVC FVC PMVF PMSVC PMFVC<br>ASR speed rigidity mode.   | 0x0000<br>(0x0000~0xffff)         | RUN                      |
| F03.02<br>(0x0302)          | ASR (speed loop)<br>proportional gain1 | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR (speed loop) proportional gain 1.                                | 20.00<br>(0.01~100.00)            | RUN                      |
| F03.03<br>(0x0303)          | ASR (speed loop)<br>integral time 1    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR (speed loop) integral time 1.                                    | 0.100s<br>(0.000~6.000s)          | RUN                      |
| F03.04<br>(0x0304)          | ASR filter time1                       | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR filter time 1.   | 0.0ms<br>(0.0~100.0ms)            | RUN                      |
| F03.05<br>(0x0305)          | ASR switching<br>frequency1            | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR switching frequency 1.   | 10.00Hz<br>(0~ Max.<br>frequency) | RUN                      |
| F03.06<br>(0x0306)          | ASR (speed loop)<br>proportional gain2 | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR (speed loop) proportional gain 2.                                | 10.00<br>(0.01~100.00)            | RUN                      |
| F03.07<br>(0x0307)          | ASR (speed loop)<br>integral time 2    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR (speed loop) integral time 2.                                    | 0.050s<br>(0.000~6.000s)          | RUN                      |
| F03.08<br>(0x0308)          | ASR filter time 2                      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR filter time 2.   | 0.0ms<br>(0.0~100.0ms)            | RUN                      |
| F03.09<br>(0x0309)          | ASR switching<br>frequency 2           | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the ASR switching frequency 2.   | 5.00Hz<br>(0~最大频率)                | RUN                      |

Table 4-15

##### ◆ Group F03.1x: Current loop and torque limit

| Parameter code<br>(Address) | Designation  | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|---|----------------------------|--------------------------|
| F03.10<br>(0x030A)          | Current loop D-axis<br>proportional gain               | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the current loop D-axis proportional gain.              | 1.00<br>(0.001~4.000)      | RUN                      |
| F03.11<br>(0x030B)          | Current loop D-axis<br>integral gain                   | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the current loop D-axis integral gain.                  | 1.00<br>(0.001~4.000)      | RUN                      |
| F03.12<br>(0x030C)          | Current loop Q-axis<br>proportional gain               | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the current loop Q-axis proportional gain.              | 1.00<br>(0.001~4.000)      | RUN                      |
| F03.13<br>(0x030D)          | Current loop Q-axis<br>integral gain                   | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the current loop Q-axis integral gain.                  | 1.00<br>(0.001~4.000)      | RUN                      |
| F03.15<br>(0x030E)          | Torque limit of<br>electric state                      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the torque limit of the electric state.                 | 250.0%<br>(0.0~400.0%)     | RUN                      |
| F03.16<br>(0x030F)          | Torque limit of<br>power generation<br>state           | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the torque limit for power generation state.            | 350.0%<br>(0.0~400.0%)     | RUN                      |
| F03.17<br>(0x0312)          | Regenerative torque<br>limit value at low<br>speed     | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the regenerative torque limit value at low speed.       | 0.0%<br>(0.0~400.0%)       | RUN                      |
| F03.18<br>(0x0313)          | Torque limiting<br>frequency amplitude<br>at low speed | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the frequency amplitude limited by torque at low speed. | 6.00s<br>(0.00~30.00s)     | RUN                      |

Table 4-16

#### ◆ Group F03.2x: Torque optimization control

| Parameter code<br>(Address) | Designation  | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|--|----------------------------|--------------------------|
| F03.20<br>(0x0314)          | Low frequency<br>pull-in current for<br>synchronous motor  | V/F SVC FVC PMVF PMSVC PMFVC<br>When PM motor open loop control is effective, the higher the<br>pull-in current the higher the torque output.      | 20.0%<br>(0.0~50.0%)       | RUN                      |
| F03.21<br>(0x0315)          | High frequency<br>pull-in current for<br>synchronous motor | V/F SVC FVC PMVF PMSVC PMFVC<br>When the PM motor open-loop control is effective, the higher<br>the pull-in current, the higher the torque output. | 10.0%<br>(0.0~50.0%)       | RUN                      |
| F03.22<br>(0x0316)          | Pull-in current<br>frequency for                           | V/F SVC FVC PMVF PMSVC PMFVC<br>The set value is 100.0% of F01.10 [Maximum frequency].   | 10.0%<br>(0.0~100.0%)      | RUN                      |

|                    |  |   |                        |     |
|--------------------|--|---|------------------------|-----|
|                    | synchronous motor                                |   |                        |     |
| F03.23<br>(0x0317) | Differential compensation for asynchronous motor | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the differential compensation for asynchronous motor. | 100.0%<br>(0.0~250.0%) | RUN |
| F03.24<br>(0x0318) | Initial value of starting torque                 | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the initial value of starting torque.                 | 0.0%<br>(0.0~250.0%)   | RUN |

Table 4-17

## ◆ Group F03.3x: Flux optimization

| Parameter code<br>(Address) | Designation                                      | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|---|----------------------------|--------------------------|
| F03.30<br>(0x031E)          | Weak magnetic feedforward coefficient            | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the weak magnetic feedforward coefficient.        | 10.0%<br>(0.0~200.0%)      | RUN                      |
| F03.31<br>(0x031F)          | Weak magnetic control gain                       | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the weak magnetic control gain.                   | 100.0%<br>(0.0~500.0%)     | RUN                      |
| F03.32<br>(0x0320)          | Upper limit of weak magnetic current             | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the upper limit of weak magnetic current.         | 60.0%<br>(0.0~250.0%)      | STOP                     |
| F03.33<br>(0x0321)          | Weak magnetic voltage coefficient                | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the weak magnetic voltage coefficient.            | 97.0%<br>(0.0~120.0%)      | STOP                     |
| F03.34<br>(0x0322)          | Output power limit                               | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the output power limit.                           | 250.0%<br>(0.0~400.0%)     | RUN                      |
| F03.35<br>(0x0323)          | Overexcitation braking gain                      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the overexcitation braking gain.                  | 100.0%<br>(0.0~500.0%)     | RUN                      |
| F03.36<br>(0x0324)          | Over-excitation braking limit                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the overexcitation braking limit.                 | 100.0%<br>(0.0~250.0%)     | RUN                      |
| F03.37<br>(0x0325)          | Energy-saving running                            | V/F SVC FVC PMVF PMSVC PMFVC<br>0:Off; 1:On   | 0<br>(0~1)                 | RUN                      |
| F03.38<br>(0x0326)          | Lower excitation limit for energy-saving running | V/F SVC FVC PMVF PMSVC PMFVC<br>Set lower excitation limit for energy-saving running. | 50.0%<br>(0.0~80.0%)       | RUN                      |
| F03.39<br>(0x0327)          | Energy-saving running filter factor              | V/F SVC FVC PMVF PMSVC PMFVC<br>Set filter factor for energy-saving running.          | 0.010s<br>(0.000~6.000s)   | RUN                      |

Table 4-18



## ◆ Group F03.4x - F03.5x: Torque control

| Parameter code<br>(Address) | Designation                            | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|---|----------------------------|--------------------------|
| F03.40<br>(0x0328)          | Torque control<br>selection            | V/F SVC FVC PMVF PMSVC PMFVC<br>0: Speed control to limit the torque<br>1: Torque control to limit speed  | 0<br>(0~1)                 | RUN                      |
| F03.41<br>(0x0329)          | Torque command<br>giving               | V/F SVC FVC PMVF PMSVC PMFVC<br>Ones-bit: Channel A<br>Tens-bit: Channel B<br>0: Set via Keyboard number entering<br>1: Reserved<br>2: Set via current/voltage analog AI1<br>3: Set via current/voltage analog AI2<br>4: Reserved<br>5: PUL<br>6: Set via RS485 communication<br>Hundreds-bit: Method<br>0: A<br>1: B<br>2: A+B<br>3: A-B<br>4: MIN (A, B)<br>5: MAX (A, B) | 0x0000<br>(0x0000~0x0577)  | RUN                      |
| F03.42<br>(0x032A)          | Torque setting via<br>keyboard numbers | V/F SVC FVC PMVF PMSVC PMFVC<br>Set to give the torque command.   | 0.0%<br>(0.0~100.0%)       | RUN                      |
| F03.43<br>(0x032B)          | Torque input lower<br>limit value      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the lower limit of torque input.  | 0.00%<br>(0.0~100.00%)     | RUN                      |
| F03.44<br>(0x032C)          | Lower limit setting                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the corresponding value of the lower limit.   | 0.0%<br>(-200.0~200.0%)    | RUN                      |
| F03.45<br>(0x032D)          | Torque input upper<br>limit value      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the upper limit of torque input.  | 100.0%<br>(0.0~100.0%)     | RUN                      |
| F03.46<br>(0x032E)          | Upper limit setting                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the upper limit value.  | 100.0%<br>(-200.0~200.0%)  | RUN                      |

|                    |  |  |                          |     |
|--------------------|--|--|--------------------------|-----|
| F03.47<br>(0x032F) | Torque filter time   | V/F SVC FVC PMVF PMSVC PMFVC<br>Set frequency amplitude limited by torque at low speed.  | 0.100s<br>(0.000~6.000s) | RUN |
| F03.52<br>(0x0334) | Upper limit of<br>output torque                                | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the upper limit of output torque.  | 150.0%<br>(0.0~200.0%)   | RUN |
| F03.53<br>(0x0335) | Lower limit of<br>output torque                                | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the lower limit of output torque.  | 0.0%<br>(0.0~200.0%)     | RUN |
| F03.54<br>(0x0336) | Torque controlling<br>forward speed limit<br>selection         | V/F SVC FVC PMVF PMSVC PMFVC<br>0: Set via function code F03.56;<br>1: Reserved;<br>2: AI1×F03.56;<br>3: AI2×F03.56;<br>4: Reserved;<br>5: PUL×F03.56;<br>6: Given value via RS485 communication × F03.56;<br>7: Reserved; | 0<br>(0~7)               | RUN |
| F03.55<br>(0x0337) | Torque controlling<br>reverse speed limit<br>selection         | V/F SVC FVC PMVF PMSVC PMFVC<br>0: Set via function code F03.57;<br>1: Reserved;<br>2: AI1×F03.57;<br>3: AI2×F03.57;<br>4: Reserved;<br>5: PUL×F03.57;<br>6: Given value via RS485 communication×F03.57<br>7: Reserved;    | 0<br>(0~7)               | RUN |
| F03.56<br>(0x0338) | Torque controlling<br>max. speed limit for<br>forward rotation | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the maximum speed limit for torque controlling forward rotation.   | 100.0%<br>(0.0~100.0%)   | RUN |
| F03.57<br>(0x0339) | Torque controlling<br>max. speed limit for<br>reverse rotation | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the maximum speed limit for torque controlling reverse rotation.   | 100.0%<br>(0.0~100.0%)   | RUN |

Table 4-19

## ◆ Group F03.7x: Position compensation

| Parameter code | Designation | Content | Default | Adjustable |
|----------------|-------------|---------|---------|------------|
|----------------|-------------|---------|---------|------------|

| (Address)          |                                  |  | (Setting range)       | properties |
|--------------------|----------------------------------|--|-----------------------|------------|
| F03.70<br>(0x0346) | Position<br>compensation control | V/F SVC FVC PMVF PMSVC PMFVC<br>Position-compensated control under speed control, which can achieve zero servo or improve system rigidity. | 0<br>(0~5)            | RUN        |
| F03.71<br>(0x0347) | Compensation gain                | V/F SVC FVC PMVF PMSVC PMFVC<br>Set compensation gain.   | 1.0%<br>(0.0~250.0%)  | RUN        |
| F03.72<br>(0x0348) | Compensation limit               | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the compensation limit value.  | 0.0%<br>(0.0~100.0%)  | STOP       |
| F03.73<br>(0x0349) | Compensation range               | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the valid compensation range.  | 10.0%<br>(0.0~100.0%) | STOP       |

Table 4-20

#### ◆ Group F03.8x: Extension control

| Parameter code<br>(Address) | Designation                              | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|--|----------------------------|--------------------------|
| F03.80<br>(0x0350)          | MTPA gain of<br>synchronous motor        | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the MTPA gain of the synchronous motor.        | 100.0%<br>(0.0~400.0%)     | RUN                      |
| F03.81<br>(0x0351)          | MTPA filter time of<br>synchronous motor | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the filter time of the synchronous motor MTPA. | 1.0ms<br>(0.0~100.0ms)     | RUN                      |

Table 4-21

## 4.7 Group F05: Input Terminal

### ◆ Group F05.0x: Digital input terminal function

| Parameter code<br>(Address) | Designation                       | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|-----------------------------------|---|----------------------------|--------------------------|
| F05.00<br>(0x0500)          | Terminal X1 function<br>selection | V/F SVC FVC PMVF PMSVC PMFVC<br>See the function of terminal X for details. | 1<br>(0~85)                | STOP                     |
| F05.01<br>(0x0501)          | Terminal X2 function<br>selection | V/F SVC FVC PMVF PMSVC PMFVC<br>See the function of terminal X for details. | 2<br>(0~85)                | STOP                     |
| F05.02<br>(0x0502)          | Terminal X3 function<br>selection | V/F SVC FVC PMVF PMSVC PMFVC<br>See the function of terminal X for details. | 80<br>(0~85)               | STOP                     |
| F05.03<br>(0x0503)          | Terminal X4 function<br>selection | V/F SVC FVC PMVF PMSVC PMFVC<br>See the function of terminal X for details. | 61<br>(0~85)               | STOP                     |
| F05.04<br>(0x0504)          | Terminal X5 function<br>selection | V/F SVC FVC PMVF PMSVC PMFVC<br>See the function of terminal X for details. | 64<br>(0~85)               | STOP                     |
| F05.05                      | Terminal X6 function              | V/F SVC FVC PMVF PMSVC PMFVC  | 8                          | STOP                     |

|                    |                                   |  |             |      |
|--------------------|-----------------------------------|--|-------------|------|
| (0x0505)           | selection                         | See the function of terminal X for details.  | (0~85)      |      |
| F05.06<br>(0x0506) | Terminal X7 function<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See the function of terminal X for details. | 7<br>(0~85) | STOP |

Table 4-22

## ◆ Group F05.1x: Curve X1-X5 detection delay

| Parameter code<br>(Address) | Designation                      | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|----------------------------------|--|----------------------------|--------------------------|
| F05.10<br>(0x050A)          | X1 validity detection<br>delay   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X1 from the invalid state to the valid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.11<br>(0x050B)          | X1 invalidity<br>detection delay | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X1 from the valid state to the invalid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.12<br>(0x050C)          | X2 validity detection<br>delay   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X2 from the invalid state to the valid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.13<br>(0x050D)          | X2 invalidity<br>detection delay | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X2 from the valid state to the invalid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.14<br>(0x050E)          | X3 validity detection<br>delay   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X3 from the invalid state to the valid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.15<br>(0x050F)          | X3 invalidity<br>detection delay | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X3 from the valid state to the invalid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.16<br>(0x0510)          | X4 validity detection<br>delay   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X4 from the invalid state to the valid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.17<br>(0x0511)          | X4 invalidity<br>detection delay | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output terminal X4 from the valid state to the invalid state. | 0.010<br>(0.000~6.000s)    | RUN                      |
| F05.18<br>(0x0512)          | X5 validity detection<br>delay   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output  | 0.010<br>(0.000~6.000s)    | RUN                      |

|                    |                                  |   |                         |     |
|--------------------|----------------------------------|---|-------------------------|-----|
|                    |                                  | terminal X5 from the invalid state to the valid state.  |                         |     |
| F05.19<br>(0x0513) | X5 invalidity<br>detection delay | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The delay time corresponding to the transition of output<br>terminal X5 from the valid state to the invalid state. | 0.010<br>(0.000~6.000s) | RUN |

Table 4-23

## ◆ Group F05.2x: Digital input terminal function selection

| Parameter code<br>(Address) | Designation  | Content  | Default<br>(Setting range)   | Adjustable<br>properties |
|-----------------------------|--|--|------------------------------|--------------------------|
| F05.20<br>(0x0514)          | Terminal control<br>running mode                                     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: two-wire mode 1; 1: two-wire mode 2<br>2: three-wire mode 1; 3: three-wire mode 2<br>Note: see Appendix II for the terminal wiring methods.        | 0<br>(0~3)                   | STOP                     |
| F05.22<br>(0x0516)          | X1~X4 terminal<br>characteristics<br>selection                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: valid when closed; 1: valid when open<br>Ones-bit: X1 terminal<br>Tens-bit: X2 terminal<br>Hundreds-bit: X3 terminal<br>Thousands-bit: X4 terminal | 0000<br>(0000~1111)          | RUN                      |
| F05.23<br>(0x0517)          | X5~X7 terminal<br>characteristics<br>selection                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: valid when closed; 1: valid when open<br>Ones-bit: X5 terminal<br>Tens-bit: X6 terminal<br>Hundreds-bit: X7 terminal                               | 0000<br>(0000~0111)          | RUN                      |
| F05.25<br>(0x0519)          | Terminal UP/DW<br>control selection                                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: power-down frequency storage<br>1: no power-down frequency storage<br>2: frequency adjustable during running, records all cleared at<br>stop       | 0<br>(0~2)                   | STOP                     |
| F05.26<br>(0x051A)          | Terminal UP/DW<br>for the increase<br>/decrease rate of<br>frequency | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set terminal UP/DW to control the increase or decrease rate<br>of frequency.  | 0.50Hz/s<br>(0.01~50.00Hz/s) | RUN                      |
| F05.27                      | Terminal controlling   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>  | 1.00s                        | RUN                      |

|          |                                     |  |                |  |
|----------|-------------------------------------|--|----------------|--|
| (0x051B) | deceleration time of emergency stop | Set the terminal to control deceleration time of emergency stop. | (0.01~650.00s) |  |
|----------|-------------------------------------|--|----------------|--|

Table 4-24

## ◆ F05.3x group: PUL terminal

| Parameter code<br>(Address) | Designation                         | Content  | Default<br>(Setting range)   | Adjustable<br>properties |
|-----------------------------|-------------------------------------|--|------------------------------|--------------------------|
| F05.31<br>(0x051F)          | PUL input min.<br>frequency         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The minimum frequency accepted by PUL, frequency signals below will be processed by the spindle drive as the minimum frequency.<br>0.00~50.000kHz | 0.00kHz<br>(0.00~500.00kHz)  | RUN                      |
| F05.32<br>(0x0520)          | PUL input min.<br>frequency percent | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Percentage of the set PUL input min. frequency.   | 0.00%<br>(0.00~100.00%)      | RUN                      |
| F05.33<br>(0x0521)          | PUL input max.<br>frequency         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The maximum frequency accepted by PUL, frequency signals above will be processed by the spindle drive as the maximum frequency.<br>0.00~50.000kHz | 50.00kHz<br>(0.00~500.00kHz) | RUN                      |
| F05.34<br>(0x0522)          | PUL input max.<br>frequency percent | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Percentage of the set PUL input max. frequency  | 100.00%<br>(0.00~100.00%)    | RUN                      |
| F05.35<br>(0x0523)          | PUL filter time                     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the filter for the input pulse signal to eliminate interfering signals.   | 0.100s<br>(0.000~9.000s)     | RUN                      |
| F05.36<br>(0x0524)          | PUL cut-off<br>frequency            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Frequencies lower than this parameter are no longer recognized by the spindle drive. It is processed as 0Hz.                                      | 0.010kHz<br>(0.000~1.000kHz) | RUN                      |

Table 4-25

## ◆ Group F05.4x: Analog AI processing

| Parameter code<br>(Address) | Designation                     | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---------------------------------|--|----------------------------|--------------------------|
| F05.42<br>(0x052A)          | AI2 input signal type           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: voltage 0~10.00V; 1: current 0~20.00mA | 0<br>(0~1)                 | RUN                      |
| F05.43<br>(0x052B)          | Analog input curve<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Straight cable(default)                | 0x0000<br>(0x0000~0x0022)  | RUN                      |

|  |  |  |  |  |
|--|--|--|--|--|
|  |  | 1: Curve 1<br>2: Curve2<br>Ones-bit: AI1<br>Tens-bit: AI2<br>Hundreds-bit: Reserved<br>Thousands-bit: Reserved |  |  |
|--|--|--|--|--|

Table 4-26

## ◆ Group F05.5x: Analog AI liner processing

| Parameter code<br>(Address) | Designation                | Content  | Default<br>(Setting range)   | Adjustable<br>properties |
|-----------------------------|----------------------------|--|------------------------------|--------------------------|
| F05.50<br>(0x0532)          | AI1 lower limit            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Define the signal received at the AI1 terminal, and voltage signals below this value are processed as the lower limit.    | -100.0%<br>(-100.0~100.0%)   | RUN                      |
| F05.51<br>(0x0533)          | Percent of AI1 lower limit | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the percent of AI1 lower limit value.   | -100.0%<br>(-100.0~100.0%)   | RUN                      |
| F05.52<br>(0x0534)          | AI1 upper limit            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Define the signal received by the AI1 terminal, and voltage signals above this value are processed as the upper limit.    | 100.0%<br>(-100.0~100.0%)    | RUN                      |
| F05.53<br>(0x0535)          | Percent of AI1 upper limit | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the percent of AI1 upper limit value.   | 100.00%<br>(0.00~100.00%)    | RUN                      |
| F05.54<br>(0x0536)          | AI1 filter time            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the filter for the analog signal to eliminate interfering signals.  | 0.010s<br>(0.000~6.000s)     | RUN                      |
| F05.55<br>(0x0537)          | AI2 lower limit            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Define the signal received by the AI2 terminal, and any voltage signal below this value is processed as the lower limit.  | 0.0%<br>(0.0~100.0%)         | RUN                      |
| F05.56<br>(0x0538)          | Percent of AI2 lower limit | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the percent of AI2 lower limit.   | 0.00%<br>(-100.00~100.00%)   | RUN                      |
| F05.57<br>(0x0539)          | AI2 upper limit            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Define the signal received by the AI2 terminal, and voltage signals above this value are processed as upper limit values. | 100.0%<br>(0.0~100.0%)       | RUN                      |
| F05.58<br>(0x053A)          | Percent of AI2 upper limit | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the percent of AI2 upper limit.   | 100.00%<br>(-100.00~100.00%) | RUN                      |

|                    |                    |   |                          |     |
|--------------------|--------------------|---|--------------------------|-----|
| F05.59<br>(0x053B) | AI2 filtering time | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the filter for the analog signal to eliminate interfering signals. | 0.010s<br>(0.000~6.000s) | RUN |
|--------------------|--------------------|---|--------------------------|-----|

Table 4-27

## ◆ Group F05.6x:AI curve 1 processing

| Parameter code<br>(Address) | Designation   | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---|---|----------------------------|--------------------------|
| F05.60<br>(0x053C)          | Curve 1 lower limit                                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the lower limit of curve 1.                              | 0.0%<br>(0.0~100.0%)       | RUN                      |
| F05.61<br>(0x053D)          | Percent of curve 1<br>lower limit                         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set percent of curve 1 lower limit.                          | 0.0%<br>(0.0~100.0%)       | RUN                      |
| F05.62<br>(0x053E)          | Curve 1 inflection<br>point 1 input voltage               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set curve 1 inflection point 1 input voltage.                | 30.0%<br>(0.0~100.0%)      | RUN                      |
| F05.63<br>(0x053F)          | Percent of curve 1<br>inflection point 1<br>input voltage | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set percent of curve 1 inflection point 1 input voltage.     | 30.00%<br>(0.0~100.0%)     | RUN                      |
| F05.64<br>(0x0540)          | Curve 1 inflection<br>point 2 input voltage               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set curve 1 inflection point 2 input voltage.                | 60.0%<br>(0.0~100.0%)      | RUN                      |
| F05.65<br>(0x0541)          | Percent of curve 1<br>inflection point 2<br>input voltage | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the percent of curve 1 inflection point 2 input voltage. | 70.00%<br>(0.0~100.0%)     | RUN                      |
| F05.66<br>(0x0542)          | Curve 1 upper limit                                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the upper limit of curve 1.                              | 100.00%<br>(0.0~100.0%)    | RUN                      |
| F05.67<br>(0x0543)          | Percent of curve 1<br>upper limit                         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Percent of curve 1 upper limit                               | 100.0%<br>(0.0~100.0%)     | RUN                      |

Table 4-28

## ◆ Group F05.7x:AI curve 2 processing

| Parameter code<br>(Address) | Designation                       | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|-----------------------------------|--|----------------------------|--------------------------|
| F05.70<br>(0x0546)          | Curve 2 lower limit               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the lower limit value of curve 2. | 0.0%<br>(0.0~100.0%)       | RUN                      |
| F05.71<br>(0x0547)          | Percent of curve 2<br>lower limit | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set percent of curve 2 lower limit.   | 0.0%<br>(0.0~100.0%)       | RUN                      |



|                    |   |   |                          |     |
|--------------------|---|---|--------------------------|-----|
| F05.72<br>(0x0548) | Curve 2 inflection point 1 input voltage            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set curve 2 inflection point 1 input voltage.            | 30.0%<br>(0.0~100.0%)    | RUN |
| F05.73<br>(0x0549) | Percent of curve 2 inflection point 1 input voltage | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set percent of curve 2 inflection point 1 input voltage. | 30.00%<br>(0.00~100.00%) | RUN |
| F05.74<br>(0x054A) | Curve 2 inflection point 2 input voltage            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set curve 2 inflection point 2 input voltage.            | 60.0%<br>(0.0~100.0%)    | RUN |
| F05.75<br>(0x054B) | Percent of curve 2 inflection point 2 input voltage | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set percent of curve 2 inflection point 2 input voltage. | 70.00%<br>(0.0~100.0%)   | RUN |
| F05.76<br>(0x054C) | Curve 2 upper limit                                 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set curve 2 upper limit.                                 | 100.00%<br>(0.0~100.0%)  | RUN |
| F05.77<br>(0x054D) | Percent of curve 2 upper limit                      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set percent of curve 2 upper limit                       | 100.0%<br>(0.0~100.0%)   | RUN |

Table 4-29

#### ◆ Group F05.8x:AI as digital input terminal

| Parameter code<br>(Address) | Designation  | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|--|----------------------------|--------------------------|
| F05.80<br>(0x0550)          | AI as digital input terminal characteristics selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Valid at low level<br>1: Valid at high level<br>Ones-bit:AI1<br>Tens-bit:AI2 | 0000<br>(0000~1111)        | RUN                      |
| F05.81<br>(0x0551)          | AI terminal function selection (as X terminal)         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See X terminal functions.   | 0<br>(0~63)                | STOP                     |
| F05.82<br>(0x0552)          | AI high level setting                                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>An input higher than the set value here is a high-level input.                  | 70.00%<br>(0.0~100.0%)     | RUN                      |
| F05.83<br>(0x0553)          | AI low level setting                                   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>An input lower than the set value here is a low-level input.                    | 30.00%<br>(0.0~100.0%)     | RUN                      |

Table 4-30

### 4.8 Group F06: Output Terminal

#### ◆ Group F06.0x:AO analog output

| Parameter code<br>(Address) | Designation                   | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|-------------------------------|--|----------------------------|--------------------------|
| F06.00<br>(0x0600)          | AO output method<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0:0~10V<br>1:4.00~20.00mA      2:0.00~20.00mA   | 0<br>(0~2)                 | RUN                      |
| F06.01<br>(0x0601)          | AO output volume<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Given frequency<br>1: Output frequency<br>2: Output current<br>3: Input voltage<br>4: Output voltage<br>5: Mechanical speed<br>6: Given torque<br>7: Output torque<br>8: Given PID<br>9: PID feedback<br>10: Output power<br>11: Bus voltage<br>12: AI1 input value<br>13: AI2 input value<br>14: Reserved<br>15: PUL input value<br>16: Module temperature1<br>17: Module temperature2<br>18: 485 communication given<br>19: Virtual vY1 features | 0<br>(0~19)                | RUN                      |
| F06.02<br>(0x0602)          | AO output gain                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Adjust the value of the terminal output analog.   | 100.0%<br>(0.0~200.0%)     | RUN                      |
| F06.03<br>(0x0603)          | AO output bias                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the A0 output bias for adjusting the zero point of the terminal output.   | 0.0%<br>(-10.0~10.0%)      | RUN                      |
| F06.04<br>(0x0604)          | AO output filter              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the filter for analog signals to eliminate interfering signals.   | 0.01s<br>(0.0~6.00s)       | RUN                      |

Table 4-31

## ◆ Group F06.2x-F06.3x: Digital, relay outputs

| Parameter code<br>(Address) | Designation                           | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---------------------------------------|---|----------------------------|--------------------------|
| F06.20<br>(0x0614)          | Output terminal<br>polarity selection | V/F SVC FVC PMVF PMSVC PMFVC<br>0:Positive; 1:Negative<br>Ones-bit: Y terminal<br>Tens-bit: Relay output terminal 1 | 0000<br>(0000~1111)        | RUN                      |
| F06.21<br>(0x0615)          | Output terminal Y1                    | V/F SVC FVC PMVF PMSVC PMFVC<br>See terminal Y functions.   | 42<br>(0~43)               | RUN                      |
| F06.22<br>(0x0616)          | Relay 1 output<br>(TA-TB-TC)          | V/F SVC FVC PMVF PMSVC PMFVC<br>See terminal Y functions.   | 41<br>(0~43)               | RUN                      |
| F06.23<br>(0x0617)          | Output terminal Y2                    | V/F SVC FVC PMVF PMSVC PMFVC<br>See terminal Y functions.   | 8<br>(0~43)                | RUN                      |
| F06.24<br>(0x0618)          | Relay 2 output<br>(TA-TB-TC)          | V/F SVC FVC PMVF PMSVC PMFVC<br>See terminal Y functions.   | 4<br>(0~43)                | RUN                      |
| F06.25<br>(0x0619)          | Y1 output ON delay<br>time            | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the Y1 output ON delay time.  | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.26<br>(0x061A)          | Relay 1 output ON<br>delay time       | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the relay 1 output ON delay time.   | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.27<br>(0x061B)          | Y2 output ON delay<br>time            | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the Y2 output ON delay time.  | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.28<br>(0x061C)          | Relay 2 output ON<br>delay time       | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the relay 2 output ON delay time.   | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.29<br>(0x061D)          | Y1 output OFF delay<br>time           | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the Y2 output OFF delay time.   | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.30<br>(0x061E)          | Relay 1 output OFF<br>delay time      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the relay 1 output OFF delay time.  | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.31<br>(0x061F)          | Y2 output OFF delay<br>time           | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the Y2 output OFF delay time.   | 0.010s<br>(0.000~60.000s)  | RUN                      |
| F06.32<br>(0x0620)          | Relay 2 output OFF<br>delay time      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the relay 2 output OFF delay time.  | 0.010s<br>(0.000~60.000s)  | RUN                      |

Table 4-32

## ◆ Group F06.4x: Frequency detection

| Parameter code<br>(Address) | Designation                                  | Content   | Default<br>(Setting range)          | Adjustable<br>properties |
|-----------------------------|--|---|-------------------------------------|--------------------------|
| F06.40<br>(0x0628)          | Frequency detection<br>value1                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the frequency detection value 1.               | 2.00Hz<br>(0.00~ Max.<br>frequency) | RUN                      |
| F06.41<br>(0x0629)          | Frequency detection<br>amplitude 1           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the frequency detection amplitude 1.           | 1.00Hz<br>(0.00~ Max.<br>frequency) | RUN                      |
| F06.42<br>(0x062A)          | Frequency detection<br>value 2               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the frequency detection value 2.               | 2.00Hz<br>(0.00~ Max.<br>frequency) | RUN                      |
| F06.43<br>(0x062B)          | Frequency detection<br>amplitude 2           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the frequency detection amplitude 2.           | 1.00Hz<br>(0.00~ Max.<br>frequency) | RUN                      |
| F06.44<br>(0x062C)          | Detection amplitude<br>for a given frequency | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the detection amplitude for a given frequency. | 2.00Hz<br>(0.00~ Max.<br>frequency) | RUN                      |

Table 4-33

◆ Group F06.5x: Comparator output of monitoring parameters

| Parameter code<br>(Address) | Designation                          | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--------------------------------------|--|----------------------------|--------------------------|
| F06.50<br>(0x0632)          | Comparator 1<br>monitoring selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-and tens- bit: set value 00-63 for yy in the monitoring<br>parameter number Cxx.yy.<br>Hundreds- and thousands-bit: Set value 00-07 for xx in<br>monitoring parameter number Cxx.yy. | 0001<br>(0000-0763)        | RUN                      |
| F06.51<br>(0x0633)          | Comparator 1 upper<br>limit          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the comparator 1 upper limit.   | 3000<br>(0-65535)          | RUN                      |
| F06.52<br>(0x0634)          | Comparator 1 lower<br>limit          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the comparator 1 lower limit.   | 0<br>(0-65535)             | RUN                      |
| F06.53<br>(0x0635)          | Comparator 1 bias                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the comparator 1 bias value.  | 0<br>(0-1000)              | RUN                      |
| F06.54                      | Action selection                     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>  | 0                          | RUN                      |

|                    |                                      |  |                     |     |
|--------------------|--------------------------------------|--|---------------------|-----|
| (0x0636)           | when sending CP1                     | 0: Continue running (digital terminal output only)<br>1: Report a warning and free stop<br>2: Report a warning and continue running<br>3: Forced stop  | (0~3)               |     |
| F06.55<br>(0x0637) | Comparator 2<br>monitoring selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-and tens- bit: set value 00~63 for yy in the monitoring parameter number Cxx.yy.<br>Hundreds- and thousands-bit: Set value 00~07 for xx in monitoring parameter number Cxx.yy. | 0002<br>(0000~0763) | RUN |
| F06.56<br>(0x0638) | Comparator 2 upper<br>limit          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the comparator 2 upper limit value.   | 30<br>(0~65535)     | RUN |
| F06.57<br>(0x0639) | Comparator 2 lower<br>limit          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the comparator 2 lower limit value.   | 0<br>(0~65535)      | RUN |
| F06.58<br>(0x063A) | Comparator 2 bias                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the comparator 2 bias value.  | 0<br>(0~1000)       | RUN |
| F06.59<br>(0x063B) | Action selection<br>when sending CP2 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Continue running (digital terminal output only)<br>1: Report a warning and free stop<br>2: Report a warning and continue running<br>3: Forced stop                               | 0<br>(0~3)          | RUN |

Table 4-25

◆ Group F06.6x: Virtual input/output terminals

| Parameter code<br>(Address) | Designation                                | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|--|----------------------------|--------------------------|
| F06.60<br>(0x063C)          | Virtual vX1 terminal<br>function selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See terminal X functions. | 0<br>(0~63)                | RUN                      |
| F06.61<br>(0x063D)<br>RUN   | Virtual vX2 terminal<br>function selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See terminal X functions. | 0<br>(0~63)                | RUN                      |
| F06.62<br>(0x063E)          | Virtual vX3 terminal<br>function selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See terminal X functions. | 0<br>(0~63)                | RUN                      |
| F06.63<br>(0x063F)          | Virtual vX4 terminal<br>function selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See terminal X functions. | 0<br>(0~63)                | RUN                      |

|                    |   |  |                           |     |
|--------------------|---|--|---------------------------|-----|
| F06.64<br>(0x0640) | vX terminal valid status source                           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Internal link with virtual vYn<br>1: Link with physical terminal Xn<br>2: Set via the function code<br>Ones-bit: Virtual vX1<br>Tens-bit: Virtual vX2<br>Hundreds-bit: Virtual vX3<br>Thousands-bit: Virtual vX4 | 0000<br>(0000~2222)       | RUN |
| F06.65<br>(0x0641) | Set virtual vX terminal to valid status via function code | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: invalid; 1: valid<br>Ones-bit: VirtualvX1<br>Tens-bit: VirtualvX2<br>Hundreds-bit: Virtual vX3<br>Thousands-bit: Virtual vX4   | 0000<br>(0000~1111)       | RUN |
| F06.66<br>(0x0642) | Virtual vY1 output selection                              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See Y terminal functions.   | 0<br>(0~31)               | RUN |
| F06.67<br>(0x0643) | Virtual vY2 output selection                              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See Y terminal functions.   | 0<br>(0~31)               | RUN |
| F06.68<br>(0x0644) | Virtual vY3 output selection                              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See Y terminal functions.   | 0<br>(0~31)               | RUN |
| F06.69<br>(0x0645) | Virtual vY4 output selection                              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>See Y terminal functions.   | 0<br>(0~31)               | RUN |
| F06.70<br>(0x0646) | vY1 output ON delay time                                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY1 output ON delay time.   | 0.010s<br>(0.000~60.000s) | RUN |
| F06.71<br>(0x0647) | vY2 output ON delay time                                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY2 output ON delay time.   | 0.010s<br>(0.000~60.000s) | RUN |
| F06.72<br>(0x0648) | vY3 output ON delay time                                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY3 output ON delay time.   | 0.010s<br>(0.000~60.000s) | RUN |
| F06.73<br>(0x0649) | vY4 output ON delay time                                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY4 output ON delay time.   | 0.010s<br>(0.000~60.000s) | RUN |
| F06.74<br>(0x064A) | vY1 output OFF delay time                                 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY1 output OFF delay time.  | 0.010s<br>(0.000~60.000s) | RUN |
| F06.75             | vY2 output OFF delay                                      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>  | 0.010s                    | RUN |

|                    |                              |   |                           |     |
|--------------------|------------------------------|---|---------------------------|-----|
| (0x064B)           | time                         | Set vY2 output OFF delay time.  | (0.000~60.000s)           |     |
| F06.76<br>(0x064C) | vY3 output OFF delay<br>time | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY3 output OFF delay time. | 0.010s<br>(0.000~60.000s) | RUN |
| F06.77<br>(0x064D) | vY4 output OFF delay<br>time | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set vY4 output OFF delay time. | 0.010s<br>(0.000~60.000s) | RUN |

Table 4-26

## 4.9 Group F07: Running Control

### ◆ Group F07.0x: Starting control

| Parameter code<br>(Address) | Designation                      | Content   | Default<br>(Setting range)                                       | Adjustable<br>properties |
|-----------------------------|----------------------------------|---|--|--------------------------|
| F07.00<br>(0x0700)          | Starting running<br>mode         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Start from the starting frequency<br>1: DC braking first and then start from starting frequency<br>2: Start after speed tracking and direction judgment   | 0<br>(0~2)   | STOP                     |
| F07.01<br>(0x0701)          | Starting<br>pre-excitation time  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Only under vector control (without PG) on asynchronous<br>motors   | 0.00s<br>(0.00~60.00s)   | STOP                     |
| F07.02<br>(0x0702)          | Starting frequency               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>When the given frequency is lower than this value, it does<br>not start and is in standby mode.  | 0.50Hz<br>(0.00~ Upper limit<br>frequency via<br>number setting) | STOP                     |
| F07.03<br>(0x0703)          | Starting protection<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: off; 1: on<br><br>Ones-bit: Terminal starting protection on in case of<br>abnormal exit<br><br>Tens-bit: Jogging terminal starting protection on in case of<br>abnormal exit<br><br>Hundreds-bit: Terminal starting protection on when<br>command channel is switched to terminal<br><br>Thousands-bit: Reserved<br><br>Note: When the free stop, emergency stop and forced stop<br>commands are valid, the terminal starting protection is<br>turned on by default, and the A.RUNx warning is reported | 0111<br>(0000~1111)  | STOP                     |

|                    |   |   |                        |      |
|--------------------|---|---|------------------------|------|
|                    |   | during protection.  |                        |      |
| F07.05<br>(0x0705) | Rotary direction selection                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: Running direction reversed or not<br>0: direction unchanged; 1: direction reversed<br>Tens-bit: Running direction prohibited or not<br>0: allow forward and reverse commands;<br>1: allow only forward commands;<br>2: allow only reverse commands;<br>Hundreds-bit: Frequency control command direction or not<br>0: frequency control is invalid; 1: frequency control is valid<br>Thousands-bit: Reserved | 0100<br>(0000~1111)    | STOP |
| F07.06<br>(0x0706) | Restart action after power down selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: invalid; 1: valid.  | 0<br>(0~1)             | STOP |
| F07.07<br>(0x0707) | Restart waiting time after power down     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set restart waiting time after power failure.  | 0.50s<br>(0.00~60.00s) | STOP |

Table 4-27

## ◆ Group F07.1x: Stop control

| Parameter code<br>(Address) | Designation                                  | Content  | Default<br>(Setting range)                                 | Adjustable<br>properties |
|-----------------------------|--|--|--|--------------------------|
| F07.10<br>(0x070A)          | Stop mode                                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: deceleration stop; 1: free stop  | 0<br>(0~1)   | RUN                      |
| F07.11<br>(0x070B)          | Stop detection frequency                     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>When the output frequency of the spindle drive is lower than this value, it enters the stop state when the speed is reduced.    | 0.50Hz<br>(0.00~ Upper limit frequency via number setting) | RUN                      |
| F07.12<br>(0x070C)          | Stop-and-start limit time                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Waiting time to start again after a shutdown.   | 0.00s<br>(0.00~60.00s)                                     | STOP                     |
| F07.15<br>(0x070F)          | Action selection below lower limit frequency | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: Run according to frequency command<br>1: Free stop and pause<br>2: Run at the lower frequency limit<br>3: Zero-speed running | 0<br>(0~3)   | RUN                      |
| F07.16                      | Zero-speed torque                            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>  | 60.0%  | RUN                      |



|                    |                                |  |                      |      |
|--------------------|--------------------------------|--|----------------------|------|
| (0x0710)           | holding factor                 | Set zero-speed torque current, 100.0% corresponds to spindle drive's rated current.                | (0.0~150.0%)         |      |
| F07.17<br>(0x0711) | Zero-speed torque holding time | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set zero-speed torque holding time.                         | 0s<br>(0.0~6000.0s)  | RUN  |
| F07.18<br>(0x0712) | Forward/reverse dead time      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Zero frequency holding time at forward / reverse switching. | 0.0s<br>(0.0~120.0s) | STOP |

Table 4-28

## ◆ Group F07.2x: DC braking and speed tracking

| Parameter code<br>(Address) | Designation                     | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---------------------------------|---|----------------------------|--------------------------|
| F07.20<br>(0x0714)          | Pre-start braking current       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set pre-start braking current.   | 60.0%<br>(0.0~150.0%)      | STOP                     |
| F07.21<br>(0x0715)          | Pre-start braking time          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set pre-start braking time.  | 0.0s<br>(0.0~60.0s)        | STOP                     |
| F07.22<br>(0x0716)          | DC braking starting frequency   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set DC braking starting frequency.   | 1.00Hz<br>(0.00~50.00Hz)   | STOP                     |
| F07.23<br>(0x0717)          | DC braking current              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Base on spindle drive's rated current, internally limited to motor rated current.  | 60.0%<br>(0.0~150.0%)      | STOP                     |
| F07.24<br>(0x0718)          | DC braking time during shutdown | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set DC braking time during shutdown.   | 0.0s<br>(0.0~60.0s)        | STOP                     |
| F07.25<br>(0x0719)          | Speed tracking mode             | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: Search method<br>0: search from the maximum frequency;<br>1: search from the stop frequency<br>Tens-bit: Reverse the search<br>0: off; 1: on<br>Hundreds-bit: Search source<br>0: software search; 1: hardware search<br>Thousands-bit: Reserved | 00<br>(00~11)              | STOP                     |
| F07.26<br>(0x071A)          | Rotational speed tracking speed | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the speed of RPM tracking.   | 0.5s<br>(0.0~60.0s)        | STOP                     |
| F07.27                      | Stop delay due to               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>   | 1.00s                      | STOP                     |

|                    |                           |  |                        |      |
|--------------------|---------------------------|--|------------------------|------|
| (0x071B)           | speed tracking            | Set stop time delay of speed tracking.                             | (0.0~60.0s)            |      |
| F07.28<br>(0x071C) | Speed tracking<br>current | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set speed tracking current. | 120.0%<br>(0.0~400.0%) | STOP |

Table 4-29

## ◆ Group F07.3x: Jogging

| Parameter code<br>(Address) | Designation                    | Content  | Default<br>(Setting range)          | Adjustable<br>properties |
|-----------------------------|--------------------------------|--|-------------------------------------|--------------------------|
| F07.30<br>(0x071E)          | Jogging frequency<br>setting   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set jogging running frequency.  | 5.00Hz<br>(0.00~ Max.<br>frequency) | RUN                      |
| F07.31<br>(0x071F)          | Jogging acceleration<br>time   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set jogging acceleration time.  | 10.0s<br>(0.0~650.0s)               | RUN                      |
| F07.32<br>(0x0720)          | Jogging deceleration<br>time   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set jogging deceleration time.  | 10.0s<br>(0.0~650.0s)               | RUN                      |
| F07.33<br>(0x0721)          | Jogging S-curve<br>selection   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set jogging S-curve selection.<br>0: invalid; 1: valid                        | 0<br>(0~1)                          | RUN                      |
| F07.34<br>(0x0722)          | Jogging stop mode<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the jogging stop mode<br>0: set mode via F7.10; 1: deceleration stop only | 0<br>(0~1)                          | STOP                     |

Table 4-30

## ◆ Group F07.4x: Start/Stop frequency holding and hopping frequency

| Parameter code<br>(Address) | Designation                           | Content  | Default<br>(Setting range)                                       | Adjustable<br>properties |
|-----------------------------|---------------------------------------|--|--|--------------------------|
| F07.40<br>(0x0728)          | Holding frequency at<br>start-up      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Holding frequency at start-up is larger than the starting<br>frequency and smaller than the upper frequency via number<br>setting | 0.50Hz<br>(0.00~ Upper limit<br>frequency via<br>number setting) | STOP                     |
| F07.41<br>(0x0729)          | Holding frequency<br>time at start-up | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The setting value should be larger than the starting<br>frequency, and if it is not, it starts with the starting<br>frequency.    | 0.0s<br>(0.0~60.0s)  | STOP                     |
| F07.42<br>(0x072A)          | Holding frequency<br>during shutdown  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the holding frequency during shutdown.  | 0.50Hz<br>(0.00~ Upper limit)                                    | STOP                     |

|                    |   |  |                                     |      |
|--------------------|---|--|-------------------------------------|------|
|                    |   |  | frequency via<br>number setting)    |      |
| F07.43<br>(0x072B) | Holding frequency<br>time during shutdown | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set holding frequency time during shutdown. | 0.0s<br>(0.0~60.0s)                 | STOP |
| F07.44<br>(0x072C) | Hopping frequency 1                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set hopping frequency 1.                    | 0.00Hz<br>(0.00~ Max.<br>frequency) | RUN  |
| F07.45<br>(0x072D) | Hopping frequency 1<br>amplitude          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set hopping frequency 1 amplitude.          | 0.00Hz<br>(0.00~ Max.<br>frequency) | RUN  |
| F07.46<br>(0x072E) | Hopping frequency 2                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set hopping frequency 2.                    | 0.00Hz<br>(0.00~ Max.<br>frequency) | RUN  |
| F07.47<br>(0x072F) | Hopping frequency 2<br>amplitude          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set hopping frequency 2 amplitude.          | 0.00Hz<br>(0.00~ Max.<br>frequency) | RUN  |

Table 4-31

#### 4.10 Group F10: Protection Parameters

##### ◆ Group F10.0x: Current protection

| Parameter code<br>(Address) | Designation                      | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|----------------------------------|--|----------------------------|--------------------------|
| F10.00<br>(0x0A00)          | Overcurrent<br>suppression       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Automatically limits the output current below the set<br>overcurrent suppression point to prevent excessive current<br>from triggering an overcurrent fault.<br>0: suppression is always valid;<br>1: acceleration/deceleration is valid, constant speed is not<br>valid. | 0<br>(0~1)                 | RUN                      |
| F10.01<br>(0x0A01)          | Overcurrent<br>suppression point | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the load current limit level, 100% corresponding to the<br>rated motor current.   | 185.0%<br>(0.0~300.0%)     | RUN                      |
| F10.02<br>(0x0A02)          | Overcurrent<br>suppression gain  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Sets the response effect of overcurrent suppression.  | 100.0%<br>(0.0~500.0%)     | RUN                      |
| F10.03                      | Current protection               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b>  | 0001                       | STOP                     |

|                    |                                 |  |                     |      |
|--------------------|---------------------------------|--|---------------------|------|
| (0x0A03)           | setting 1                       | <p>Sets whether the current-related protection function is on</p> <p>Ones-bit: Wave-by-wave current limiting (CBC)</p> <p>0: off</p> <p>1: on</p> <p>Tens-bit: OC protection interference suppression</p> <p>0: normal</p> <p>1: primary interference suppression</p> <p>2: secondary interference suppression</p> <p>Hundreds-bit: SC protection interference suppression</p> <p>0: normal</p> <p>1: primary interference suppression</p> <p>2: secondary interference suppression</p> <p>Thousands-bit: Reserved</p> | (0000-0221)         |      |
| F10.04<br>(0x0A04) | Current protection<br>setting 2 | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones-bit: three-phase current and protection selection</p> <p>0: off; 1: on</p>  | 0001<br>(0000-0001) | STOP |

Table 4-32

#### ◆ Group F10.1x: Voltage protection

| Parameter code<br>(Address) | Designation                               | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---|--|----------------------------|--------------------------|
| F10.10<br>(0x0A0A)          | Busbar overvoltage<br>hardware protection | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set whether the busbar overvoltage hardware protection function is on</p> <p>0: off; 1: on</p>   | 0<br>(0~1)                 | STOP                     |
| F10.11<br>(0x0A0B)          | Busbar overvoltage<br>suppression         | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>When the bus voltage is greater than the overvoltage suppression point, acceleration / deceleration will be slowed down or stopped to prevent over-voltage faults from being reported.</p> <p>Ones-bit: Overpressure suppression function</p> <p>0: off</p> <p>1: on only during deceleration</p> <p>2: on during both acceleration / deceleration</p> | 0012<br>(0000-0012)        | STOP                     |

|                    |                                       |  |                        |      |
|--------------------|---------------------------------------|--|------------------------|------|
|                    |                                       | Tens-bit: Overexcitation function<br>0:off; 1: on  |                        |      |
| F10.12<br>(0x0A0C) | Busbar overvoltage suppression        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set bus voltage value for triggering the overvoltage suppression function.  | 750V<br>(0~820V)       | STOP |
| F10.13<br>(0x0A0D) | Busbar overvoltage suppression gain   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Setting the response effect of overvoltage suppression.   | 100.0%<br>(0.0~500.0%) | RUN  |
| F10.14<br>(0x0A0E) | Energy consumption brake              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set whether the energy brake function is on or off<br>0: off<br>1: on, but the overvoltage suppression function is off<br>2: on, while the overvoltage suppression function is on   | 2<br>(0~2)             | RUN  |
| F10.15<br>(0x0A0F) | Energy consumption brake voltage      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the energy consumption brake working voltage, when the bus voltage is greater than this value, the energy consumption brake starts to work.   | 740V<br>(0~820V)       | RUN  |
| F10.16<br>(0x0A10) | Bus undervoltage suppression function | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>When the bus voltage is lower than the undervoltage suppression point, the running frequency is automatically adjusted to suppress the bus voltage reduction and prevent the undervoltage fault from being reported<br>0:off; 1: on | 0<br>(0~1)             | STOP |
| F10.17<br>(0x0A11) | Busbar undervoltage suppression point | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set bus voltage value for triggering the undervoltage suppression function.   | 430V<br>(0~820V)       | STOP |
| F10.18<br>(0x0A12) | Bus undervoltage suppression gain     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Setting the response effect of undervoltage suppression.  | 100.0%<br>(0.0~500.0%) | RUN  |
| F10.19<br>(0x0A13) | Busbar undervoltage protection point  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The set lower limit voltage allowed for bus voltage, below which the spindle drive reports an undervoltage fault  | 350V<br>(0~820V)       | STOP |

Table 4-33

## ◆ Group F10.2x: Auxiliary protection

| Parameter code | Designation | Content | Default | Adjustable |
|----------------|-------------|---------|---------|------------|
|----------------|-------------|---------|---------|------------|

| (Address)          |  |   | (Setting range)      | properties |
|--------------------|--|---|----------------------|------------|
| F10.20<br>(0x0A14) | Input / output phase loss protection selection | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set whether the input / output phase loss protection function is on.</p> <p>Ones-bit: Output phase loss protection function<br/>0: off; 1: on</p> <p>Tens-bit: Input phase loss protection function<br/>0: off<br/>1: on, input phase loss warning A.ILF is detected, continue running<br/>2: on, input phase loss warning A.ILF is detected, free stop</p> | 021<br>(000~121)     | STOP       |
| F10.21<br>(0x0A15) | Input phase loss threshold                     | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Voltage detection percentage of the set input phase loss detection, 100% corresponding to the rated bus voltage.</p>  | 10%<br>(0~30.0%)     | STOP       |
| F10.22<br>(0x0A16) | Ground short circuit protection selection      | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Whether the spindle drive output and the spindle drive cooling fan ground short circuit protection are on.</p> <p>Ones-bit: Output short circuit protection to ground<br/>0: off<br/>1: on</p> <p>Tens-bit: Cooling fan short circuit protection to ground<br/>0: off<br/>1: on</p>   | 11<br>(00~12)        | STOP       |
| F10.23<br>(0x0A17) | Fan ON/OFF control selection                   | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set spindle drive cooling fan running modes.</p> <p>0: fan runs after spindle drive is powered on<br/>1: fan is related to temperature after shutdown, and fan runs with the drive.<br/>2: Fan stops after the set F10.24 time after shutdown, and running is related to temperature.</p>   | 1<br>(0~2)           | RUN        |
| F10.24<br>(0x0A18) | Fan delay time                                 | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the time from when the run command is released to when the cooling fan stops running.</p>   | 30.00s<br>(0~600.00) | STOP       |

|                    |  |  |                     |     |
|--------------------|--|--|---------------------|-----|
| F10.25<br>(0x0A19) | Spindle drive<br>overheating oHI<br>warning detection<br>level | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the temperature value for spindle drive overheating warning, report the overheating warning when it's greater than the value. | 80.0°C<br>(0~100.0) | RUN |
|--------------------|--|--|---------------------|-----|

Table 4-34

## ◆ Group F10.3x: Load protection

| Parameter code<br>(Address) | Designation  | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|---|----------------------------|--------------------------|
| F10.30<br>(0x0A1E)          | Motor overload<br>protection curve<br>factor                               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the factor of overload protection for the load motor, increasing this value will increase the overload capacity of the motor.  | 100.0%<br>(0~250.0%)       | STOP                     |
| F10.31<br>(0x0A1F)          | Selection of spindle<br>drive overload<br>characteristics at low<br>speeds | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set whether the spindle drive overload protection function is effective at low speed (below 5Hz)<br>0: invalid<br>1: valid   | 0<br>(0~1)                 | STOP                     |
| F10.32<br>(0x0A20)          | Load warning<br>detection setting  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the spindle drive load warning detection method and the according warning method<br>LED ones-bit: Detection selection (protection 1)<br>0: no detection;<br>1: overload detection;<br>2: overload detection at constant speed only;<br>3: underload detection<br>4: underload detection at constant speed only;<br>5: overload detection (position control valid)<br>6: underload detection (position control valid)<br>LED tens-bit: Warning selection<br>0: report the warning and continue running<br>1: protections on and free stop<br>LED hundreds-bit: detection selection (protection 2)<br>0: no detection; | 0000<br>(0000~1414)        | STOP                     |

|                    |                                   |  |                      |      |
|--------------------|-----------------------------------|--|----------------------|------|
|                    |                                   | <p>1: overload detection;<br/> 2: overload detection at constant speed only;<br/> 3: underload detection<br/> 4: underload detection at constant speed only;<br/> 5: overload detection (position control valid)<br/> 6: underload detection (position control valid)<br/> LED thousands-bit: Warning selection<br/> 0: report the warning and continue running<br/> 1: protections on and free stop</p> |                      |      |
| F10.33<br>(0x0A21) | Load warning<br>detection level 1 | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the detection value 1 of load warning.<br/> For VF control, it is 100% of the rated motor current.<br/> For vector control, it is 100% the rated output torque of the motor.</p>   | 130.0%<br>(0~200.0%) | STOP |
| F10.34<br>(0x0A22) | Load warning<br>detection time 1  | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the duration of the detection of load warning 1, the load is greater than the load warning detection level after the duration of the time, report the load detection warning 1.</p>  | 5.0s<br>(0~60.0)     | STOP |
| F10.35<br>(0x0A23) | Load warning<br>detection level 2 | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the detection value 2 of load warning.<br/> For VF control, it is 100% of the rated motor current.<br/> For vector control, it is 100% the rated output torque of the motor.</p>   | 130.0%<br>(0~200.0%) | STOP |
| F10.36<br>(0x0A24) | Load warning<br>detection time 2  | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the duration of the detection of load warning 2, the load is greater than the load warning detection level after the duration of the time, report the load detection warning 2.</p>  | 5.0s<br>(0~60.0)     | STOP |

Table 4-35

#### ◆ Group F10.4x: Stall protection

| Parameter code<br>(Address) | Designation                             | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---|---|----------------------------|--------------------------|
| F10.40<br>(0x0A28)          | Excessive speed<br>deviation protection | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the selection of early warning detection method and</p> | 00<br>(00~12)              | STOP                     |



|                    |   |   |                      |      |
|--------------------|---|---|----------------------|------|
|                    |   | <p>warning method when the deviation between the given speed and the feedback speed of the motor is too large.</p> <p>Ones-bit: detection selection</p> <p>0: no detection</p> <p>1: detection on at constant speed only</p> <p>2: detection on all the time</p> <p>Tens-bit: Warning selection</p> <p>0: free stop and report fault</p> <p>1: report the warning and continue running</p>                                      |                      |      |
| F10.41<br>(0x0A29) | Excessive speed deviation detection threshold | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the detection value for excessive speed deviation, which is 100% of F01.10 [maximum frequency].</p>   | 10.0%<br>(0~60.0%)   | STOP |
| F10.42<br>(0x0A2A) | Excessive speed deviation detection time      | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the detection time for detecting excessive speed deviation. If the deviation between the given speed and the feedback speed is greater than F10.41 and lasts for this time, the excessive speed deviation warning is reported.</p>  | 2s<br>(0~60)         | STOP |
| F10.43<br>(0x0A2B) | Stall protection                              | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Setting the selection of detection method and warning method when the motor is running at high speed.</p> <p>Ones-bit: Detection selection</p> <p>0: no detection</p> <p>1: detection on at constant speed only</p> <p>2: detection on all the time</p> <p>Tens-bit: Warning selection</p> <p>0: free stop and report fault</p> <p>1: report the warning and continue running</p> | 00<br>(00~12)        | STOP |
| F10.44<br>(0x0A2C) | Stall detection threshold                     | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the stall warning detection value, which is 100% corresponding to F01.10 [maximum frequency]</p>  | 110.0%<br>(0~150.0%) | STOP |
| F10.45<br>(0x0A2D) | Stall detection time                          | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Set the duration of the stall detection, when the feedback speed is greater than F10.44 and continues for this time, the</p>  | 0.01s<br>(0~2)       | STOP |

|  |  |                                      |  |  |
|--|--|--------------------------------------|--|--|
|  |  | stall detection warning is reported. |  |  |
|--|--|--------------------------------------|--|--|

Table 4-36

#### ◆ Group F10.5x: Fault recovery protection

| Parameter code<br>(Address) | Designation                          | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--------------------------------------|---|----------------------------|--------------------------|
| F10.50<br>(0x0A32)          | Fault self-recovery<br>times         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the allowable times of fault self-recovery to be performed.<br>Note: 0 means to turn off the fault self-recovery function, otherwise it means this function is on. | 0<br>(0~10)                | STOP                     |
| F10.51<br>(0x0A33)          | Fault self-recovery<br>interval time | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the waiting time between a spindle drive failure and a reset.  | 1.0s<br>(0~100.0)          | STOP                     |
| F10.52<br>(0x0A34)          | Number of recovered<br>faults        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Indicate the number of fault self-recovery times that have been performed; read-only.  | 0                          | READ                     |

Table 4-37

#### 4.11 Group F11: Operator Parameters

##### ◆Group F11.0x: Key operation

| Parameter code<br>(Address) | Designation                   | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|-------------------------------|---|----------------------------|--------------------------|
| F11.00<br>(0x0B00)          | Key lock selection            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: no lock<br>1: keyboard lock of function parameter modification<br>2: function parameters and non-start/stop key lock<br>3: function parameters and key full-lock  | 0<br>(0~3)                 | RUN                      |
| F11.01<br>(0x0B01)          | Key lock password             | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set key lock password.   | 0<br>(0~65535)             | RUN                      |
| F11.04<br>(0x0B04)          | Up/down function<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: Up / down modification selection<br>0: invalid<br>1: used to adjust F01.09 frequency given via keyboard<br>2: used to adjust F13.01 PID given via keyboard<br>3: Keyboard up / down to modify the parameter number | 0011<br>(0000~0213)        | STOP                     |

|                    |  |   |                     |     |
|--------------------|--|---|---------------------|-----|
|                    |  | <p>Tens-bit: Power-down storage</p> <p>0: power-down frequency storage off</p> <p>1: power-down frequency storage on</p> <p>Hundreds-bit: Restrictions</p> <p>0: adjustable during stop</p> <p>1: adjustable only during running, stored during stop</p> <p>2: adjustable during running, cleared during stop</p> |                     |     |
| F11.05<br>(0x0B05) | Up / down for quick change of parameter code | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones- and tens-bit: set 00~99 to yy in the function code Fxx.yy.</p> <p>Hundreds- and thousands-bit: set 00~15 to xx in the function code Fxx.yy.</p>   | 0109<br>(0000~1563) | RUN |

Table 4-38

#### ◆ Group F11.1x: Cycle monitoring on the status interface

| Parameter code<br>(Address) | Designation   | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---|---|----------------------------|--------------------------|
| F11.11<br>(0x0B0B)          | Cyclic display parameter 1 on the 1 <sup>st</sup> cable | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones- and tens-bit: set 00~63to yy in the function code Cxx.yy.</p> | 0000<br>(0000~0763)        | RUN                      |
| F11.12<br>(0x0B0C)          | Cyclic display parameter 2 on the 1 <sup>st</sup> cable | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones- and tens-bit: set 00~63to yy in the function code Cxx.yy.</p> | 0001<br>(0000~0763)        | RUN                      |
| F11.13<br>(0x0B0D)          | Cyclic display parameter 3 on the 1 <sup>st</sup> cable | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones- and tens-bit: set 00~63to yy in the function code Cxx.yy.</p> | 0002<br>(0000~0763)        | RUN                      |
| F11.14<br>(0x0B0E)          | Cyclic display parameter 4 on the 1 <sup>st</sup> cable | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones- and tens-bit: set 00~63to yy in the function code Cxx.yy.</p> | 0011<br>(0000~0763)        | RUN                      |

Table 4-39

#### ◆ Group F11.2x: Monitoring parameter control

| Parameter code<br>(Address) | Designation               | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|---------------------------|--|----------------------------|--------------------------|
| F11.20<br>(0x0B14)          | Keyboard display settings | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b></p> <p>Ones-bit: Output frequency display selection</p> | 0002<br>(0000~111f)        | RUN                      |

|                    |                                    |  |                            |      |
|--------------------|------------------------------------|--|----------------------------|------|
|                    |                                    | <p>0: target frequency<br/>1: running frequency<br/>2: target frequency, filter depth increases with this value<br/>Tens-bit: Reserved<br/>0: invalid<br/>1: active power by removing stator resistance loss<br/>Hundreds-bit: Power with scale<br/>0: power with percentage (%)<br/>1: power with kilowatt (KW)<br/>Thousands-bit: Reserved</p>   |                            |      |
| F11.21<br>(0x0B15) | Speed factor                       | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b><br/>Adjust the display of C00.06 RPM.</p>   | 100.0%<br>(0.0~500.0%)     | RUN  |
| F11.22<br>(0x0B16) | Power factor                       | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b><br/>Adjust the display of C00.10 output power.</p>  | 100.0%<br>(0.0~500.0%)     | RUN  |
| F11.23<br>(0x0B17) | Monitoring parameter group display | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b><br/>Ones-bit: Reserved<br/>0: invalid; 1: valid<br/>Tens-bit: C05 display selection<br/>0: automatic switching according to the control modes<br/>1: VF mode related parameters<br/>2: VC mode related parameters<br/>Hundreds-bit: C00.40~C00.63 display selection<br/>0: no display; 1: display<br/>Thousands-bit: Communication fault code switching<br/>0: non-enabling;<br/>1: enable;</p> | 0000<br>(0000~FFFF)        | RUN  |
| F11.24<br>(0x0B18) | Monitoring parameter filter        | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b><br/>Ones-bit: Output current with filtering<br/>0-F: The larger the value, the deeper the filtering</p>   | 0x0000<br>(0x0000~0x 000F) | RUN  |
| F11.25<br>(0x0B19) | Display during motor self-learning | <p><b>V/F SVC FVC PMVF PMSVC PMFVC</b><br/>Set the display when the motor is self-learning<br/>0: display self-learning process status;<br/>1: self-learning process status is not displayed</p>   | 0<br>(0~1)                 | STOP |

|                    |                            |  |                           |     |
|--------------------|----------------------------|--|---------------------------|-----|
| F11.27<br>(0x0B1B) | Fault display<br>selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: set whether to display the faults when they are self-recovered<br>0: no display<br>1: display | 0x0001<br>(0x0000-0x0001) | RUN |
|--------------------|----------------------------|--|---------------------------|-----|

Table 4-40

## 4.12 Group F12: Communication Parameters

### ◆Group F12.0x: MODBUS slave parameters

| Parameter code<br>(Address) | Designation                        | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|------------------------------------|---|----------------------------|--------------------------|
| F12.00<br>(0x0C00)          | Master/Slave<br>selection          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: slave, 1: master  | 0<br>(0~1)                 | STOP                     |
| F12.01<br>(0x0C01)          | Modbus<br>communication<br>address | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Different values are set for different slaves.   | 1<br>(1~247)               | STOP                     |
| F12.02<br>(0x0C02)          | Communication baud<br>rate         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0:1200 bps<br>1:2400 bps<br>2:4800 bps<br>3:9600 bps<br>4:19200 bps<br>5:38400 bps<br>6:57600 bps  | 3<br>(0~6)                 | STOP                     |
| F12.03<br>(0x0C03)          | Modbus data format                 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0:(N, 8, 1) No checksum.<br>Data bit:8.<br>Stop bit:1<br>1:(E, 8, 1) even parity.<br>Data bit:8.<br>Stop bit:1<br>2:(O, 8, 1) odd parity.<br>Data bit:8.<br>Stop bit:1<br>3:(N, 8, 2) No parity. | 0<br>(0~5)                 | STOP                     |

|                    |   |   |                          |     |
|--------------------|---|---|--------------------------|-----|
|                    |   | Data bit:8.<br>Stop bit:2<br>4:(E, 8, 2) even parity.<br>Data bit:8.<br>Stop bit:2<br>5:(O, 8, 2) odd parity.<br>Data bit:8.<br>Stop bit:2                          |                          |     |
| F12.04<br>(0x0C04) | Modbus transmission<br>response processing      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: write operation with response<br>1: write operation without response  | 0<br>(0~1)               | RUN |
| F12.05<br>(0x0C05) | Modbus<br>communication<br>response delay       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set Modbus communication response delay.   | 0ms<br>(0~500ms)         | RUN |
| F12.06<br>(0x0C06) | Modbus<br>communication<br>failure timeout time | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set Modbus communication failure timeout time  | 1.0s<br>(0.1~100s)       | RUN |
| F12.07<br>(0x0C07) | Communication<br>disconnection<br>processing    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: no timeout fault detection<br>1: fault detected and free stop<br>2: report warning and continue running<br>3: forced stop | 0<br>(0~3)               | RUN |
| F12.08<br>(0x0C08) | Receive data (address<br>0x3000) zero offset    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Offset correction for address 0x3000 communication data.   | 0.00<br>(-100.00~100.00) | RUN |
| F12.09<br>(0x0C09) | Receive data (address<br>0x3000) gain           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Liner correction of the address 0x3000 communication data.   | 100.0%<br>(0.0~500.0%)   | RUN |

Table 4-41

## ◆ Group F12.1x: MODBUS master parameters

| Parameter code<br>(Address) | Designation                                  | Content  | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|--|--|----------------------------|--------------------------|
| F12.10<br>(0x0C0A)          | Master sending cyclic<br>parameter selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-, tens-, hundreds-, and thousands-bit:<br>0: invalid | 0031<br>(0000~CCCC)        | RUN                      |

|                    |                                      |   |                     |     |
|--------------------|--------------------------------------|---|---------------------|-----|
|                    |                                      | 1: master running command<br>2: master given frequency<br>3: master output frequency<br>4: master upper limit frequency<br>5: master given torque<br>6: master output torque<br>7: reserved<br>8: reserved<br>9: master given PID<br>A: master PID feedback<br>B: reserved<br>C: active current component |                     |     |
| F12.11<br>(0x0C0B) | Customized address to give frequency | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the customized address to give frequency.  | 0000<br>(0000-FFFF) | RUN |
| F12.12<br>(0x0C0C) | Customized address to send command   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Customized address to send command.  | 0000<br>(0000-FFFF) | RUN |
| F12.13<br>(0x0C0D) | Forward running command value        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the command to the forward running value.  | 0001<br>(0000-FFFF) | RUN |
| F12.14<br>(0x0C0E) | Reverse running command value        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the command to the reverse running value.  | 0002<br>(0000-FFFF) | RUN |
| F12.15<br>(0x0C0F) | Stop command value                   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the command to the stop value.   | 0005<br>(0000-FFFF) | RUN |
| F12.16<br>(0x0C10) | Reset command value                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the command to the reset value.  | 0007<br>(0000-FFFF) | RUN |

Table 4-42

◆ Group F12.6x:M3 bus communication parameters

|                    |                    |   |                     |      |
|--------------------|--------------------|---|---------------------|------|
| F12.61<br>(0x0C3D) | M3 bus axis No.    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: Corresponding CNC axis number<br>0-F<br>Tens-bit: Reserved | 0024<br>(0000-FFFF) | STOP |
| F12.62<br>(0x0C3E) | M3 bus data length | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Corresponding CNC data length<br>0:16 bytes                          | 2<br>(0-5)          | STOP |

|                    |  |  |            |      |
|--------------------|--|--|------------|------|
|                    |  | 1:32 bytes<br>2:48 bytes<br>3:64 bytes   |            |      |
| F12.63<br>(0x0C3F) | Burning and upper computer connection method | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The communication method during communication with the master computer or burning software.<br>0: USB<br>1: UART<br>Select the correct one and then connect them correctly. | 1<br>(0-5) | STOP |

Table 4-43

**4.13 Group F15: Position Control**

| Parameter code<br>(Address) | Designation                        | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|------------------------------------|---|----------------------------|--------------------------|
| F15.00<br>(0x0F00)          | Position control mode selection    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0:off; 1:on  | 0<br>(0-1)                 | RUN                      |
| F15.01<br>(0x0F01)          | Pulse position giving              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: keyboard 1: X7 terminal 2: pulse terminal   | 2<br>(0-2)                 | RUN                      |
| F15.02<br>(0x0F02)          | Pulse counting mode                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0:AB;<br>1:CW+CCW;<br>2: pulse + direction;<br>3: reserved;<br>4: opposite to AB;<br>5: opposite to CW+CCW;<br>6: opposite to pulse + direction;<br>7: reserved; | 4<br>(0-7)                 | STOP                     |
| F15.03<br>(0x0F03)          | Setting via keyboard numbers       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the amount of pulses via keyboard.   | 0<br>(0-65535)             | RUN                      |
| F15.04<br>(0x0F04)          | Electronic gear numerator          | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set electronic gear ratio numerator.   | 1<br>(1-32767)             | STOP                     |
| F15.05<br>(0x0F05)          | Electronic gear denominator        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set electronic gear ratio denominator.   | 1<br>(1-32767)             | STOP                     |
| F15.06<br>(0x0F06)          | Set first order filtering time for | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Used to filter the input position command to make motor  | 0.0<br>(0.0-6000.0ms)      | STOP                     |



|                    | positions                                     | rotation smoother  |   |      |
|--------------------|---|--|---|------|
| F15.07<br>(0x0F07) | Set given smoothing filter time for positions | V/F SVC FVC PMVF PMSVC PMFVC<br>Used to filter the input position command to make motor rotation smoother.   | 0.1<br>(0.0~512.0ms)                          | STOP |
| F15.08<br>(0x0F08) | Speed feedforward gain                        | V/F SVC FVC PMVF PMSVC PMFVC<br>For improving system dynamic running and following performance.  | 100.0%<br>(0.0%~300.0%)                       | RUN  |
| F15.09<br>(0x0F09) | Speed feedforward filter time                 | V/F SVC FVC PMVF PMSVC PMFVC<br>Filter the command pulse signal to increase interference immunity.   | 1.0<br>(0.0~100.0ms)                          | RUN  |
| F15.10<br>(0x0F0A) | Position controller output limit              | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the output limit value of the position proportional controller.  | 100.0%<br>(0.0%~100.0%)                       | RUN  |
| F15.11<br>(0x0F0B) | Position loop proportional gain 1             | V/F SVC FVC PMVF PMSVC PMFVC<br>For improving system response and rigidity.  | 50.0<br>(0.0~600.0Hz)                         | RUN  |
| F15.12<br>(0x0F0C) | Position loop proportional gain 2             | V/F SVC FVC PMVF PMSVC PMFVC<br>For improving system response and rigidity.  | 30.0<br>(0.0~600.0Hz)                         | RUN  |
| F15.13<br>(0x0F0D) | Gain switching mode                           | V/F SVC FVC PMVF PMSVC PMFVC<br>0: no switching; 1: terminal switching<br>2: position error; 3: speed error  | 0<br>(0~3)                                    | STOP |
| F15.14<br>(0x0F0E) | Switching filter time                         | V/F SVC FVC PMVF PMSVC PMFVC<br>For adjusting the smooth switching position loop gain.   | 0.030<br>(0.000~6.000s)                       | STOP |
| F15.15<br>(0x0F0F) | Switching position error                      | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the position error value of switching gain.  | 10<br>(1~32767)                               | RUN  |
| F15.16<br>(0x0F10) | Switching speed command                       | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the speed value of switching gain.   | 0.00Hz<br>(0.00~ Max. frequency via keyboard) | RUN  |
| F15.17<br>(0x0F11) | Positioning completion condition              | V/F SVC FVC PMVF PMSVC PMFVC<br>0: the absolute value of position deviation is smaller than the positioning completion range.<br>1: the absolute value of position deviation is smaller than the positioning completion range and the position command | 0<br>(0~1)                                    | RUN  |

|                    |  |   |                          |      |
|--------------------|--|---|--------------------------|------|
|                    |  | is zero.  |                          |      |
| F15.18<br>(0x0F12) | Positioning<br>completion width            | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the positioning completion threshold.   | 10<br>(1~32767)          | RUN  |
| F15.19<br>(0x0F13) | Position proximity<br>width                | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>When the absolute value of position deviation is smaller than the position proximity width, the output terminal "position proximity" outputs a valid signal                       | 100<br>(1~32767)         | RUN  |
| F15.20<br>(0x0F14) | Zero servo<br>movement error               | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set zero servo movement deviation threshold.  | 0<br>(0~1000)            | RUN  |
| F15.21<br>(0x0F15) | Position overrun<br>selection              | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: position overrun remains undetected;<br>1: position overrun detection is valid, and send the warning signal.<br>2: position overrun detection is valid, send the fault signal. | 0<br>(0~2)               | RUN  |
| F15.22<br>(0x0F16) | Position overrun<br>detection frequency    | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set frequency threshold for position overrun detection.   | 110.0%<br>(0.0%~200.0%)  | RUN  |
| F15.23<br>(0x0F17) | Position overrun<br>detection time         | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set position overrun detection time.  | 10ms<br>(0~6000ms)       | STOP |
| F15.24<br>(0x0F18) | Servo stop method                          | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: enter the shutdown state after positioning is completed.<br>1: control mode switching to speed control mode to stop at zero speed  | 0<br>(0~1)               | STOP |
| F15.25<br>(0x0F19) | Position control ASR<br>proportional gain  | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system response and rigidity.   | 30.00<br>(0.01~100.00)   | RUN  |
| F15.26<br>(0x0F1A) | Position control ASR<br>integral time      | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system response and rigidity.   | 0.050s<br>(0.000~6.000s) | RUN  |
| F15.28<br>(0x0F1C) | Pulse numerator of<br>transmission ratio   | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder pulses as the numerator in the transmission ratio.  | 1000<br>(0~65535)        | RUN  |
| F15.29<br>(0x0F1D) | Pulse denominator of<br>transmission ratio | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder pulses as the denominator in the transmission ratio.  | 1000<br>(0~65535)        | RUN  |
| F15.30             | Subdivision feedback                       | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b>  | 0                        | STOP |

|                    |  |   |                       |      |
|--------------------|--|---|-----------------------|------|
| (0x0F1E)           |  | 0: no subdivision required<br>1: speed subdivided while position not (sine + cosine + square wave)<br>2: speed and position subdivided (sine cosine, sine cosine + sine cosine) | (0~2)                 |      |
| F15.31<br>(0x0F1F) | Z-pulse width extension                  | V/F SVC FVC PMVF PMSVC PMFVC<br>Hundreds-bit: Spindle encoder<br>Thousands-bit: Motor encoder<br>0: no movement; 1: Z-pulse extension   | 1100<br>(0000~1111)   | STOP |
| F15.32<br>(0x0F20) | ADRC observer gain $\beta$ 1             | V/F SVC FVC PMVF PMSVC PMFVC<br>For improving system response and rigidity.   | 10000<br>(0~20000)    | RUN  |
| F15.33<br>(0x0F21) | ADRC observer gain $\beta$ 2             | V/F SVC FVC PMVF PMSVC PMFVC<br>For improving system response and rigidity.   | 100<br>(0~200)        | RUN  |
| F15.34<br>(0x0F22) | ADRC input factor b                      | V/F SVC FVC PMVF PMSVC PMFVC<br>For improving system response and rigidity.   | 32<br>(1~200)         | RUN  |
| F15.35<br>(0x0F23) | ADRC toggle switch                       | V/F SVC FVC PMVF PMSVC PMFVC<br>Toggle switch between ADRC and PI.  | 1<br>(0~1)            | STOP |
| F15.36<br>(0x0F24) | Torque feedforward gain                  | V/F SVC FVC PMVF PMSVC PMFVC<br>Torque feedforward gain during position control.  | 0.00<br>(0.00~100.00) | RUN  |
| F15.41<br>(0x0F29) | Mechanical brake current limit threshold | V/F SVC FVC PMVF PMSVC PMFVC<br>When it is turned on, the current is limited within the error range of the corresponding position.  | 0<br>(0~10000)        | RUN  |
| F15.46<br>(0x0F2E) | Low speed measurement method             | V/F SVC FVC PMVF PMSVC PMFVC<br>Speed measurement method at position control<br>0: low speed equivalent M method<br>1: M/T method + T method                                    | 0<br>(0~1)            | RUN  |

Table 4-44

#### 4.14 Group F24: Spindle Control

| Parameter code<br>(Address) | Designation                        | Content   | Default<br>(Setting range) | Adjustable<br>properties |
|-----------------------------|------------------------------------|---|----------------------------|--------------------------|
| F24.00<br>(0x5800)          | Spindle positioning                | V/F SVC FVC PMVF PMSVC PMFVC<br>0: disabled; 1: enabled         | 0<br>(0~1)                 | STOP                     |
| F24.01<br>(0x5801)          | Orientation positioning zero point | V/F SVC FVC PMVF PMSVC PMFVC<br>0: Z-pulse; 1: proximity switch | 0<br>(0~1)                 | STOP                     |

|                    |   |   |                         |      |
|--------------------|---|---|-------------------------|------|
| F24.02<br>(0x5802) | Zero update mode                                  | V/F SVC FVC PMVF PMSVC PMFVC<br>0: update only for the first time after power-up<br>1: update at each zero-edge signal                | 0<br>(0~1)              | STOP |
| F24.03<br>(0x5803) | Orientated mode 2<br>running mode                 | V/F SVC FVC PMVF PMSVC PMFVC<br>0:in positioning mode 2, spindle running <1 turn<br>1: in positioning mode 2, spindle running >1 turn | 0<br>(0~1)              | STOP |
| F24.04<br>(0x5804) | Orientated running<br>direction                   | V/F SVC FVC PMVF PMSVC PMFVC<br>0: minimum travel principle<br>1: forward<br>2: reverse   | 0<br>(0~2)              | STOP |
| F24.05<br>(0x5805) | Orientation speed                                 | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the speed when searching for Z pulses or proximity switches.                                      | 5.00<br>(0.01~100.00Hz) | STOP |
| F24.06<br>(0x5806) | Orientated<br>acceleration /<br>deceleration time | V/F SVC FVC PMVF PMSVC PMFVC<br>Set acceleration / deceleration time when searching for Z pulse or proximity switch.                  | 3.00s<br>(0.01~100.00s) | STOP |
| F24.07<br>(0x5807) | Spindle indexing<br>offset                        | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing offset value.  | 0<br>(0~65535)          | STOP |
| F24.08<br>(0x5808) | Spindle indexing<br>position 1                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 1.  | 0<br>(0~65535)          | STOP |
| F24.09<br>(0x5809) | Spindle indexing<br>position 2                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 2.  | 0<br>(0~65535)          | STOP |
| F24.10<br>(0x580A) | Spindle indexing<br>position 3                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 3.  | 0<br>(0~65535)          | STOP |
| F24.11<br>(0x580B) | Spindle indexing<br>position 4                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 4.  | 0<br>(0~65535)          | STOP |
| F24.12<br>(0x580C) | Spindle indexing<br>position 5                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 5.  | 0<br>(0~65535)          | STOP |
| F24.13<br>(0x580D) | Spindle indexing<br>position 6                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 6.  | 0<br>(0~65535)          | STOP |
| F24.14<br>(0x580E) | Spindle indexing<br>position 7                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing position 7.  | 0<br>(0~65535)          | STOP |
| F24.15             | Spindle indexing                                  | V/F SVC FVC PMVF PMSVC PMFVC  | 0                       | STOP |

|                     |   |  |                          |      |
|---------------------|---|--|--------------------------|------|
| (0x580F)            | position 8  | Set spindle indexing position 8.   | (0~65535)                |      |
| F24.16<br>(0x5810)  | Delay time of indexing selection terminal with valid change                   | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set delay time of indexing selection terminals when changes are valid.   | 0.010S<br>(0.000~1.000S) | STOP |
| F24.20<br>(0x5814)  | Orientated position loop proportional gain                                    | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the proportional gain of the orientated position loop.   | 60.0Hz<br>(0.1~600.0Hz)  | RUN  |
| F24.21<br>(0x5815)  | Orientated speed loop proportional gain                                       | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set orientated speed loop proportional gain.   | 20.00<br>(0.01~100.00)   | RUN  |
| F24.22<br>(0x5816)  | Orientated speed loop integral time   | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set orientated speed loop integral time.   | 0.050s<br>(0.000~6.000s) | RUN  |
| F24.23<br>(0x5817)  | Zero-speed orientated position loop proportional gain                         | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set zero-speed orientated position loop proportional gain.   | 40.0Hz<br>(0.1~600.0Hz)  | RUN  |
| F24.24<br>(0x5818)  | Zero-speed position loop output limit   | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Limit position loop output amplitude at zero speed.  | 2.5%<br>(0.0~100.0%)     | RUN  |
| F024.25<br>(0x5819) | Proximity switch equivalent number of pulses of one turn                      | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>The number of one-turn pulses of the orientated proximity switch is automatically set during self-learning.  | 0<br>(0~65535)           | STOP |
| F024.26<br>(0x581A) | Effective number of proximity switch rotation after starting                  | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>A value greater than this is considered valid for an orientated position.  | 2<br>(0~100)             | STOP |
| F024.27<br>(0x581B) | Proximity switch orientated positioning effective times after starting        | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>The first orientated positioning is performed only if it is greater than this value, otherwise it will keep rotating to find the proximity switch point.   | 3<br>(0~100)             | STOP |
| F024.28<br>(0x581C) | Proximity switch captured effective deviation threshold during first power-up | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Judge whether the captured proximity switch latching point is valid according to the first three rotations, if the deviation of the first two comparisons with the corresponding number of pulses per revolution F24.25 is within the setting range of this value, it is considered normal, otherwise the search for the finite proximity switch point will start again. | 20<br>(0~65535)          | STOP |

|                    |   |   |                |      |
|--------------------|---|---|----------------|------|
| F24.29<br>(0x581D) | 2nd gear proximity switches equivalent number of pulses in one turn | V/F SVC FVC PMVF PMSVC PMFVC<br>The number of one-turn pulses when the second gear proximity switch is orientated, which is set automatically during self-learning. The second gear works when the Xi terminal is set to 86 and receives a high level, and system will send to the drive that this is the second gear and the drive runs as the second gear parameter F24.29/F24.30, otherwise it runs as the first gear parameter F24.25/F24.07. | 0<br>(0-65535) | STOP |
| F24.30<br>(0x581E) | 2nd gear spindle indexing offset                                    | V/F SVC FVC PMVF PMSVC PMFVC<br>Set spindle indexing offset value.  | 0<br>(0-65535) | STOP |

Table 4-45



#### 4.15 C0x Group: Monitoring Parameters

##### Group C00: Basic monitoring

| Code (address)  | Designation                      | Code (address)  | Designation                                 |
|-----------------|----------------------------------|-----------------|---|
| C00.00 (0x2100) | Given frequency                  | C00.20 (0x2114) | Analog output AO                            |
| C00.01 (0x2101) | Output frequency                 | C00.21 (0x2115) | Reserved                                    |
| C00.02(0x2102)  | Output current                   | C00.22 (0x2116) | Counter value                               |
| C00.03 (0x2103) | Input voltage                    | C00.23 (0x2117) | This power-up running time                  |
| C00.04 (0x2104) | Output voltage                   | C00.24 (0x2118) | Cumulative running time                     |
| C00.05 (0x2105) | Mechanical speed                 | C00.25 (0x2119) | Spindle drive power level                   |
| C00.06 (0x2106) | Given torque                     | C00.26 (0x211A) | Spindle drive rated voltage                 |
| C00.07 (0x2107) | Output torque                    | C00.27 (0x211B) | Spindle drive rated current                 |
| C00.08 (0x2108) | Given PID                        | C00.28 (0x211C) | Software version                            |
| C00.09 (0x2109) | PID feedback                     | C00.29 (0x211D) | PG feedback frequency                       |
| C00.10 (0x210A) | Output power                     | C00.30 (0x211E) | Timer                                       |
| C00.11 (0x210B) | Bus voltage                      | C00.31 (0x211F) | PID output value                            |
| C00.12 (0x210C) | Module temperature 1             | C00.32 (0x2120) | Spindle drive software sub-version          |
| C00.13 (0x210D) | Module temperature 2             | C00.33(0x2121)  | Encoder feedback angle                      |
| C00.14 (0x210E) | Input terminal X ON state (Note) | C00.34 (0x2122) | Z pulse cumulative error                    |
| C00.15 (0x210F) | Input terminal Y ON state (Note) | C00.35 (0x2123) | Z-pulse counting                            |
| C00.16(0x2110)  | Analog AI1 input value           | C00.36 (0x2124) | Fault warning code                          |
| C00.17 (0x2111) | Analog AI2 input value           | C00.37 (0x2125) | Cumulative electricity consumption<br>(low) |

|                 |                                    |                 |   |
|-----------------|------------------------------------|-----------------|---|
| C00.18 (0x2112) | Keyboard potentiometer input value | C00.38 (0x2126) | Cumulative electricity consumption (high) |
| C00.19 (0x2113) | Pulse signal PUL input value       | C00.39 (0x2127) | Impedance angle                           |

Table 4-46

Note: For example, when terminals X1 and X2 are ON, C00.14 is displayed as  , When the terminal Y and the relay are ON, C00.15 is displayed as  .

**Group C01: Fault monitoring**

| Code (address)  | Designation                            | Code (address)  | Designation                             |
|-----------------|--|-----------------|---|
| C01.00 (0x2200) | Fault type diagnosis information       | C01.12 (0x220C) | Previous 1 fault running frequency      |
| C01.01 (0x2201) | Troubleshooting information            | C01.13 (0x220D) | Previous 1 fault output voltage         |
| C01.02 (0x2202) | Fault running frequency                | C01.14 (0x220E) | Previous 1 fault output current         |
| C01.03 (0x2203) | Fault output voltage                   | C01.15 (0x220F) | Previous 1 fault bus voltage            |
| C01.04 (0x2204) | Fault output current                   | C01.16 (0x2210) | Previous 1 fault module temperature     |
| C01.05 (0x2205) | Fault bus voltage                      | C01.17 (0x2211) | Previous 1 spindle drive fault status   |
| C01.06 (0x2206) | Fault module temperature               | C01.18 (0x2212) | Previous 1 fault input terminal status  |
| C01.07 (0x2207) | Spindle drive fault status             | C01.19 (0x2213) | Previous 1 fault output terminal status |
| C01.08 (0x2208) | Fault input terminal status            | C01.20 (0x2214) | Previous 2 fault types                  |
| C01.09 (0x2209) | Fault output terminal status           | C01.21 (0x2215) | Previous 2 troubleshooting information  |
| C01.10 (0x220A) | Previous 1 fault type                  | C01.22 (0x2216) | Previous 3 fault types                  |
| C01.11 (0x220B) | Previous 1 troubleshooting information | C01.23 (0x2217) | Previous 3 troubleshooting information  |

Table 4-47

**Group C02: Application monitoring**

| Code (address)  | Designation               | Code (address)             | Designation                         |
|-----------------|---------------------------|----------------------------|-------------------------------------|
| C02.08 (0x2308) | Forward / reverse command | C02.15 (0x230F)            | Inverter overload timing factor     |
| C02.09 (0x2309) | Jogging command           | C02.16(0x2310)<br>(0x2310) | Motor overload timing factor        |
| C02.10 (0x230A) | A11 with curve adjustment | C02.18(0x2312)<br>(0x2310) | Real-time carrier frequency         |
| C02.11 (0x230B) | A12 with curve adjustment | C02.19 (0x2313)            | Wave-by-wave current limiting times |

Table 4-48

**Group C04: Spindle feedback monitoring**

| Code (address)  | Designation                    | Code (address)  | Designation                                 |
|-----------------|--------------------------------|-----------------|---|
| C04.00 (0x2500) | Spindle position (pulse)       | C04.25 (0x2519) | Spindle encoder pulse counting              |
| C04.01 (0x2501) | Spindle position (angle)       | C04.26 (0x251A) | Spindle encoder one-turn position           |
| C04.02 (0x2502) | Spindle zero counting          | C04.27 (0x251B) | Spindle encoder Z pulse detection<br>No.    |
| C04.03 (0x2503) | Spindle external zero counting | C04.28 (0x251C) | Spindle encoder Z pulse cumulative<br>error |
| C04.04 (0x2504) | Spindle external zero position | C04.29 (0x251D) | Spindle encoder frequency (PU)              |
| C04.15          | Position error                 |                 |   |

Table 4-49

**Group C05: Position control monitoring**

| Code (address)  | Designation                 | Code (address)  | Designation                               |
|-----------------|-----------------------------|-----------------|---|
| C05.20 (0x2614) | Pulse command counting      | C05.25 (0x2619) | Motor encoder pulse counting              |
| C05.21 (0x2615) | Pulse counting increment    | C05.26 (0x261A) | Motor encoder one-turn position           |
| C05.22 (0x2616) | Pulse counting frequency    | C05.27 (0x261B) | Motor encoder Z-pulse detection<br>times  |
| C05.23 (0x2617) | X7 pulse counting           | C05.28 (0x261C) | Motor encoder Z pulse cumulative<br>error |
| C05.24 (0x2618) | X7 pulse counting frequency | C05.29 (0x261D) | Motor encoder frequency (PU)              |

Table 4-50

**4.16 Terminal input / Output Function Selection**

| X | Function explanation               | X  | Function explanation                                 | X  | Function explanation                   |
|---|------------------------------------|----|--|----|--|
| 0 | No function                        | 29 | PID feedback switching 3                             | 58 | Run output blocking command            |
| 1 | Forward running                    | 30 | Program running (PLC) pause                          | 59 | Reserved                               |
| 2 | Reverse running                    | 31 | Program running (PLC) reboot                         | 60 | Speed-torque control switching         |
| 3 | Three-wire running control<br>(Xi) | 32 | Acceleration/deceleration time<br>setting terminal 1 | 61 | Rigid tapping / pulse position control |
| 4 | Forward jogging                    | 33 | Acceleration/deceleration time<br>setting terminal 2 | 62 | Reserved                               |
| 5 | Reverse jogging                    | 34 | Acceleration/deceleration pause                      | 63 | Reserved                               |
| 6 | Free stop                          | 35 | Swing frequency input                                | 64 | Zero-servo command                     |
| 7 | Emergency stop                     | 36 | Swing frequency pause                                | 65 | Reserved                               |
| 8 | Fault reset                        | 37 | Swing frequency reset                                | 66 | Reserved                               |



|          |  |          |   |          |   |
|----------|--|----------|---|----------|---|
| 9        | External fault input                         | 38       | Keyboard keys and self-test display selection | 67       | Reserved                                    |
| 10       | Frequency up (UP)                            | 39       | X4 frequency measurement                      | 68       | Reserved                                    |
| 11       | Frequency down (DW)                          | 40       | Timer triggering terminal                     | 69       | Position gain switching                     |
| 12       | Frequency up/down (UP/DW zero clearing)      | 41       | Timer zeroing terminal                        | 70       | X7 pulse direction switching                |
| 13       | Channel A switching to channel B             | 42       | Counter clock input terminal                  | 71       | Pulse input disabled                        |
| 14       | Frequency channel combination switching to A | 43       | Counter zeroing terminal                      | 72       | Pulse error zeroing                         |
| 15       | Frequency channel combination switching to B | 44       | DC brake command                              | 73       | Pulse forward running disabled              |
| 16       | Multi-speed terminal 1                       | 45       | Pre-excitation command terminal               | 74       | Pulse reverse running disabled              |
| 17       | Multi-speed terminal 2                       | 46       | Reserved                                      | 75       | Reserved                                    |
| 18       | Multi-speed terminal 3                       | 47       | Reserved                                      | 76       | Reserved                                    |
| 19       | Multi-speed terminal 4                       | 48       | Command channel switching to keyboard         | 77       | Reserved                                    |
| 20       | PID control cancellation                     | 49       | Command channel switching to terminal         | 78       | Reserved                                    |
| 21       | PID control pause                            | 50       | Command channel switching to communication    | 79       | Reserved                                    |
| 22       | PID characteristic switching                 | 51       | Reserved                                      | 80       | Spindle orientation enabled                 |
| 23       | PID parameter switching                      | 52       | Running disabled                              | 81       | Indexing selection 1                        |
| 24       | PID giving switching 1                       | 53       | Forward running disabled                      | 82       | Indexing selection 2                        |
| 25       | PID giving switching 2                       | 54       | Reverse running disabled                      | 83       | Indexing selection 3                        |
| 26       | PID giving switching 3                       | 55       | Reserved                                      | 84       | Proximity switch                            |
| 27       | PID feedback switching 1                     | 56       | Reserved                                      | 85       | Swing enabled                               |
| 28       | PID feedback switching 2                     | 57       | Reserved                                      |          |   |
| <b>Y</b> | <b>Function explanation</b>                  | <b>Y</b> | <b>Function explanation</b>                   | <b>Y</b> | <b>Function explanation</b>                 |
| 0        | No output                                    | 15       | Program running cycle completed               | 30       | Communication address 0x3018 control output |
| 1        | Spindle drive running                        | 16       | Program running phase completed               | 31       | Spindle drive overheating warning           |

|    |  |    |                                    |    |                                  |
|----|--|----|------------------------------------|----|----------------------------------|
| 2  | Spindle drive reversing  | 17 | PID feedback over the upper limit  | 32 | Motor overheating warning output |
| 3  | Spindle drive forwarding   | 18 | PID feedback below the lower limit | 33 | Select motor 2                   |
| 4  | Fault trip warning 1<br>(warning during fault<br>self-recovery)    | 19 | PID feedback sensor disconnected   | 34 | output paused (module blocking)  |
| 5  | Fault trip warning 2 (no<br>warning during fault<br>self-recovery) | 20 | Counting meter length reached      | 35 | Torque limiting                  |
| 6  | External fault shutdown  | 21 | Timer time up                      | 36 | Running at upper limit speed     |
| 7  | Spindle drive undervoltage   | 22 | Counters maximum value reached     | 37 | Comparator 1                     |
| 8  | Spindle drive ready for<br>running                                 | 23 | Counter setpoint reached           | 38 | Comparator 2                     |
| 9  | Output frequency level<br>detection 1 (FDT1)                       | 24 | Energy-consumption braking         | 39 | Zero-servo ending                |
| 10 | Output frequency level<br>detection 2 (FDT2)                       | 25 | PG feedback disconnection          | 40 | Positioning completed            |
| 11 | Given frequency reached  | 26 | Emergency stopping                 | 41 | Spindle orientation completed    |
| 12 | Zero speed running   | 27 | Overload pre-warning output 1      | 42 | Position controlling             |
| 13 | Upper limit frequency<br>reached                                   | 28 | Overload pre-warning output 2      | 43 | Position approaching             |
| 14 | Lower limit frequency<br>reached                                   | 29 | Spindle drive sending warning      |    |                                  |

Table 4-51

#### 4.17 Fault and Warning Code List

Note: The numbers in brackets in the code column are fault codes or warning codes (Dec. means decimal).

| Display<br>(Dec.) | Fault name                       | Type  | Display (Dec.) | Fault name                          | Type  |
|-------------------|----------------------------------|-------|----------------|-------------------------------------|-------|
| E.SC1 (1)         | System fault in acceleration     | Fault | E.TExx (52)    | Motor parameter self-learning fault | Fault |
| E.SC2 (2)         | System failure in deceleration   | Fault | E.IAE1 (71)    | Motor angle learning fault 1        | Fault |
| E.SC3 (3)         | System failure at constant speed | Fault | E.IAE2 (72)    | Motor angle learning fault 2        | Fault |
| E.SC4 (4)         | Shutdown system fault            | Fault | E.IAE3 (73)    | Motor angle learning fault 3        | Fault |
| E.O.C1 (5)        | Overcurrent in acceleration      | Fault | E.PST1(74)     | Synchronizer out-of-step fault 1    | Fault |

|             |  |       |               |                                   |         |
|-------------|--|-------|---------------|-----------------------------------|---------|
| E.OC2 (6)   | Overcurrent in deceleration                | Fault | E.PST2(75)    | Synchronizer out-of-step fault 2  | Fault   |
| E.OC3 (7)   | Overcurrent at constant speed              | Fault | E.PST3(76)    | Synchronizer out-of-step fault 3  | Fault   |
| E.OU1 (9)   | Overvoltage in acceleration                | Fault | E.DEF (77)    | Excessive speed deviation         | Fault   |
| E.OU2 (10)  | Overpressure in deceleration               | Fault | E.SPD (78)    | Stall fault                       | Fault   |
| E.OU3 (11)  | Overvoltage at constant speed              | Fault | E.LD1 (79)    | Load protection 1                 | Fault   |
| E.LU (13)   | Undervoltage in running                    | Fault | E.LD2 (80)    | Load protection 2                 | Fault   |
| E.OL1 (14)  | Motor overload                             | Fault | E.CPU (81)    | CPU timeout fault                 | Fault   |
| E.OL2 (15)  | Spindle drive overload 1                   | Fault | E.LOC (85)    | Chip locking                      | Fault   |
| E.OL3 (16)  | Spindle drive overload 2                   | Fault | E.EEP (86)    | Parameter storage fault           | Fault   |
| E.OL4 (17)  | Spindle drive overload 3                   | Fault | E.BUS5 (95)   | CPLD communication error 1        | Fault   |
| E.ILF (18)  | Input phase loss                           | Fault | E.BUS6 (96)   | CPLD communication error 2        | Fault   |
| E.OLF (19)  | Three-phase output phase loss              | Fault | E.CP1 (97)    | Monitor comparison output 1 fault | Fault   |
| E.OLF1(20)  | U-phase output phase loss                  | Fault | E.CP2 (98)    | Monitor comparison output 2 fault | Fault   |
| E.OLF2(21)  | V-phase output phase loss                  | Fault | E.DAT (99)    | Parameter setting error           | Fault   |
| E.OLF3(22)  | W-phase output phase loss                  | Fault | E.POE (100)   | Position overrun fault            | Fault   |
| E.OH1 (30)  | Rectifier module overtemperature           | Fault | Warning codes |                                   |         |
| E.OH2 (31)  | IGBT module overtemperature                | Fault | A.LU1 (128)   | Shutdown undervoltage             | Warning |
| E.EF(33)    | External fault                             | Fault | A.OU (129)    | Shutdown overvoltage              | Warning |
| E.CE(34)    | Modbus communication fault                 | Fault | A.ILF (130)   | Input phase loss                  | Warning |
| E.HAL1(35)  | Large U-phase zero drift                   | Fault | A.PID (131)   | PID feedback disconnection        | Warning |
| E.HAL2(36)  | Large V-phase zero drift                   | Fault | A.EEP (132)   | Parameter storage warning         | Warning |
| E.HAL (37)  | None-zero sum fault of three phase current | Fault | A.DEF (133)   | Excessive speed deviation         | Warning |
| E.HAL3(38)  | Large W-phase zero drift                   | Fault | A.SPD (134)   | Stall warning                     | Warning |
| E.SGxx (40) | Ground short circuit                       | Fault | A.GPS1 (135)  | GPS locking                       | Warning |
| E.FSG (41)  | Fan short circuit                          | Fault | A.GPS2 (136)  | GPS disconnection                 | Warning |
| E.PID (42)  | PID feedback disconnection                 | Fault | A.CE (137)    | External warning                  | Warning |
| E.COP (43)  | Parameter copy fault                       | Fault | A.LD1 (138)   | Load protection 1                 | Warning |
| E.PG1 (44)  | PG parameter setting error                 | Fault | A.LD2 (139)   | Load protection 2                 | Warning |
| E.PG2 (44)  | Encoder Z-pulse fault                      | Fault | A.OH1 (141)   | Module over-temperature warning   | Warning |
| E.PG5 (44)  | ABZ encoder disconnection                  | Fault | A.OH3 (142)   | Motor over-temperature warning    | Warning |
| E.PG6 (44)  | Spindle encoder disconnection              | Fault | A.RUN1 (143)  | Run command conflicts             | Warning |

|            |                                     |       |              | -                                    |         |
|------------|-------------------------------------|-------|--------------|--------------------------------------|---------|
| E.PG7 (44) | Spindle encoder Z-pulse error fault | Fault | A.POE (156)  | Position overrun warning             | Warning |
| E.PG8 (44) | Encoder Z-pulse logic fault         | Fault | A.RUN2 (158) | Jogging terminal starting protection | Warning |
| E.PG9 (44) | Spindle encoder Z-pulse logic fault | Fault | A.RUN3 (159) | Terminal starting protection         | Warning |
| E.PG10(44) | Encoder Z-pulse disconnection       | Fault | A.CP1 (146)  | Monitor comparison output 1 warning  | Warning |
| E.BRU (50) | Brake unit fault                    | Fault | A.CP2 (147)  | Monitor comparison output 2 warning  | Warning |

Table 4-52

## Chapter 5 Spindle Function Application Guidance

### 5.1 Motor Self-Learning

Motor self-learning is required before commissioning. Please refer to the control circuit wiring diagram for wiring definitions, and parameters are as follows.

| Code<br>(Address)  | Designation                    | Content  | Factory value<br>(setting range)           | Adjustable<br>properties |
|--------------------|--------------------------------|--|--|--------------------------|
| F01.00<br>(0x0100) | Motor 1 control<br>method      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Control mode of motor<br>0:AM-VF; asynchronous motor V/F control<br>1:AM-SVC; asynchronous motor open-loop vector control<br>2:AM-FVC; asynchronous motor closed-loop vector control<br>10:PM-VF; synchronous motor V/F control<br>11:PM-SVC; synchronous motor open-loop vector control<br>12:PM-FVC; synchronous motor closed-loop vector control | 2<br>(0~12)                                | STOP                     |
| F02.01<br>(0x0201) | Motor poles No.                | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the number of motor poles.  | 4<br>(2~98)                                | STOP                     |
| F02.02<br>(0x0202) | Motor rated power              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated power of the motor.   | Set by models<br>(0.1~1000.0kW)            | STOP                     |
| F02.03<br>(0x0203) | Motor rated<br>frequency       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated frequency of the motor.   | Set by models<br>(0.01~ Max.<br>frequency) | STOP                     |
| F02.04<br>(0x0204) | Motor rated speed              | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated speed of the motor.   | Set by models<br>(0~65000rpm)              | STOP                     |
| F02.05<br>(0x0205) | Motor rated voltage            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated voltage of the motor.   | Set by models<br>(0~1500V)                 | STOP                     |
| F02.06<br>(0x0206) | Motor rated current            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the rated current of the motor.   | Set by models<br>(0.1~3000.0A)             | STOP                     |
| F02.30<br>(0x021E) | Speed feedback<br>encoder type | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: normal ABZ encoder<br>4: sine-cosine encoder  | 0<br>(0~2)                                 | STOP                     |
| F02.33<br>(0x0221) | ABZ encoder cable<br>No.       | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Sets the number of ABZ encoder cables.   | 2500<br>(1~10000)                          | STOP                     |
| F02.40             | Encoder installation           | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b>   | 0  | STOP                     |

|                    |                                    |  |                   |      |
|--------------------|------------------------------------|--|-------------------|------|
| (0x0228)           | position                           | V/F SVC FVC PMVF PMSVC PMFVC<br>0: single motor encoder 1: single spindle encoder 2: dual encoder  | (0~2)             |      |
| F02.43<br>(0x022B) | Position encoder<br>cable No.      | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Sets the number of ABZ encoder cables.   | 1024<br>(1~10000) | STOP |
| F02.07<br>(0x0207) | Self-tuning of motor<br>parameters | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>The value of [F02.07] will be set to "0" automatically upon completion of the adjustment.<br>0:no movement<br>1: stationary + rotary self-learning<br>2: stationary self-learning<br>3: stator resistance self-learning<br>6: Rotary self-learning<br>7: inertia self-learning | 0<br>(0~7)        | STOP |

Table 5-1

Set the parameters above, change F02.07 to 1 for rotary self-learning, and then r-00 is displayed, continue to press SET for 1 second until r-01 appears and then here goes the self-learning.

Before self-learning, users need to select the relevant parameters according to the encoder installation positions, choose the encoder installation position by F2.40: single motor encoder, single spindle encoder, double encoder.

**5.1.1 Single-motor Encoder Mode (F02.40=0)**

When the encoder is built into the motor, the default F2.40=0 parameter is used to set the number of encoder cables and then the self-learning can be performed directly.

If there is any difference between the actual speed and the set speed after the self-learning test run, it can be corrected by fine-tuning the parameter F15.28/F15.29.

**5.1.2 Single-spindle Encoder Mode (F2.40=1)**

When the encoder is not installed in the motor but in the mechanical spindle, set the number of encoder cables and select F2.40=1 for self-learning.

|                    |                              |  |                |     |
|--------------------|------------------------------|--|----------------|-----|
| F02.35<br>(0x0223) | Encoder ratio<br>numerator   | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder ratio numerator.   | 1<br>(1~32767) | RUN |
| F02.36<br>(0x0224) | Encoder ratio<br>denominator | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the encoder ratio denominator. | 1<br>(1~32767) | RUN |

Table 5-2

After self-learning, the encoder ratio will be automatically set to F02.35 and F02.36. The gain is weakened to prevent severe vibrations

from occurring in this mode.

### 5.1.3 Dual Encoder Mode (F2.40=2)

When the motor has a built-in encoder and the mechanical spindle also has an encoder, it is considered as the dual encoder mode, and it is necessary to set the number of two encoder cables and select F2.40=1 for self-learning.

|                    |   |  |                   |     |
|--------------------|---|--|-------------------|-----|
| F15.28<br>(0x0F1C) | Pulse numerator of transmission ratio   | V/F SVC FVC PMVF PMSVC PMFVC<br>Set pulse numerator of transmission ratio.   | 1000<br>(0~65535) | RUN |
| F15.29<br>(0x0F1D) | Pulse denominator of transmission ratio | V/F SVC FVC PMVF PMSVC PMFVC<br>Set pulse denominator of transmission ratio. | 1000<br>(0~65535) | RUN |

Table 5-3

In the dual encoder mode, self-learning will automatically learn the numerators and denominators of pulse number in the F15.28, F15.29 transmission ratio. The actual speed can be manually fine-tuned via F15.28, F15.29 if there is deviation in the speed mode.

## 5.2 Speed Control

| Code<br>(Address)  | Designation                       | Content  | Factory value<br>(setting range)                    | Adjustable<br>properties |
|--------------------|-----------------------------------|--|---|--------------------------|
| F01.02<br>(0x0102) | Frequency giving source channel A | V/F SVC FVC PMVF PMSVC PMFVC<br>Set the frequency giving source A for spindle drive.<br>0: given by keyboard numbers;<br>1: given by keyboard analog potentiometer give<br>2: given by voltage analog AI1<br>3: given by current/voltage analog AI2<br>4: reserved<br>5: given by terminal pulse PUL<br>6: given by RS485 communication<br>7: given by terminal UP/DW<br>8: given by PID<br>9: given by program control (PLC)<br>10: given by positioning pulse terminal<br>11: given by multi-speed | 10<br>(0~11)  | RUN                      |
| F01.10<br>(0x010A) | Max. frequency                    | V/F SVC FVC PMVF PMSVC PMFVC<br>The max. frequency that can be set for the spindle drive.  | 150.00Hz<br>(Upper limit<br>frequency<br>~600.00Hz) | STOP                     |
| F01.12<br>(0x010C) | Upper limit frequency setting via | V/F SVC FVC PMVF PMSVC PMFVC<br>The upper limit frequency given channel when F01.11 is set   | 150.00Hz<br>(0.00~ Max.                             | RUN                      |

|                    | keyboard numbers                    | to 0.  | frequency set via numbers)        |     |
|--------------------|-------------------------------------|--|-----------------------------------|-----|
| F01.22<br>(0x0116) | Acceleration time 1                 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The time it takes to accelerate the output frequency from 0.00Hz to the reference frequency.<br>1~65000s(F01.21 = 0)<br>0.1~6500.0s(F01.21 = 1)<br>0.01~650.00s(F01.21 = 2) | Set by models<br>(0.01~650.00s)   | RUN |
| F01.23<br>(0x0117) | Deceleration time1                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The time it takes to accelerate the output frequency from 0.00Hz to the reference frequency.  | Set by models<br>(0.01~650.00s)   | RUN |
| F03.02<br>(0x0302) | ASR (speed loop) proportional gain1 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the ASR (speed loop) proportional gain 1.   | 20.00<br>(0.01~100.00)            | RUN |
| F03.03<br>(0x0303) | ASR (speed loop) integral time 1    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the ASR (speed loop) integral time 1.   | 0.100s<br>(0.000~6.000s)          | RUN |
| F03.04<br>(0x0304) | ASR filter time1                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the ASR filter time 1.  | 0.0ms<br>(0.0~100.0ms)            | RUN |
| F03.05<br>(0x0305) | ASR switching frequency1            | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the ASR switching frequency 1.  | 10.00Hz<br>(0.00~ Max. frequency) | RUN |
| F03.06<br>(0x0306) | ASR (speed loop) proportional gain2 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the ASR (speed loop) proportional gain 2.   | 20.00<br>(0.01~100.00)            | RUN |
| F03.07<br>(0x0307) | ASR (speed loop) integral time 2    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the ASR (speed loop) integral time 2.   | 0.050s<br>(0.000~6.000s)          | RUN |
| F03.08<br>(0x0308) | ASR filter time 2                   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set ASR filter time 2.  | 0.0ms<br>(0.0~100.0ms)            | RUN |
| F03.09<br>(0x0309) | ASR switching frequency 2           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set ASR switching frequency 2.  | 5.00Hz<br>(0.00~ Max. frequency)  | RUN |
| F15.33<br>(0x0F21) | ADRC observer gain $\beta$ 2        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>For improving system response and rigidity.   | 100<br>(0~200)                    | RUN |
| F15.34<br>(0x0F22) | ADRC input factor b                 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>For improving system response and rigidity.   | 32<br>(1~200)                     | RUN |



|                    |                            |   |                     |      |
|--------------------|----------------------------|---|---------------------|------|
| F15.35<br>(0x0F23) | ADRC toggle switch         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Toggle switch between ADRC and PI.   | 1<br>(0~1)          | STOP |
| F07.05<br>(0x0705) | Rotary direction selection | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Ones-bit: Reverse running direction<br>0: direction unchanged 1: direction reversed<br>Tens-bit: Running direction disabled<br>0: forward and reverse commands allowed<br>1: only forward command allowed<br>2: Only reverse command allowed<br>Hundreds-bit: Frequency control command direction<br>0: frequency control direction invalid<br>1: frequency control direction valid<br>Thousands-bit: reserved | 0100<br>(0000~1111) | STOP |

Table 5-4




Figure 5-1

5.2.1 Analog Speed Control

The speed command source is given by the analog, and it can be controlled by unipolarity and bipolarity according to the actual needs. The direction cannot be changed by unipolarity, so it needs to switch forward and reverse directions via the X terminal, while the direction can be changed by the polarity of the analog for bipolarity. The maximum value of the analog input (10V/20mA) corresponds to the maximum frequency of the spindle servo drive, and the running direction can be changed by the F07.05.

The wiring pins and parameters involved in the commissioning are as follows.

Analog unipolarity 0~10V/4~20mA wiring: AI2(16), AGND (1/3/18/32).

Analog bipolarity -10V~+10V wiring: AI1(17), AGND (1/3/18/32).

The analog speed control changes F01.02 (frequency giving source channel A) to 3 (AI2) or 2 (AI1) according to unipolar or bipolar wiring, and adjusts F01.10 (maximum frequency) and F01.12 (upper frequency) and F01.22 (acceleration time) and F01.23 (deceleration time)

accordingly.

### 5.2.2 Pulse Speed Control

The speed command source is given by pulse, and the 5V differential signals given by CNC system are connected to PULS+(20), PULS-(5), SIGN+(19), SIGN-(4) respectively, please note that these four ports only receive 5V differential signals;

The pulse type and direction are changed by F15.02 (pulse counting mode), the related debugging parameters are the same as the speed list above, F01.02 default is 10 (given by pulse).

### 5.2.3 Speed Control Parameter Adjustment

#### Parameters related to ASR (speed loop) and PI.

F15.35 toggle switch between ADRC and PI.

F15.35 = 0, speed mode, position mode and orientation all with the PI controller;

F03.02 ASR proportional gain 1 (high speed gain); F03.03 ASR integral time 1 (high speed integration); F03.04 ASR filter time 1;

F03.05 ASR switching frequency 1;

F03.06 ASR proportional gain 2 (low speed gain); F03.07 ASR integral time 2 (low speed integration); F03.08 ASR filter time 2;

F03.09 ASR switching frequency 2.

The schematic diagram of the speed loop proportional gain and integration time switching is as follows.




Figure 5-2

#### Parameters related to ADRC.

F15.35 toggle switch between ADRC and PI control.

When F15.35=1, ADRC is used for speed mode and orientation mode, and PI is used for position mode; when F15.35=2, ADRC is used for speed mode, position mode, and orientation mode all.

After turning on ADRC, it's important to adjust F15.33 ADRC observer gain  $\beta_2$ , F15.34 ADRC input factor b but F03.02 and F03.06 are still valid.

F15.33 is equivalent to the integral gain ( $1/T_i$ ) of PI control. The larger, the more rigid it is, currently the default 100 is considered as high rigidity. When connection between the encoder and motor is non-rigid, please reduce its gain, otherwise it is easy to vibrate. When F2.40=1, the single spindle mode, it will be automatically set to 30.

F15.34 can be taken as inertia adjustment, and the normal adjustment range is 32~10, the smaller the value, the larger the electronic inertia adjusted at this time. Since the equivalent inertia becomes larger, response without overshoot can be achieved, and anti-interference performance is enhanced. And considering that the equivalent inertia is generated by the electromagnetic torque, so the smaller the F15.34, the greater the inertia, but more vibration is likely to happen.

### 5.3 Position Control

In the pulse position mode, a high-speed pulse terminal signal can be received, and C-axis functions such as indexing and rigid tapping can be performed when the X4 terminal is valid.

| Code<br>(Address)  | Designation                             | Content   | Factory value<br>(setting range) | Adjustable<br>properties |
|--------------------|---|---|----------------------------------|--------------------------|
| F15.00<br>(0x0F00) | Position control<br>mode                | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0:off; 1: on  | 0<br>(0~1)                       | RUN                      |
| F15.01<br>(0x0F01) | Pulse position giving<br>source         | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0: keyboard; 1: X7 terminal ; 2: pulse terminal   | 2<br>(0~2)                       | RUN                      |
| F15.02<br>(0x0F02) | Pulse counting mode                     | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>0:AB;<br>1:CW+CCW;<br>2: pulse + direction;<br>3: reserved;<br>4: reverse AB<br>5: reverse CW+CCW;<br>6: reverse pulse + direction;<br>7: reserved; | 4<br>(0~7)                       | STOP                     |
| F15.03<br>(0x0F03) | Keyboard number<br>giving               | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set pulses to be given via the keyboard.  | 0<br>(0~65535)                   | RUN                      |
| F15.04<br>(0x0F04) | Electronic gear<br>numerator            | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set electronic gear ratio numerator.  | 1<br>(1~32767)                   | STOP                     |
| F15.05<br>(0x0F05) | Electronic gear<br>denominator          | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set electronic gear ratio denominator.  | 1<br>(1~32767)                   | STOP                     |
| F15.06<br>(0x0F06) | First order filter time<br>for position | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Filter the input position command to make motor rotation smoother.  | 0.0<br>(0.0~6000.0ms)            | RUN                      |
| F15.07             | Smooth filter time for                  | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b>  | 0.1                              | STOP                     |

|                    |  |   |                          |     |
|--------------------|--|---|--------------------------|-----|
| (0x0F07)           | position                                   | Filter the input position command to make motor rotation smoother.  | (0.0~512.0ms)            |     |
| F15.08<br>(0x0F08) | Speed feedforward gain                     | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system dynamic running and following.   | 0.0%<br>(0.0%~300.0%)    | RUN |
| F15.09<br>(0x0F09) | Speed feedforward filter time              | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Filter the command pulse signal to improve interference immunity.   | 1.0<br>(0.0~100.0ms)     | RUN |
| F15.10<br>(0x0F0A) | Position controller output limit           | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Set the output limit value of the position proportional controller.   | 100.0%<br>(0.0%~100.0%)  | RUN |
| F15.11<br>(0x0F0B) | Position loop proportional gain 1          | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system response and rigidity.   | 50.0<br>(0.0~600.0Hz)    | RUN |
| F15.12<br>(0x0F0C) | Position loop proportional gain 2          | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system response and rigidity.   | 30.0<br>(0.0~600.0Hz)    | RUN |
| F15.25<br>(0x0F19) | Position controlling ASR proportional gain | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system response and rigidity.   | 30.00<br>(0.01~100.00)   | RUN |
| F15.26<br>(0x0F1A) | Position controlling ASR integral time     | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>For improving system response and rigidity.   | 0.050s<br>(0.000~6.000s) | RUN |
| F15.46<br>(0x0F2E) | Low speed measurement method               | V/F SVC <b>FVC</b> PMVF PMSVC <b>PMFVC</b><br>Speed measurement method during position control<br>0: low speed equivalent M method<br>1: M/T method + T method estimation | 0<br>(0~1)               | RUN |

Table 5-5




Figure 5-3

To raise rigidity, increase F15.11, F15.25, and decrease F15.26 values, but users need to consider the problems between jitter and sound. If jitter occurs at the arrival position, reduce the gain appropriately. And to further improve the response speed, increase F15.08 speed feedforward

gain.

### Common problems during pulse position control

**Problem 1:** The system is enabled but the motor does not run or does not run properly.

**Monitor:** C5.20 pulse command counting

**Judgement:** If there is no change in C5.20, there may be a wiring or soldering error; If there is a change in C05.20: but the value is abnormal and the running is not regular, check whether the pulse counting mode is abnormal.

**Problem 2:** Exact positions can't be reached.

**Monitor:** C5.20 pulse command counting, C5.25 motor encoder pulse counting (spindle encoder C4.25), C4.15 position error

**Judgement:** If C5.20 and C5.25 increments are the same, and C4.15=0, check whether the system ratio and command are set correctly; otherwise, try to increase gain a little.

**Problem 3:** Analysis of jitter during position control

**Monitor:** C04.15 position error

High-frequency jitter: loud vibration sound, strong vibration felt by hands if not by naked eyes, generally such vibration is caused by high gain of speed loop.

**Conclusion:** Reduce the speed loop gain F15.25; and increase F2.37 speed feedback filter (increased to 3~7ms);

Low-frequency jitter: vibration can be observed by the naked eye and frequency is low, which is generally caused by high gain of position loop or the speed measurement method.

**Conclusion:** Reduce position loop gain F15.11, increase the integral time F15.26 and weaken the response; Adjust F15.46 speed measurement method (0~1 modification)

## 5.4 Spindle Orientation

Z pulse or proximity switch can be used for the zero point of orientation positioning and orientation is available when X3 terminal is valid.

Set the orientation point: For only one orientation point, check the current value by entering C04.00 and long press the confirmation key for 3 seconds, and exit the current value to confirm the change, and the current value will be stored in F24.07. Check the value of F24.07 after setting is completed.

| Code<br>(Address)  | Designation                        | Content   | Factory value<br>(setting range) | Adjustable<br>properties |
|--------------------|------------------------------------|---|----------------------------------|--------------------------|
| F24.00<br>(0x5800) | Spindle positioning                | V/F SVC FVC PMVF PMSVC PMFVC<br>0: disabled; 1: enabled   | 0<br>(0~1)                       | STOP                     |
| F24.01<br>(0x5801) | Orientation positioning zero point | V/F SVC FVC PMVF PMSVC PMFVC<br>0:Z-pulse; 1: proximity switch  | 0<br>(0~1)                       | STOP                     |
| F24.02<br>(0x5802) | Zero update mode                   | V/F SVC FVC PMVF PMSVC PMFVC<br>0: update only at the first time after power-up<br>1: update at each zero-edge delay signal | 0<br>(0~1)                       | STOP                     |

|                     |   |   |                          |      |
|---------------------|---|---|--------------------------|------|
| F24.03<br>(0x5803)  | Orientation mode 2 running mode                             | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: positioning mode 2 running less than 1 turn<br>1: positioning mode 2 running spindle running more than 1 turn | 0<br>(0~1)               | STOP |
| F24.04<br>(0x5804)  | Orientation running direction                               | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>0: principle of shortest stroke<br>1: forward<br>2: reverse  | 0<br>(0~2)               | STOP |
| F24.05<br>(0x5805)  | Orientation speed   | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set the speed when searching for Z pulses or proximity switches.   | 5.00<br>(0.01~100.00Hz)  | STOP |
| F24.06<br>(0x5806)  | Orientation acceleration/deceleration time                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set acceleration / deceleration time when searching for Z pulse or proximity switch.                             | 3.00s<br>(0.01~100.00s)  | STOP |
| F24.07<br>(0x5807)  | Spindle indexing offset                                     | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set spindle indexing offset value  | 0<br>(0~65535)           | STOP |
| F24.16<br>(0x5810)  | Delay time of indexing selection terminal with valid change | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set delay time of indexing selection terminals when changes are valid.   | 0.010S<br>(0.000~1.000S) | STOP |
| F24.20<br>(0x5814)  | Orientation position loop proportional gain                 | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set orientation position loop proportional gain.   | 60.0Hz<br>(0.1~600.0Hz)  | RUN  |
| F24.21<br>(0x5815)  | Orientation speed loop proportional gain                    | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set orientation speed loop proportional gain.  | 20.00<br>(0.01~100.00)   | RUN  |
| F24.22<br>(0x5816)  | Orientation speed loop integral time                        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set orientation speed loop integral time.  | 0.050s<br>(0.000~6.000s) | RUN  |
| F24.23<br>(0x5817)  | Zero-speed orientation position loop proportional gain      | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set zero-speed orientation position loop proportional gain.  | 40.0Hz<br>(0.1~600.0Hz)  | RUN  |
| F24.24<br>(0x5818)  | Zero-speed position loop output limit                       | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Limit position loop output amplitude at zero speed.  | 2.5%<br>(0.0~100.0%)     | RUN  |
| F024.25<br>(0x5819) | Proximity switch equivalent number of pulses in one         | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The number of one-turn pulses of the orientated  | 0<br>(0~65535)           | STOP |

|                     |   |  |                 |      |
|---------------------|---|--|-----------------|------|
|                     | revolution  | proximity switch is automatically set during self-learning.  |                 |      |
| F024.26<br>(0x581A) | Effective number of proximity switch rotation after starting                  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>A value greater than this is considered valid for an orientated position.   | 2<br>(0~100)    | STOP |
| F024.27<br>(0x581B) | Proximity switch orientated positioning effective times after starting        | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The first orientated positioning is performed only if it is greater than this value, otherwise it will keep rotating to find the proximity switch point.  | 3<br>(0~100)    | STOP |
| F024.28<br>(0x581C) | Proximity switch captured effective deviation threshold during first power-up | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Judge whether the captured proximity switch latching point is valid according to the first three rotations, if the deviation of the first two comparisons with the corresponding number of pulses per revolution F24.25 is within the setting range of this value, it is considered normal, otherwise the search for the finite proximity switch point will start again.  | 20<br>(0~65535) | STOP |
| F024.29<br>(0x581D) | 2nd gear proximity switches equivalent number of pulses in one turn           | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>The number of one-turn pulses when the second gear proximity switch is orientated, which is set automatically during self-learning. The second gear works when the Xi terminal is set to 86 and receives a high level, and system will send to the drive that this is the second gear and the drive runs as the second gear parameter F24.29/F24.30, otherwise it runs as the first gear parameter F24.25/F24.07. | 0<br>(0~65535)  | STOP |
| F24.30<br>(0x581E)  | 2nd gear spindle indexing offset  | <b>V/F SVC FVC PMVF PMSVC PMFVC</b><br>Set spindle indexing offset value.  | 0<br>(0~65535)  | STOP |

Table 5-6




Figure 5-4

### Orientation FAQ

**Problem 1:** The motor is moving too slowly when it is stationary to enable orientation.

**Treatment:** Reduce F24.06 acceleration/deceleration time and increase F24.23/24 value.

**Problem 2:** The quasi-stop is not stopped accurately

**Monitoring:** C4.15 position error

**Judgment:** C4.15=0, then determine whether the system mode is set correctly; rotate the axis and observe C4.00 to determine whether the quasi-stop point is the desired point.

## 5.5 Common Faults and Problems Explanation

### 5.5.1 Encoder-related Faults

Self-learning-related fault E. PGxx's detailed diagnosis information is shown in the table below, "xx" is the self-learning fault sub-code, or C01.01=44xx.

| Sub-code | Troubleshooting information       | Solutions   |
|----------|-----------------------------------|---|
| 1        | Encoder parameter error           | Motor rotation frequency is not consistent with the encoder feedback frequency.<br>The difference between the numerator/denominator of the encoder ratio (F02.35/F02.36) is too large |
| 2        | Motor encoder Z-pulse fault       | 1. Wrong setting of encoder wire number.<br>2. The encoder has lost pulse or the external encoder pulley is skidding.   |
| 5        | Motor encoder disconnection fault | Hardware does not detect a clear level signal<br>1. Encoder fault.<br>2. Cables are not plugged (F2.38=0 for shielding, not recommended to shield for common use)                     |



|    |   |  |
|----|---|--|
| 6  | Spindle encoder disconnection fault       | Hardware does not detect a clear level signal<br>1. Encoder fault.<br>2. Cables are not plugged (F2.38=0 for shielding, not recommended to shield for common use)  |
| 7  | Spindle encoder Z-pulse fault             | 1.Wrong setting of encoder cable number.<br>2.The encoder has lost pulse or the external encoder pulley is skidding.   |
| 8  | Motor encoder Z-logic fault               | 1. Encoder Z signal rewired without self-learning (F02.07=6).<br>2.Strong electrical interference is serious without grounding and shielded wires.<br>3.Magnetic ring encoder sensor installation distance is far. |
| 9  | Spindle encoder Z-logic fault             | 1. Encoder Z signal rewired without self-learning (F02.07=6).<br>2.Strong electrical interference without grounding and shielded wires.<br>3.Magnetic ring encoder sensor installation distance is too far.        |
| 10 | Motor encoder Z-pulse loss fault          | Z pulse width is too narrow and the rotation speed is too fast, set F2.46 to 0 for shielding.  |
| 11 | Spindle encoder Z-pulse loss fault        | Z pulse width is too narrow and the rotation speed is too fast, set F2.46 to 0 for shielding.  |
| 15 | Enable before self-learning cause warning | Disable first for self-learning.   |
| 16 | Excessive load-motor deviation warning    | Check whether the spindle encoder signal is abnormal.  |

Table 5-7

### 5.5.2 Self-learning Related Faults

Self-learning fault E. TExx's detailed diagnosis information is shown in the table below, "xx" is the self-learning fault sub-code, or

C01.01=52xx.

| Subcode | Troubleshooting information  | Solutions  |
|---------|--|--|
| 1       | Current saturation, Hall detection problem or excessive output current | 1. Check whether there is a phase short circuit among the motor cable, and please connect the motor cables correctly.<br>2. Rotation by a certain angle may result in too much current during synchronous motor DC learning. Try to learn a few times again.<br>3.The internal wiring of the inverter is abnormal or damaged, please contact the manufacturer. |
| 2       | Excessive current zero bias  | 1. Check whether there is a problem with the Hall sensor.<br>2. If the fault is not eliminated after several times of self-learning, please contact  |

|   |   |  |
|---|---|--|
|   |   | the manufacturer.  |
| 3 | Unbalance current                                   | <ol style="list-style-type: none"> <li>1. Check whether there is output phase loss of motor cables, and please connect the motor cables correctly if any mistakes.</li> <li>2. Measure the resistance value among the motor cables, please replace the cable if any deviation.</li> </ol>  |
| 4 | Current oscillation                                 | <ol style="list-style-type: none"> <li>1. Check whether there is a phase short circuit among the motor wires, please connect the motor wires correctly if there any mistake.</li> <li>2. Check whether the input motor nameplate parameters are correct, please correct them if any errors.</li> <li>3. Set the acceleration/deceleration time too large to casue current oscillation, appropriately reduce F01.22 [acceleration time 1] and F01.23 [deceleration time 1].</li> <li>4. Adjust F04.06 [oscillation suppression gain] according to the parameter description.</li> </ol> |
| 5 | Static learning current amplitude exceeds the limit | <ol style="list-style-type: none"> <li>1. Check whether there is a phase short circuit in the motor line, if there is an error, please connect the motor line correctly</li> <li>2. Check whether the input motor nameplate parameters and the number of encoder cables are correct, please correct the errors.</li> <li>3. Make sure the rated current of the motor is smaller than the output current limit of the inverter.</li> </ol>  |
| 6 | U phase current overrun during static learning      | Check the U-phase motor connection, whether there is a phase-to-phase or ground short circuit, please connect correctly if there is a mistake.   |
| 7 | V phase current overrun during static learning      | Check the V-phase motor connection, whether there is a phase-to-phase or ground short circuit, please connect correctly if there is a mistake.   |
| 8 | W phase current overrun during static learning      | Check the W-phase motor connection, whether there is a phase-to-phase or ground short circuit, please connect correctly if there is a mistake.   |
| 9 | Continuous current overrun during dynamic learning  | <ol style="list-style-type: none"> <li>1. Check whether there is a phase short circuit among the motor wires, please connect the motor wires correctly if there is a mistake.</li> <li>2. Check whether the input motor nameplate parameters are correct, please correct if there is a mistake.</li> <li>3. Make sure that the load carried by the motor does not exceed 50% of the rated load.</li> <li>4. Increase F01.22 [acceleration time 1] and F01.23 [deceleration time 1]</li> </ol>  |

|    |  |   |
|----|--|---|
|    |  | appropriately.  |
| 10 | Voltage saturation                             | <ol style="list-style-type: none"> <li>1. Check whether there is an open circuit among the motor connection cables, please connect the motor cables correctly if there is an error.</li> <li>2. Check whether the input motor nameplate parameters are correct, please correct if there is a mistake.</li> <li>3. Shorten the motor power cable length (&lt;1000m) or increase the motor power cable diameter.</li> </ol> |
| 15 | Too high rotor resistance value                | <ol style="list-style-type: none"> <li>1. Check whether the input motor nameplate parameters are correct, please correct the mistakes.</li> <li>2. Shorten the motor power cable length (&lt;1000m) or increase the motor power cable diameter.</li> </ol>  |
| 16 | Excessive inductance                           | <ol style="list-style-type: none"> <li>1. Check whether the input motor nameplate parameters are correct, please correct the mistakes.</li> <li>2. Shorten the motor power cable length (&lt;1000m) or increase the motor power cable diameter.</li> </ol>  |
| 40 | Self-learning timeout                          | <ol style="list-style-type: none"> <li>1. Check whether the input motor nameplate parameters are correct, please correct if there is a mistake.</li> <li>2. Check whether the difference between inverter power level and motor power level is too large (&gt;3 levels).</li> <li>3. If the fault is not eliminated after several times of self-learning, please contact the manufacturer.</li> </ol>                     |
| 41 | Parameter error                                | Re-enter the motor nameplate parameters correctly and make sure the rated frequency of the motor is in the range of 10~500Hz.   |
| 44 | Negative rotor resistance                      | <ol style="list-style-type: none"> <li>1. Check whether the input motor nameplate parameters are correct.</li> <li>2. If the fault is not eliminated after several times of self-learning, please contact the manufacturer.</li> </ol>  |
| 45 | Synchronous motor output voltage exceeds limit | Check whether the input motor nameplate parameters are correct (especially whether the keyboard input rated frequency is larger than the motor nameplate rating).   |
| 46 | High learning counter potential voltage        | Check whether the input motor nameplate parameters are correct (especially whether the keyboard input rated frequency is larger than the motor nameplate rating).   |
| 47 | Low learning counter potential voltage         | 1. Check whether the input motor nameplate parameters are correct (especially   |

|        |   |  |
|--------|---|--|
|        |   | <p>the keyboard input rated frequency is much smaller than the motor nameplate rating).</p> <p>2. Check whether the motor is demagnetized.</p>   |
| 49     | Motor parameter error                                   | 1. Check whether the input motor nameplate parameters are correct, wrong rated frequency setting will lead to this fault.  |
| 50     | Wrong direction of motor rotation                       | <p>1. Check whether the number of encoder cables is set correctly.</p> <p>2. Check whether the motor load is too large (&gt;30%).</p> <p>3. Separate the motor from the machine and start the learning again.</p>  |
| 52     | Z-pulse not detected by synchronous motor               | <p>1. Check whether the encoder Z pulse wiring is normal.</p> <p>2. Check whether the encoder connection cable is poorly wired causing excessive interference.</p> <p>3. Make sure the encoder output Z pulse normally.</p> <p>4. Motor pole number setting error.</p> |
| 53     | Z pulse deviation of the synchronous motor is too large | <p>1. Check whether the number of encoder cables is set correctly.</p> <p>2. Check whether the encoder connection cable is poorly wired to cause excessive interference.</p>   |
| 61     | Limited maximum frequency                               | The maximum frequency of the inverter set is smaller than the rated frequency of the motor, reset the maximum frequency of the inverter and the upper limit frequency and then learn again.  |
| 62     | Excessive current deviation between inverter and motor  | Check whether the difference between the power level of the inverter and the power level of the motor is too large, please ensure the difference does not exceed 2 power level.  |
| 90     | Stop command given during self-learning                 | Fail to complete parameter learning, so please start learning again. Enable signal is given during self-learning.  |
| Others | Multiple faults occur simultaneously during learning    | <p>1. Check whether the motor connection is correct.</p> <p>2. The sub-code fault is still reported after rewiring, please seek technical support from the manufacturer.</p>   |

Table 5-8

## Chapter 6 Inspection, Maintenance and Warranty

### 6.1 Inspection

Spindle drives consist of semiconductor devices, passive electronics, and motion devices, and all these devices have a service life. Even under normal operating conditions, some of the devices may change their characteristics or fail if their service life is exceeded. To prevent this kind of failure, preventive inspection and maintenance such as daily inspection, periodic inspection, and device replacement must be performed.

It is recommended that inspection be performed every 3~4 months after the machine is installed.

- Daily inspection: to avoid damage to the spindle drive and shortened service life, please check the following items daily.

| Item           | Inspection content   | Solution  |
|----------------|--|---|
| Power supply   | Check whether the supply voltage meets the requirements and whether there is a lack of phase supply.                             | Solve by nameplate.   |
| Surroundings   | Check whether the installation environment meets the requirements.   | Identify the source and address it properly.  |
| Cooling system | Check whether there is abnormal heat and discoloration on the spindle drive and motor, and the working condition of cooling fan. | Confirm if there is overload, whether the heat sink of the spindle drive is dirty, or the fan is blocked. Tighten the screws. |
| Motor          | Check whether there is abnormal vibration and abnormal sound of the motor.   | Fasten mechanical and electrical connections and lubricate mechanical parts.  |
| Load condition | Check whether the spindle drive output current is higher than the motor or spindle drive rating for a certain period.            | Verify that no overload has occurred and that the spindle drive is correctly selected.  |

Table 6-1

- Periodic inspection: generally, it is appropriate to conduct periodic inspection every 3 to 4 months, but in actual cases, please inspect based on the actual usage and working environment of each machine.

| Item                  | Inspection content  | Solution  |
|-----------------------|---|---|
| Overall               | Insulation resistance check; environmental check.   | Fasten and replace defective parts; clean and improve the working environment.  |
| Electrical connection | <ul style="list-style-type: none"> <li>• Whether the cables and connections are discolored, or whether the insulation is broken, cracked, discolored, or aged;</li> <li>• Whether the connection terminal is worn, damaged or loose;</li> <li>• Grounding check.</li> </ul> | <ul style="list-style-type: none"> <li>• Replace damaged wires;</li> <li>• Tighten loose terminals and replace damaged terminals;</li> <li>• Measure the grounding resistance and tighten the corresponding grounding terminals.</li> </ul> |
| Mechanical connection | <ul style="list-style-type: none"> <li>• Whether there is abnormal vibration and rattling sound, and whether the fixing is loose.</li> </ul>  | <ul style="list-style-type: none"> <li>• Fasten, lubricate, and replace defective parts.</li> </ul>   |
| Semiconduct           | <ul style="list-style-type: none"> <li>• Whether it is covered with garbage and dust;</li> </ul>  | <ul style="list-style-type: none"> <li>• Clean the working environment;</li> </ul>  |

|                        |  |  |
|------------------------|--|--|
| or devices             | <ul style="list-style-type: none"> <li>Whether there is any obvious change on the appearance.</li> </ul>   | <ul style="list-style-type: none"> <li>Replace damaged parts.</li> </ul>   |
| Electrolytic capacitor | <ul style="list-style-type: none"> <li>Whether liquid leakage, discoloration, cracking, safety valve exposure, expansion, rupture or leakage.</li> </ul>   | <ul style="list-style-type: none"> <li>Replace damaged parts.</li> </ul>   |
| Surroundings           | <ul style="list-style-type: none"> <li>External equipment appearance and insulation inspection.</li> </ul>   | <ul style="list-style-type: none"> <li>Clean the environment and replace damaged parts.</li> </ul>   |
| Printed circuit board  | <ul style="list-style-type: none"> <li>Whether there is odor, discoloration, serious rust, and whether the connectors are correct and reliable.</li> </ul>   | <ul style="list-style-type: none"> <li>Fasten connections;</li> <li>Clean the printed circuit board;</li> <li>Replace damaged printed circuit boards;</li> </ul> |
| Cooling system         | <ul style="list-style-type: none"> <li>Whether the cooling fan is broken or blocked;</li> <li>Whether the heat sink is contaminated with garbage and dusty or dirty;</li> <li>Whether the air inlet and exhaust port are blocked or contaminated with foreign matter.</li> </ul> | <ul style="list-style-type: none"> <li>Clean the working environment;</li> <li>Replace damaged parts.</li> </ul>   |
| Keyboard               | <ul style="list-style-type: none"> <li>Whether the keyboard is broken and the display is defective.</li> </ul>   | <ul style="list-style-type: none"> <li>Replace damaged parts.</li> </ul>   |
| Motor                  | <ul style="list-style-type: none"> <li>Whether the motor has abnormal vibration and abnormal rattling sound.</li> </ul>  | <ul style="list-style-type: none"> <li>Fasten mechanical and electrical connections and lubricate the motor shaft.</li> </ul>                                    |

Table 6-2

**Note:** Do not carry out the relevant work while the power is on, otherwise there is a risk of death by electric shock. So, when carrying out the relevant work, please cut off the power and make sure that the DC voltage of the main circuit has dropped to a safe level, and wait for 5 minutes before any movements.

## 6.2 Maintenance

All equipment and components have a service life. Proper maintenance may extend the life, but not solve the damaged equipment and devices, please replace the devices according to the requirements.

| Part name | Life cycle | Part name              | Life cycle | Part name             | Life cycle |
|-----------|------------|------------------------|------------|-----------------------|------------|
| Fan       | 2~3 years  | Electrolytic capacitor | 4~5 years  | Printed circuit board | 8~10 years |

Table 6-3

## 6.3 Product Warranty

- If the product fails during the warranty period, please refer to the warranty terms on the warranty card for details about the scope.
- In general, the primary fault diagnosis will be carried out by customers, but the service can be provided by Veichi or Veichi's service network for a fee at your request. If the cause of the failure is on the product itself, the service will be free of charge based on mutual discussion.
- Exemption from liability. Any inconvenience caused to customers or or secondary customers by the failure of our products and any damage caused to non-our products, whether within the warranty period, shall not fall within the scope of our responsibility.

## Appendix

### Appendix I: Modbus Communication Protocol

#### • Communication frame structure

The communication data format is as follows.

One byte includes a start bit, 8 data bits, a parity bit and a stop bit.

|           |      |      |      |      |      |      |      |      |            |          |
|-----------|------|------|------|------|------|------|------|------|------------|----------|
| Start bit | Bit1 | Bit2 | Bit3 | Bit4 | Bit5 | Bit6 | Bit7 | Bit8 | Parity bit | Stop bit |
|-----------|------|------|------|------|------|------|------|------|------------|----------|

Table appendix-1

The information of a frame must be transmitted in a continuous data stream. If the interval time before the end of the whole frame transmission is more than 1.5 bytes, the receiving device will clear this incomplete information and incorrectly assume that the subsequent byte is the address field part of the new frame. Similarly, if the interval between the start of a new frame and the previous frame is fewer than 3.5 bytes, the receiving device will consider it as a continuation of the previous frame and, due to the misalignment of the frame, the final CRC checksum value will be incorrect, resulting in a communication error.

#### • Communication control parameter group address description

| Function description                     | Address definition | Data description   |   | R/W |
|--|--------------------|--|---|-----|
| Communication giving frequency           | 0x3000 or 0x2000   | 0~32000 corresponds to 0.00Hz~320.00Hz   |   | W/R |
| Communication command setting            | 0x3001 or 0x2001   | 0x0000: No command<br>0x0001: Forward running<br>0x0002: Reverse running<br>0x0003: Forward jogging<br>0x0004: Reverse jogging | 0x0005: Deceleration stop<br>0x0006: Free stop<br>0x0007: Fault reset<br>0x0008: Running not allowed<br>0x0009: Running allowed | W/R |
| Spindle drive status                     | 0x3002 or 0x2002   | Bit0   | 0: Stop<br>1: Running   | R   |
|  |                    | Bit1   | 0: Non-accelerated<br>1: Accelerating   |     |
|  |                    | Bit2   | 0: Non-deceleration<br>1: Decelerating  |     |
|  |                    | Bit3   | 0: Forward<br>1: Reverse  |     |
|  |                    | Bit4   | 0: No fault<br>1: Spindle drive failure   |     |
|  |                    | Bit5   | 0: GPRS unlocked<br>1: GPRS locked  |     |
| Spindle drive fault code                 | 0x3003 or 0x2003   | Current fault code of the spindle drive (see fault code table)   |   | R   |
| Communication giving the upper frequency | 0x3004 or 0x2004   | 0~32000 corresponds to 0.00Hz~320.00Hz   |   | W/R |
| Communication torque setting             | 0x3005 or 0x2005   | 0~1000 corresponds to 0.0~100.0%   |   | W/R |
| Torque controlling forward max frequency | 0x3006 or 0x2006   | 0~1000 corresponds to 0.0~100.0%   |   | W/R |
| Torque controlling reverse max frequency | 0x3007 or 0x2007   | 0~1000 corresponds to 0.0~100.0%   |   | W/R |
| Communication giving PID                 | 0x3008 or 0x2008   | 0~1000 corresponds to 0.0~100.0%   |   | W/R |
| Communication giving the PID             | 0x3009 or 0x2009   | 0~1000 corresponds to 0.0~100.0%   |   | W/R |








Figure appendix-2




Figure appendix-3

| Analog cable |            |                      |              | IO signal cable |            |                              |              |
|--------------|------------|----------------------|--------------|-----------------|------------|------------------------------|--------------|
| Pin          | Definition | Function             | Remark       | Pin             | Definition | Function                     | Remark       |
| 16           | AI2        | 0~10V or 0~20mA      | 2-wire       | 10              | X4         | Multi-contact input 4        | 2-wire       |
| 18           | AGND       | Analog GND           | twisted pair | 25              | X5         | Multi-contact input 5        | twisted pair |
| 4            | SIGN-      | Command direction-   | 2-wire       | 11              | X1         | Multi-contact input 1        | 2-wire       |
| 19           | SIGN+      | Command direction +  | twisted pair | 26              | X2         | Multi-contact input 2        | twisted pair |
| 5            | PULS-      | Pulse command -      | 2-wire       | 12              | 24V+       | Internal 24V,100mA           | 2-wire       |
| 20           | PULS+      | Pulse command +      | twisted pair | 42              | COM        | Internal +24V power grounded | twisted pair |
| 6            | OB-        | Crossover output OB- | 2-wire       | 14              | TA2        | Relay A2                     | 2-wire       |
| 21           | OB+        | Crossover output OB+ | twisted pair | 43              | TC2        | Relay C2                     | twisted pair |
| 7            | OA-        | Crossover output OA- | 2-wire       | 15              | TA1        | Relay A1                     | 2-wire       |
| 22           | OA+        | Crossover output OA+ | twisted pair | 44              | TC1        | Relay C1                     | twisted pair |
| 35           | OZ-        | Crossover output OZ- | 2-wire       | 27              | SC         | I/O Public port+             | 2-wire       |
| 36           | OZ+        | Crossover output OZ+ | twisted pair | 39              | X7         | Multi-contact input 7        | twisted pair |

|                 |    |                 |  |                 |     |                          |                     |
|-----------------|----|-----------------|--|-----------------|-----|--------------------------|---------------------|
| Inner iron case | PE | Shielding layer |  | 28              | Y2+ | Open collector output 2+ | 2-wire twisted pair |
|                 |    |                 |  | 13              | Y1+ | Open collector output 1+ |                     |
|                 |    |                 |  | 40              | X6  | Multi-contact input 6    | 2-wire twisted pair |
|                 |    |                 |  | 41              | X3  | Multi-contact input 3    |                     |
|                 |    |                 |  | 29              | TB2 | Relay B2                 | 2-wire twisted pair |
|                 |    |                 |  | 30              | TB1 | Relay B1                 |                     |
|                 |    |                 |  | Inner iron case | PE  | Shielding layer          |                     |

Table appendix-4

2. Encoder cables

# ENC M – L03 – B S L




Figure appendix-4

1) Single encoder cable




Figure appendix-5

2) Dual encoder cable






Figure appendix-6



View A



Assembled female connector (jack)

Figure appendix-7

Figure appendix-8

| Signal definition    | Terminal A Pin No. (DB15) |   | Terminal B Pin No. (Air plug)   | Remark       |
|----------------------|---------------------------|---|---------------------------------|--------------|
| A-                   | 3                         | ↔ | 4                               | twisted pair |
| A+                   | 8                         |   | 3                               |              |
| B-                   | 4                         |   | 6                               | twisted pair |
| B+                   | 9                         |   | 5                               |              |
| 5V                   | 12                        |   | 1                               | twisted pair |
| 0V                   | 13                        |   | 2                               |              |
| Z-                   | 14                        |   | 8                               | twisted pair |
| Z+                   | 15                        | 7 |                                 |              |
| PE (Shielding layer) | Internal metal case       |   | 10                              |              |
| 5V                   | 12                        | ↔ | tubular pre-insulated terminals | twisted pair |
| 0V                   | 13                        |   |                                 | twisted pair |
| U-                   | 1                         |   |                                 | twisted pair |
| U+                   | 6                         |   |                                 | twisted pair |
| W-                   | 2                         |   |                                 | twisted pair |
| W+                   | 7                         |   |                                 | twisted pair |
| V-                   | 5                         |   |                                 | twisted pair |
| V+                   | 10                        |   |                                 | twisted pair |
| T1                   | 11                        |   |                                 |              |
| PE (Shielding layer) | Internal metal case       |   |                                 |              |

Table appendix-5

Note: Single encoder cables are enough for normal cases but please choose the double encoder cables if there is any need.

The view A and B of single and double encoder are the same, the wiring definition of the double encoder has the signal under the PE shielding layer in the above table when compared to the single encoder.